

MICREX-SX *series*

USER'S MANUAL

Software Package for Personal Computers

SX-Programmer Standard V3 <Reference>

Type: NP4H-SWN

Preface

Thank you for your selection of Fuji Electric Programmable Controller MICREX-SX Series.

This User's Manual explains the details of how to use the MICREX-SX Series Personal computer loader software package SX-Programmer Standard V3. After learning basic operations, use this manual to check the detailed functions.

For the basic operations, refer to <Introduction> (FEH597).

Also read the related manuals shown below.

Special Notes

- 1) This product cannot read programs created by SX-Programmer Expert (D300win).
(There is no compatibility with each other.)
- 2) The PLC model names displayed in the loader screen in this manual may have been increased on the loader screen of the latest version according to addition of new models. The company name displayed in the loader screen may have also been changed according to changes in organization structure.

Title	Manual No.	Contents
User's Manual Instructions, MICREX-SX series SPH	FEH588	Explains the memory, language and system definitions of the MICREX-SX series SPH.
User's Manual Hardware, MICREX-SX series SPH	FEH201	Explains the system configuration, hardware specifications and operations of modules in the MICREX-SX series SPH.
User's Manual Instructions, MICREX-SX series SPB (SX-mode) Standard	FEH430	Explains the memory, language and system definitions of the MICREX-SX series SPB.
User's Manual Hardware, MICREX-SX series SPB	FEH401	Explains the system configuration, hardware specifications and operations of units in the MICREX-SX series SPB.
User's Manual Board Controller, MICREX-SX series	FEH423	Explains the system configuration, hardware and software specifications, and operations of the board controller.
User's Manual SX-Programmer Standard V3 <Introduction>	FEH597	Explains basic operation of SX-Programmer Standard V3.
Replacement Manual, MICREX-F with SX <Introduction>	FEH059	Explains the outline and procedure of replacement of MICREX-F series PLC with SX series PLC.

* In addition to the above manuals, the following Fuji Electric Co.,Ltd.site offers various manuals and technical documents associated with MICREX-SX series.

URL <http://www.fujielectric.com>

Notes

1. This manual may not be reproduced in whole or part in any form without prior written approval by the manufacturer.
2. The contents of this manual (including specifications) are subject to change without prior notice.
3. If you find any ambiguous or incorrect descriptions in this manual, please write them down (along with the manual No. shown on the cover) and contact FUJI.

* Microsoft and Windows are registered trademarks or trademarks of Microsoft Corporation of the U.S.A.

* Pentium is a registered trademark or trademark of Intel Corporation of the U.S.A.

Safety Precautions

Be sure to read the “Safety Precautions” thoroughly before using the module.

**Caution**

: Incorrect handling of the device may result in minor injury or physical damage.

Even some items indicated by “Caution” may result in a serious accident.

These safety instructions provide important information. Be sure to strictly observe them.

The items to be cared most are shown below:

**Caution**

- Do not use parts which are found to be damaged or distorted when unpacking the unit because use of such parts may cause failure or malfunction.
- Do not apply shock to the product by dropping or falling, etc. because to do so may cause damage to or failure of the product.
- Do not bring a floppy disk close to magnetized objects because magnetism may cause failure.
- The product CD is a CD-ROM. Never reproduce it using a audio CD player.
Large sound volume may cause damage to the ear or audio equipment.
- Perform disk check periodically. Use of damaged floppy disk or hard disk may cause failure or malfunction of created data and system.
- Be sure to attach and lock certainly the connector of the loader cable because failure to do so may cause malfunction.
- Do not get dust at connectors because dust may cause malfunction or failure.
- Insert the CD-ROM, loader connector, etc. into the right direction because failure to do so may cause malfunction or failure.
- Fully check safety before modifying the program during operation, performing forced output, activating or deactivating the equipment, or performing other operations because failure to do so may cause mis-operation resulting in damage to the equipment or accident.
- Do not turn off the power during loader operation (during access to hard disk or floppy disk, during communication with the PLC) because to do so may cause loss of data, failure or malfunction of the product, damage to the equipment, or accident.
- Use the equipment in a software operation environment described in the manual because failure to do so may cause failure or malfunction.
- Upgrade the software according to descriptions in the manual.
- When unplugging the loader cable or power cable, do not hold the cord because to do so may cause failure or malfunction.
- Operate the loader in a stable place where there is no risk of dropping because failure to do so may cause accident.
- When discarding this product, handle it as industrial waste.

Revision

* The manual No. is printed at the bottom right of the cover of this manual.

Printed on	* Manual No.	Revision contents
Sep. 2009	FEH598	First edition
May. 2016	FEH598b	Widely revised reflecting the contents of the product version V3.0.13.* (The suffix "b" is added to the manual No. in accordance with the Japanese version.)

Contents

Preface

Safety Precautions

Revision

Contents

Section 1 Overview

1-1 Special Notes	1-1
1-2 Basic Connection Configuration	1-3
1-2-1 Connecting to SPH Series	1-3
1-2-2 Connecting to SPB Series.....	1-4
1-3 Installation	1-5
1-3-1 Personal computer operating environment required for Standard loader	1-5
1-3-2 Installation.....	1-6
1-4 Difference between old and new versions	1-8
1-4-1 Difference of file's compatibility between old and new versions	1-8
1-4-2 Main difference of function between old and new versions.....	1-10
1-5 Configuration of Loader Screen	1-11
1-5-1 Screen configuration elements.....	1-11
1-5-2 Changing screen layout	1-12
1-5-3 Auto-slide function.....	1-18

Section 2 Menu Reference

2-1 File Menu	2-1
2-1-1 File Menu - New project	2-2
2-1-2 File Menu - Based on an existing project	2-3
2-1-3 File Menu - Open	2-4
2-1-4 File Menu - Close.....	2-5
2-1-5 File Menu - Save	2-6
2-1-6 File Menu - Save As	2-7
2-1-7 File Menu - Page Setup	2-8
2-1-8 File Menu - Print.....	2-8
2-1-9 File Menu - Print preview	2-8
2-1-10 File Menu - Recent Project	2-9
2-1-11 File Menu - Create Short Cut.....	2-10
2-1-12 File Menu - Exit.....	2-10
2-2 Edit Menu	2-11
2-2-1 Edit Menu - Undo / Redo.....	2-12
2-2-2 Edit Menu - Cut / Copy / Paste.....	2-13
2-2-3 Edit Menu - Find.....	2-14
2-2-4 Edit Menu - Replace.....	2-17
2-2-5 Edit Menu - Go to - Go to Line / Go to Section	2-18
2-2-6 Edit Menu - Insert Row / Delete Row, Insert Column / Delete Column.....	2-19
2-2-7 Edit Menu - Insert Returning	2-19
2-2-8 Edit Menu - Line Comment	2-20
2-2-9 Edit Menu - Instruction List.....	2-21
2-2-10 Edit Menu - Multi operation input wizard.....	2-22
2-2-11 Edit Menu - Copy to ladder library, Paste from ladder library	2-23
2-2-12 Edit Menu - Book marks.....	2-26
2-2-14 Edit Menu - Align.....	2-28
2-2-15 Edit Menu - Split Program.....	2-28
2-3 View Menu	2-29
2-3-1 View Menu - Status Bar / Tool Bar	2-30
2-3-2 View Menu - Project View / Instruction Jog	2-31

Contents

2-3-3	View Menu - Find Result / Cross Reference Window / Message Window / Paste Result	2-32
2-3-4	View Menu - Tag Rows / Address Rows / Monitor Data Rows	2-35
2-3-5	View Menu - Default/ Integer/ Hexadecimal.....	2-36
2-3-6	View Menu - Program No.....	2-37
2-3-7	View Menu - Sort Program.....	2-38
2-3-8	View Menu - Zoom.....	2-39
2-3-9	View Menu - Display Tag / Display Description.....	2-40
2-3-10	View Menu - Display Grid Lines.....	2-40
2-3-11	View Menu - Synchronize zoom rate	2-40
2-4	Project Menu.....	2-41
2-4-1	Project Menu - Local Device Setting	2-42
2-4-2	Project Menu - Model Change	2-43
2-4-3	Project Menu - Security - Protection Programs.....	2-44
2-4-4	Project Menu - Security - Read Only.....	2-46
2-4-5	Project Menu - Verify.....	2-48
2-4-6	Project Menu - Import.....	2-54
2-4-7	Project Menu - Export	2-65
2-4-8	Project Menu - Cross Reference.....	2-72
2-5	Online Menu.....	2-73
2-5-1	Online Menu - Communication Setting	2-74
2-5-2	Online menu - Simulation mode.....	2-84
2-5-3	Online menu - PLC Operation (Run/Stop, Load)	2-85
2-5-3-1	PLC operation buttons.....	2-85
2-5-3-2	Failure Diagnosis button.....	2-96
2-5-4	Online - Monitor.....	2-109
2-5-5	Online menu- Load the changed program into PLC.....	2-110
2-5-6	Online menu - Data modify	2-111
2-5-7	Online- Break Point.....	2-114
2-5-8	Online - condition monitor	2-123
2-5-9	Online - Sampling Trace	2-130
2-5-10	Online - Program Operation.....	2-148
2-5-11	Online - Task execution time measurement.....	2-149
2-5-12	Online - Data monitor.....	2-150
2-6	Conversion menu	2-152
2-6-1	Conversion menu - Conversion / Conversion All.....	2-153
2-6-2	Conversion menu - ST Syntax Check.....	2-154
2-6-3	Conversion menu - Program Check.....	2-154
2-7	Tools menu	2-155
2-7-1	Tools menu – User ROM Utility.....	2-156
2-7-2	Tools menu - Address Assignment.....	2-170
2-7-3	Tools menu - SX Control Utility	2-171
2-7-4	Tool Menu- Shortcut key	2-172
2-7-5	Tool Menu- Customize Instruction Jog.....	2-177
2-7-6	Tools - Option.....	2-180
2-8	Window menu	2-188
2-9	Help menu	2-189

Section 3 System Definition

3-1	System Definition of SPH Series	3-1
3-1-1	Registering Modules	3-1
3-1-2	CPU Parameter Setting.....	3-8
3-1-3	System Property.....	3-20
3-1-4	Address inversion setting.....	3-27
3-1-5	Bus tact Time check function	3-31
3-2	System Definition of SPB Series	3-32
3-2-1	Registering Units.....	3-32
3-2-2	Basic unit parameter setting.....	3-35

Contents

Section 4 Print

4-1 Page Setup.....	4-1
4-2 Print.....	4-2
4-3 Print Preview.....	4-9
4-4 Circuit Print.....	4-10

Appendix 1 SX Control Utility

Appendix 1-1 Starting SX Control Utility.....	App.1-1
Appendix 1-2 SX Control Utility Window.....	App.1-3
Appendix 1-3 SX Control Utility Operations.....	App.1-4
Appendix 1-4 CPU Memory Backup.....	App.1-7

Appendix 2 System Software Utility

Appendix 3 Simulator Function

Appendix 3-1 Specifications of Simulation Function.....	App.3-1
Appendix 3-1-1 Screen configuration at simulation.....	App.3-1
Appendix 3-1-2 Specifications of simulation function.....	App.3-2
Appendix 3-1-3 Details of instruction operation restrictions.....	App.3-3
Appendix 3-2 Simulation Procedure.....	App.3-4
Appendix 3-2-1 Basic simulation procedure.....	App.3-4
Appendix 3-2-2 Using simulation panel.....	App.3-7
Appendix 3-2-3 Using auto feedback (AFB).....	App.3-18

Appendix 4 Arrays/ Structures

Appendix 4-1 Specification of Arrays/Structures.....	App.4-2
Appendix 4-2 Definition of Arrays/ Structures.....	App.4-3
Appendix 4-2-1 Array definition.....	App.4-3
Appendix 4-2-2 Structure definition.....	App.4-4
Appendix 4-3 Array/Structure Declaration.....	App.4-5
Appendix 4-4 Array/Structure Expression on Programs.....	App.4-6
Appendix 4-5 Importing Array/Structure Definition.....	App.4-7
Appendix 4-6 Array/Structure Number.....	App.4-9

Appendix 5 Password Function

Appendix 5-1 Standard password.....	App.5-3
Appendix 5-1-1 Registering password.....	App.5-3
Appendix 5-1-2 Password authentication.....	App.5-4
Appendix 5-1-3 Changing password.....	App.5-6
Appendix 5-1-4 Clearing password.....	App.5-8
Appendix 5-2 3-level Access Restriction Function.....	App.5-10
Appendix 5-2-1 Overview.....	App.5-10
Appendix 5-2-2 Specifications of 3-level Access Restriction Function.....	App.5-11
Appendix 5-2-3 Operation procedure.....	App.5-13
Appendix 5-2-3-1 Registering password.....	App.5-13
Appendix 5-2-3-2 Password authentication.....	App.5-15
Appendix 5-2-3-3 Changing password.....	App.5-17
Appendix 5-2-3-4 Clearing password.....	App.5-19
Appendix 5-2-4 Changing access restriction setting.....	App.5-21
Appendix 5-3 Notes on Use.....	App.5-26

Contents

Appendix 6 How to Use ST Language

Appendix 6-1 Overview of ST Language	App.6-1
Appendix 6-1-1 ST operators.....	App.6-1
Appendix 6-1-2 ST statements	App.6-1
Appendix 6-1-3 Basic description specifications	App.6-2
Appendix 6-2 How to Use Control Statements	App.6-4
Appendix 6-2-1 Condition statements	App.6-4
Appendix 6-2-2 Iteration control statements	App.6-7
Appendix 6-2-3 RETURN statement	App.6-8
Appendix 6-2-4 Nesting structure of control statements.....	App.6-9
Appendix 6-3 Operations of ST Language Editor	App.6-10
Appendix 6-3-1 Basic operations.....	App.6-10
Appendix 6-3-2 Applied operations	App.6-13
Appendix 6-3-3 Restrictions on program creation in ST language	App.6-16

Appendix 7 Alternative Proposal

<MICREX-F series alternative proposal>	App.7-2
<FLEX-PC series alternative proposal>	App.7-16

Appendix 8 Project View

Appendix 8-1 Resource	App.8-2
Appendix 8-2 Device	App.8-5
Appendix 8-3 Unassigned Programs	App.8-11
Appendix 8-4 Function Blocks	App.8-12
Appendix 8-5 Simulation	App.8-12
Appendix 8-6 Array/Structure	App.8-12
Appendix 8-7 File Defines	App.8-12

Appendix 9 USB Driver Installation


Appendix 9-1 Offline Installation	App.9-1
Appendix 9-2 Online Installation	App.9-4
Appendix 9-3 When USB Communication Fails	App.9-9

Section 1 Overview

1-1 Special Notes


(1) There is no compatibility with SX-Programmer Expert (D300win).

Projects created by SX-Programmer Expert (D300win) can be read neither by SX-Programmer Standard (this loader) nor from the MICREX-SX main unit. When online connection to SX_CPU created by D300win is made, an error message appears.




(2) Cautions in creating, changing or loading a project

In the MICREX-SX series, a PLC program created by a user is called a "project." A project consists of "system definition" and "program (user application)" as shown in the figure below.



In the system definition, modules and the memory size of the CPU are registered, which are closely related to addresses that are used in the program. When downloading a project, the program must match the system definition. Therefore, when downloading a new project to the PLC, be sure to download the program and system definition at the same time and reset the system.



Section 1 Overview

<Steps to follow in changing a project>

Operation	Step to follow
Changing both system definition and program	Download both the system definition and program, and reset the PLC system.
Changing system definition only	Download both the system definition and program, and reset the PLC system.
Changing program only	Download the program, and start the PLC system.

Note: Changing “no equipment” setting of a module in the module registration is also regarded as a change of system definition.

(3) Cautions in uploading a program that includes an expansion FB


When uploading a program that includes an expansion FB provided by Fuji Electric (FBs beginning with “_” such as _C_free and _MHCNTR), you need to download the expansion FBs to the computer that is used for upload in advance.

You can install the standard expansion FBs using the installation CD of Standard. Or alternatively, you can obtain the data for installation from Fuji Electric website (Fe Library).

If a program includes an expansion FB, the following dialog box appears. Click the [Yes] button to import the expansion FB.



If no expansion FBs have been downloaded in the computer, the following message appears.




In this case, the program can be uploaded, however, the expansion FB has no contents. If you execute [Conversion] menu > [Conversion All]. an error occurs. Click [Project] menu > [Import] > [Program] to import the expansion FBs manually. For CSV interface FB and PID FB in which a structure is used, you also need to import structure definition. Click [Project] menu > [Import] > [Array/Structure] to import array definition.

Section 1 Overview

1-2 Basic Connection Configuration




You can use a computer as a program loader for MICREX-SX Series by installing this software in it.

1-2-1 Connecting to SPH Series



Section 1 Overview

1-2-2 Connecting to SPB Series



MICREX-SX SPB series / Board controller

Note: To use the SPB in SX-mode, the software version of the SPB must be V**. 10 or later.

Section 1 Overview

1-3 Installation

1-3-1 Personal computer operating environment required for Standard loader

Item	Specification
Personal computer	IBM-AT compatible equipment
CPU	Intel Pentium III 800MHz or higher (2GHz or more is recommended.)
Hard disk	200 MB or more
CD-ROM drive	Required at the time of installation (quadruple speed or more is recommended.)
Memory capacity	512MB or more (1GB or more is recommend.)
Mouse	At least one of USB mouse, serial mouse, bus mouse, and PS2 mouse is supported.
Keyboard	106 keyboard
Display	Resolution: 1024 x 768 dots or more
Operating system (Note 1)	Any of the following Microsoft Windows -Microsoft Windows 2000 -Microsoft Windows XP (32 bits) -Microsoft Windows Vista (32 bits) -Microsoft Windows 7 (32 bits): Supported by V3.0.3.34 -Microsoft Windows 7 (64 bits): Supported by V3.0.4.10 -Microsoft Windows 8 (64 bits): Supported by V3.0.9.10
Other software (Note 2)	Microsoft Internet Explorer version 5.01 or later Microsoft.NET Framework2.0 runtime library Microsoft.NET Framework English Language pack 2.0 Adobe Reader

Note 1: Update the OS to the latest version (adjustment of Service Pack etc.)

Note 2: .NET Framework is necessary to use the "failure analysis" function.

It is contained in the product CD-ROM.

For Windows 8, ".NET Framework3.5" is also necessary. Download and install it from the following Microsoft website.

<https://msdn.microsoft.com/en-US/aa496123>

Note 3: With Windows XP/Vista/7/8, users who have no administrator's privilege can not access any folder that requires administrator's privilege. When multiple users may use the same computer, Standard loader should be installed in a folder that can be read, written or deleted by any account other than administrator's privilege.

Note 4: With Windows 8, the touch monitor cannot be used. Use a mouse.

Section 1 Overview

1-3-2 Installation

Standard loader is provided in a CD-ROM that includes the installation program. When you insert the CD-ROM into the CD-ROM drive with the personal computer turned ON, the following screen appears automatically.

<Notes on installation>

Note 1: If [.NET Framework2.0] has not been installed in the destination personal computer, [.NET Framework2.0] is automatically installed.

It takes a few minutes or sometimes more than ten minutes to install [.NET Framework2.0].

(The time required for installation depends on the performance of the personal computer used.)

Note 2: If the installation screen does not appear after inserting the CD-ROM, click the [Start] button of Windows, select [Run], enter "x:\autorun.exe" (x indicates the drive into which the CD-ROM is inserted), and then click the [OK] button.

Note 3: If Standard V2 has already been installed and started, finish it before installation.

◆ Click "Install the English version."



Section 1 Overview

- ◆ Click “Standard V3 Setup.”



<FYI>

“FLEX-PC(Standard V2) Setup”:

Software for StandardV2 (MICREX-SX series) and FLEX-PC (NB/NJ/NS series PLC, SPB N mode)

For the details of StandardV2 loader operations, refer to the user's manual FEH590.

For the details of FLEX-PC loader operations, refer to the user's manual FEH403.

“MICREX-F PLC Programmer Setup”:

Software for MICREX-F series PLC
For the details of loader operations, refer to the user's manual FEH147.

- ◆ On the following screen, click “Standard V3” to start installation. Follow the direction that appears on the screen.



- * “Standard V3 (Monitor)” is a monitoring tool for maintenance people. This software cannot change a program.
When installing StandardV3 into Windows2000 computer, execute “Windows Installer 3.1 Setup” on the screen above before installing StandardV3.

Section 1 Overview

1-4 Difference between old and new versions

1-4-1 Difference of file's compatibility between old and new versions

This subsection explains the compatibility with the old version of standard loader (V2)
The followings are the main points.

<Offline Project>

"Offline Project" corresponds to the project files saved in computer.

- The project files created by V2 can be opened by V3.
The project files created by or saved in V3 cannot be opened by V2.
The following lists the extensions of files.

	Compressed file	Non-compressed file
V2	Zpj	Spj
V3	Zpj3	Spj3 (Note 1)

Note1: If you check "Support non compressed project file" in [Options] setting, this extension is effective.

- You can newly create a user function (FCT) in V2, however not in V3. Functions created in V2 can be opened and edited in V3. When creating a new document, substitute FBs (function blocks).

Section 1 Overview



<Online Project>

“Online Project” corresponds to project files saved in the PLC.

- A project created by V2 and transferred to the PLC can be read by V3.
- A project created by V3 and transferred to the PLC cannot be read by V2. However, if the project uses a new editing function of V3, the display on V2 is as shown below.



1) The number of condition contacts before word instructions

The number of condition contacts that can be described in a word instruction is seven on V2 and nine on V3 at the maximum. If you create a circuit that has more than seven condition contacts in a word instruction by V3 and load it to the PLC, the circuit automatically becomes a returning line when read by V2.



2) Condition contact before user FB

You can write a condition contact before a user FB in V3, however cannot in V2. If a circuit that has condition contacts before a user FB is read from PLC by V2, the circuit causes an error. The program (POU) including such a circuit cannot be transferred to the PLC by V2. Use V3.



Section 1 Overview

1-4-2 Main difference of function between old and new versions

This subsection explains the difference of the function between old and new versions of Standard loader.
The followings is the main point.

(1) The number of project files that can be opened at the same time

You can open multiple project files in the old version (V2), however, can open only one project file in the new version (V3).
When you need to open multiple files at a time, startup several pieces of loader software.


Section 1 Overview

1-5 Configuration of Loader Screen

1-5-1 Screen configuration elements

This subsection explains configuration elements of the loader screen.

The loader screen mainly consists of the main menu bar, tool bar, instruction jog bar, project view window, document window and each message windows.



Name	Function detail
Main menu bar	This bar is used to perform main operations to the loader.
Tool bar	Commands used frequently in the main menu are registered as icons.
Instruction jog bar	This bar is used to switch the instruction group and choose an instruction for the chosen group.
Project view window	This window structurally displays each constructing element of a project (system definition, program, and device).
Document window	This window is a space to display a program and a data worksheet.
Message window	This window displays messages, for example, program information, conversion error information, cross reference. You can change the arrangement by using your mouse and display multiple windows side by side.
Status bar	This bar displays messages about the type of PLC, program usage, PLC status, and other supplemental information depending on the situation.


Section 1 Overview

1-5-2 Changing screen layout

You can change the layout of document window, message window and project window following the procedure below.


(1) Displaying a program and data monitor screen on the document window at the same time.

- ◆ To display a program, double-click the program instance under the program folder in the project view.
- To display data monitor screen, click [Online] menu > [Data monitor] > [Data monitor].
- To switch the display between the program and data, click the tab that you want to display.




Section 1 Overview

- ◆ To display a program and data one above the other, click and hold down the left mouse button on the “Data monitor 1” tab. The “Docking indicator” appears. The screen is reversely displayed.




- ◆ While holding down the left mouse button, move the mouse pointer to the lower button of “Docking indicator.” The lower half of the screen is reversely displayed. (The contents of the selected tab will appear on the reversely displayed part.)




Section 1 Overview

- ◆ Release the mouse button, and the “Data monitor 1” worksheet is displayed on the lower half of the screen. (Docking display)




- * Function of each button on “Docking indicator.”



Section 1 Overview



(2) Adjusting the layout of message windows

- ◆ To display a message window, click [View] menu > [Message window], and then select an arbitrary message window. Open message windows are displayed as a list at the bottom left of the screen .



Section 1 Overview

- ◆ Click and hold down the left mouse button on an arbitrary item of the message list. The “Docking indicator” appears, and the screen is reversely displayed. The following procedure is the same as that of the screen layout change of the project view window.



Section 1 Overview



Information


Resource	Program Name	Program Type	Step	User FB	Ed
	Ladder1	Program	82 step	0	
	Ladder2	Program	61 step	0	
	Ladder1_0	Program	60 step	3	
	aaa	Function Block	26 step	0	
	bbb	Function Block	26 step	0	
	ccc	Function Block	26 step	0	
Total		Program : 3 Function : 0 Function block : 3	281 step		

Section 1 Overview


1-5-3 Auto-slide function

The auto-slide function can be set for the project window or device monitor window. If the auto-slide function is enabled, the window automatically shows and hides according to the mouse pointer position.

Put the mouse pointer here to show the hidden window.




Move the mouse pointer out of the window to hide it automatically.




Section 1 Overview

The auto-slide function is disabled by default. To enable this function, use the push-pin icon at the top left of the window as described below.




When the auto-slide function is disabled, the push-pin icon faces to the bottom. Click the push-pin icon.



The push-pin icon faces to the left. The auto-slide function is enabled. To disable, click the push-pin icon.



When the auto-slide function is enabled, if you move the mouse pointer out of the project view window and click, the window automatically hides. If you move the mouse pointer on the project view icon, the project window automatically shows.



Section 2 Menu Reference

This section explains all the functions that can be used from the main menu shown below.

- File menu ⇒ File processing commands
- Edit menu ⇒ Ladder editing functions
- View menu ⇒ Program window display mode setting functions
- Project menu ⇒ Project editing functions
- Online menu ⇒ Online functions
- Conversion menu ⇒ Program conversion and check functions
- Tools menu ⇒ Utility tools functions
- Window menu ⇒ Window display options
- Help menu ⇒ User's manual and version information

2-1 File Menu

The "File" menu contains the following commands:

- New project ⇒ Opens a new project file.
- Based on an existing project ⇒ Creates a new project based on an existing project.
- Open ⇒ Opens an existing project file.
- Close ⇒ Closes the open project.
- Save ⇒ Overwrites the open project window.
- Save As ⇒ Saves the current project with a filename.
- Page Setup ⇒ Sets up the page format for printing.
- Print ⇒ Prints the program and documentation information.
- Print Preview ⇒ Displays the print preview in the screen.
- Resent Projects ⇒ Displays the recently used project.
- Create Short Cut ⇒ Creates a shortcut to start up the loader software and open a project file at the same time.
- Exit ⇒ Exits the loader.


Section 2 Menu Reference

2-1-1 File Menu - New project


This command is used to open a new file.

- ◆ Click [File] menu > [New project]. The following dialog box opens.
To change the display mode, click the [Display switch] button, and then select “Large icon” or “Small icon” mode.

<Large icon mode>



<Small icon mode>




- ◆ Select the type of a CPU and click the [OK] button to create a new project.

Section 2 Menu Reference

2-1-2 File Menu - Based on an existing project

This command is used to create a new project based on an existing project. An existing project is opened as a new project file. (Therefore, the existing project is not affected.)

- ◆ Click [File] menu > [Based on an existing project]. The following dialog box opens.
On this dialog box, select a file type and a project file to open.
When you select a file and click the [Open] button, the project opens in offline mode.



<Type of file>

Type of file (extension)	Usage
V3 zipped Project (*.Zpj3)	V3 zipped project file.
V3 unzipped project (*.Spj3)	V3 project file, which consists of multiple files and folders. When you open a file, specify this project file. To make this type available, perform option setting.
V2 zipped Project (*.Zpj)	V2 zipped project file.
V2 unzipped project (*.Spj)	V2 project file, which consists of multiple files and folders. When you open a file, specify this project file.
SX Template (*.Sxt)	Template type for V2 project.


Section 2 Menu Reference

2-1-3 File Menu - Open

This command is used to open an existing project file.

* Only one file can be opened at the same time. To open multiple projects in a computer at the same time, start up multiple pieces of loader software and open project files in each software.

- ◆ Click [File] menu > [Open]. The following dialog box opens.
On this dialog box, select a file type and a project file to open.
When you select a file and click the [Open] button, the project opens in offline mode.



<Type of file>

Type of file (extension)	Usage
V3 zipped Project (*.Zpj3)	V3 zipped project file.
V3 unzipped project (*.Spj3)	V3 project file, which consists of multiple files and folders. When you open a file, specify this project file. To make this type available, perform option setting.
V2 zipped Project (*.Zpj)	V2 zipped project file.
V2 unzipped project (*.Spj)	V2 project file, which consists of multiple files and folders. When you open a file, specify this project file.
MICREX-F program (*.Ldx)	MICREX-F program file. If you select this file, Standard loader automatically converts the project to SX.
FLEX-PC program (*.Fxl)	FLEX-PC program file. If you select this file, Standard loader automatically converts the project to SX.
FUJILog-UK program (*.Prj)	Fujilog-uk (or uK-mini) program file. A program can be loaded from FUJILog-uK (or uK-mini) and saved as a file using "FUJILog utility" software supplied with StandardV3. If you select this file, Standard loader automatically converts the project to SX.
FLEX-PC (T type) program (*.Pma)	FLEX-PC (T type) program file. A program can be loaded from a T-type CPU and saved as a file using MS-DOS version T-type loader or "WinFN-T" loader by SINWA Electric Corporation. If you select this file, Standard loader automatically converts the project to SX.

Section 2 Menu Reference

2-1-4 File Menu - Close

This command is used to close an opened project file.

◆ Click [File] menu > [Close]. The currently opened project is closed.

Section 2 Menu Reference

2-1-5 File Menu - Save

This command is used to overwrite the contents of the currently open project.

When the project is newly created or loaded online, it has no project name. In this case, the “Save As” dialog box appears to save with a name.

(Refer to “2-1-6 File Menu - Save As.”)

Section 2 Menu Reference


2-1-6 File Menu - Save As

This command is used to save the currently open project with a name.

◆ Click [File] menu > [Save As]. The following dialog box opens.

Select a folder, enter a file name, and then click the [Save] button to save the project file.

Note: The file name can be up to 32 byte characters. Symbols ':', '.', '*', '?', '"', '<', '>', '|' cannot be used for the file name. Space characters cannot be used, either.



Section 2 Menu Reference

2-1-7 File Menu - Page Setup

This command is used to perform all settings about printing in the page setting dialog box.

2-1-8 File Menu - Print

This command is used to open the print menu dialog box.

2-1-9 File Menu - Print preview

This command is used to open print preview dialog box.


* For more details of the print function, refer to Section 4.

Section 2 Menu Reference


2-1-10 File Menu - Recent Project

This command is used to display up to 10 projects that you have most recently used since the loader software was installed. The projects are listed in the order in which they were used. When you open a project on the list, the file name is listed as the latest.

- ◆ Click [File] menu > [Recent Projects]. The recent project history is displayed as a list. Click a project from the list to open it.




- ◆ Alternatively, you can open the recent project by clicking the drop-down list beside the “open folder” icon.



Section 2 Menu Reference

2-1-11 File Menu - Create Short Cut

This command is used to create a shortcut to start up the loader software and open a project file at the same time.



<Options>

- Include the communication setting:
Creates a shortcut file that includes information on the communication setting set in the loader.
- Set the read-only attribute:
Specifies the attribute of the shortcut file as “read-only.”
- Load from PLC:
When this option is unchecked, a project in the loader is read. When checked, a program in the PLC is read.
- Destination:
Select the CPU No. of the PLC. For a single CPU system, select CPU 0. For a multi-CPU system, select a destination CPU.
- Load in Zip File:
Reads a zip file at the same time when reading a program. A zip file includes information such as tags. You can select any of the following three options.
 - Zip File: Reads a zip file in the PLC.
 - Tag Project: Reads a tag project in the PLC.
 - Project: Reads the tags that a project in the loader includes. Click the [Browse] button to select a project in the loader.

2-1-12 File Menu - Exit

This command exits the loader software.

Section 2 Menu Reference

2-2 Edit Menu

The “Edit” menu contains the following commands.

- Undo ⇨ Cancels the circuit edit operation last performed.
- Redo ⇨ Performs the canceled operation again.
- Cut ⇨ Moves a selected circuit to the clip board.
- Copy ⇨ Copies a selected circuit to the clip board.
- Paste ⇨ Pastes the circuit of the clip board in the program.
- Find ⇨ Searches for an address or a tag for the active program.
- Replace ⇨ Replaces an address with another one for the active program.
- Go to ⇨ Moves to a specified line or section number.
- Insert Row ⇨ Inserts a row above the cursor position.
- Delete Row ⇨ Deletes the row on the cursor position.
- Insert Column ⇨ Inserts a column above the cursor position.
- Delete Column ⇨ Deletes the column on the cursor position.
- Insert Returning ⇨ Inserts a return of a line.
- Line Comment ⇨ Adds or modifies a line comment.
- Instruction List ⇨ Displays the currently using mnemonics.
- Multi operation input wizard ⇨ Used for multiple numeric data operation in ST language.
- Split Program ⇨ Splits a program into two programs.
- Open Device Editor ⇨ Opens the screen to edit tags of the memory devices such as M, L, X, and Y in a batch and check the use status of the devices. You can also open this screen by double-clicking the “Device” icon in the project view.
For more details, refer to “Appendix 8-2 Device.”
- Copy to ladder library ⇨ Saves a part of the program as a library.
- Paste from ladder library ⇨ Opens and pastes a library program on the currently created program.
- Book marks ⇨ Sets book marks on the program.
- Grid ⇨ Sets the grid line on the simulation panel.
- Align ⇨ Aligns multiple items on the simulation panel.

Section 2 Menu Reference

2-2-1 Edit Menu - Undo / Redo

(1) Undo

This command is used to cancel the editing operation performed last.

- ◆ Click [Edit] menu > [Undo]. The system is restored to the status that took effect just before the last editing operation. Alternatively you can execute this function with the [Undo] button on the main tool bar or pressing the <Ctrl> + <Z> keys.

(2) Redo

This command has the opposite function of the [Undo] command in [Edit] menu.

- ◆ Click [Edit] menu > [Redo]. The system is restored to the status that took effect just before the last editing operation. Alternatively you can execute this function with the [Redo] button on the main tool bar or pressing the <Ctrl> + <Y> keys.

* The operation history is deleted when you close the project file or change the PLC model.


Section 2 Menu Reference

2-2-2 Edit Menu - Cut / Copy / Paste

These commands are used to perform “cut,” “copy,” and “paste” operations in units of programs (instances) or circuits.


<“Cut” or “Copy” of a program>

- ◆ Select a program instance in the project view, and then click [Edit] menu > [Cut] or [Copy].
Alternatively, you can execute “cut” or “copy” with the right-click menu or the following shortcut keys, <Ctrl> + <X> for cut and <Ctrl> + <C> for copy.



<“Paste” of a program>

- ◆ Select a program instance in the project view, and then click [Edit] menu > [Paste].
Alternatively, you can execute “paste” with the right-click menu or the shortcut key, <Ctrl> + <X>.



* For more details of “Cut,” “Copy,” and “Paste” of a circuit, refer to FEH597 “2-4-2 Cutting, copying, and pasting a circuit.”


Section 2 Menu Reference

2-2-3 Edit Menu - Find


(1) Find - Find / Find Output Device / Next in the Find command

These commands are used to search for a specified address or tag for the active program.

- ◆ Click [Edit] menu > [Find] > [Find].

Alternatively, you can execute this function with the shortcut key, <Ctrl> + <F> or the "Find button" icon .

The "Find Device" dialog box opens.




<Options>


- Find what:
Enter an address or a tag name to find. If you execute the "Find" command while selecting a contact or a coil, the address is automatically entered. You can search for an address by specifying the range such as "M0-M10."
To search for a page by SECTION instruction, enter Nxxx (xxx = section No.)
- Look in:
Choose "Active Program" or "All Programs."
"Active Program": Searches the currently open program.
"All Programs": Searches all programs.
- Origin:
Choose "Entire Scope" or "From Cursor. This option is enabled when "Active Program" is selected for "Look in."
"Entire Scope": Searches from the top of the currently open program
"From Cursor": Searches from the current position.
- Search up:
Scrolls up from the current cursor position to search. When this option is unchecked, it scrolls down to search.
This option is enabled when "Active Program" is selected for "Look in."
- Find the overlapped device in bit/ word:
The scope of search includes the bit/ word/double-word devices that has the specified address.
For example, when you enter M0 (bit) in the "Find what" box, the scope of search includes WM0 (word), DM0 (double word) including M0.
When you enter WM0 (word) in the "Find what" box, the scope of search includes M0 to MF (bit), DM0 (double word).
- Find the area of block transfer instructions:
The scope of search includes data with many words such as the area of block transfer instructions.
This option can be enabled only when word/ double word is entered in the "Find what" box.
- Find output device:
The scope of search is only the devices used as an output instruction (coil or forwarding destination of transfer instruction).
- Report find result window:
This option is enabled when "All Programs" is selected for "Look in." When the search is complete, the "Find Result" window opens on the lower side of the screen.
If "Clear Previous Report" is checked, the previous search results are cleared and only the latest result is displayed.

Section 2 Menu Reference

- ◆ When the entered address is found, the line is displayed by scrolling it to the top of the program window. The “Find Device” dialog box is automatically folded and moved to outside of the project view window.



Click the [Find] button to search the next address.



Click this button to display the “Find Device” dialog box in detail.

- ◆ [Edit] menu > [Find] > [Find Output Device] command is used to search only output devices. The same operation is performed when you execute [Edit] menu > [Find] > [Find] and select “Find Output Device.”
- ◆ [Edit] menu > [Find] > [Next] command is used to search the next address after executing the “Find” command.

Section 2 Menu Reference

(2) Find - Find Instruction


This command is used to search for a specified instruction.

- ◆ Click [Edit] menu > [Find] > [Find Instruction].


The “Find Instruction” dialog box opens.

Enter an instruction in the “Find what” box or select an instruction from “Assortment” and “Instruction List,” and click the [Find] button.

If “Clear Previous Report” is checked, the previous search results are cleared and only the latest result is displayed.



- ◆ When the search is complete, the “Find Result” message window appears.




Section 2 Menu Reference

2-2-4 Edit Menu - Replace

This command is used to replace an address.

- ◆ Click [Edit] menu > [Replace]. The “Replace Device” dialog box opens.



<Options>

- Find what:
Enter an address or a tag name to replace. If you execute the “Replace” command while selecting a contact or a coil, the address is automatically entered. You can search for an address by specifying the range such as “M0-M10.”
- Replace:
Enter an address with which the found address is replaced. If you specify the range, only the starting address is specified here.
- Look in:
Choose “Active program” or “All Program.”
“Active Program”: Searches in the currently open program.
“All Programs”: Searches in whole program.
- Origin:
Choose “Entire Scope” or “From Cursor.”
“Entire Scope”: Replaces from the top of the program in the currently open program.
“From Cursor”: Replaces from the current cursor position.
- Search up:
Scrolls up from the current cursor position to replace. If this option is unchecked, it scrolls down to replace.
This option is enabled when “Active Program” is selected for “Look in.”
- Find the internal bit/ word address:
When you specify a word/double-word address as a replacement device, the scope of replacement includes bit/ word devices including the word/double-word device.
For example, when you enter WM0 (word) in the [Find what] dialog box, the scope of replacement includes M0 to MF.
When you enter DM0 (double word) in the “Find what” dialog box, the scope of replacement includes M0 to M1F (bit), WM0 to WM1 (word).
- Replace with tag:
When the address is replaced, the tag is also replaced at the same time.
- Change NO/NC contacts:
Switches NO and NC of the specified address.

<Buttons>

- Find:
This button is used to replace with confirming the corresponding address to replace one-by-one. Click this button to search for the corresponding address to replace. Also when you do not replace the found address and move to the next, click this button.
- Replace:
When you click this button while the cursor is put on the found address, the replacement is executed.
- Close:
This button closes the dialog box.
- Replace All:
This button replaces the addresses in a batch. This button is enabled only when the scope of search is “Active Program.”



Section 2 Menu Reference

2-2-5 Edit Menu - Go to - Go to Line / Go to Section

These commands are used to jump the cursor to a specified line or section instruction in a currently active program.

- ◆ Click [Edit] menu > [Go to Line].

The following dialog box opens. Enter a line number, and then click the [OK] button. The cursor jumps to the specified line.



Section 2 Menu Reference

2-2-6 Edit Menu - Insert Row / Delete Row, Insert Column / Delete Column

Insert Row ⇨ This command is used to insert a row in a circuit.

Delete Row ⇨ This command is used to delete a row in a circuit.

Insert Column ⇨ This command is used to insert a column in a circuit.

Delete Column ⇨ This command is used to delete a column in a circuit.

For more details, refer to FEH597 “2-4-3 Inserting and deleting a row” and “2-4-4 Inserting and deleting a column.”

2-2-7 Edit Menu - Insert Returning

This command is used to create a returning line when 12 or more contacts are connected in series in a row.




For more details, refer to FEH597 “2-4-5 Inserting a return.”

Section 2 Menu Reference

2-2-8 Edit Menu - Line Comment

This command is used to put a comment on each line.

- ◆ Put the cursor on a line, and then click [Edit] menu > [Line Comment]. The “Line Comment Editor” dialog box opens. Enter a comment, and then click the [OK] button. The line comment is inserted above the cursor. Up to 32767 comment lines can be inserted.





- * To edit a comment line, double-click the comment line to open the “Line Comment Editor” dialog box. To delete a comment line, put the cursor on the comment line, and then click [Edit] menu > [Delete Row].

Section 2 Menu Reference

2-2-9 Edit Menu - Instruction List

This command is used to display a circuit of the cursor position in the instruction list.

- ◆ Put the cursor on a circuit to display in the instruction list, and then click [Edit] menu > [Instruction list].
The Instruction list for the circuit appears.



- * You can edit the program in Instruction list mode.
- * In Instruction list mode, instructions and operands constituting the ladder circuit are listed. The tag is not displayed.
- * To change the instruction code or operand, move the cursor and directly change it.
- * To enter an instruction, directly enter an instruction name.

- ◆ Edit the program and click the [OK] button, or [Cancel] button to close the dialog box and return to the normal ladder display.

Note: If you change the circuit so that it cannot be displayed by Ladder, an error message appears.

Section 2 Menu Reference

2-2-10 Edit Menu - Multi operation input wizard

This command is used for multiple numeric data operation in ST language.
For more details, refer to Appendix 6-3-2.

Section 2 Menu Reference



2-2-11 Edit Menu - Copy to ladder library, Paste from ladder library

These commands are used to save the selected circuit as a library in a file, and paste it from the file to a program.

(1) Copy to ladder library

This command is used to save the selected circuit as a library in a file.


- ◆ Select a circuit to register in the library. To select the circuit, put the cursor on the starting position (the top left) and scroll down the project window. Then, while pressing the <Shift> key, click on the ending position. The circuit selected and reversely displayed.



Section 2 Menu Reference

- ◆ Click [Edit] menu > [Copy to ladder library].

The “Copy to Ladder Library” dialog box opens. Enter a file name, and then click the [Save] button.





Section 2 Menu Reference


(2) Paste from ladder library

This command is used to open a library file and paste it in a program.

- ◆ Put the cursor on the program, and then click [Edit] menu > [Paste from ladder library].
The “Paste from Ladder Library” dialog box opens. Select a file name, and then click the [Open] button.



- ◆ The circuit is pasted.




Section 2 Menu Reference

2-2-12 Edit Menu - Book marks

This command is used to set a book mark on a circuit of the cursor position. After setting a book mark, you can search for the book marked circuit or show only the book marked circuit (Ladder filter function). The book mark is effective until the program is closed.

(1) Book marks - Toggle book mark

This command is used to set a book mark on a circuit of the cursor position. If a book mark is already set, the book mark is deleted.



(2) Book marks - Previous book mark / Next book mark

- Previous book mark:
Moves to a book mark that is set above the cursor. If there is no book mark above the cursor, a book mark is searched from the bottom.
- Next book mark:
Moves to a book mark that is set below the cursor. If there is no book mark below the cursor, a book mark is searched from the top.

(3) Book marks - Clear book marks

This command is used to clear all the book marks in the active program.

(4) Book marks - Filter

This command is used to display only a book marked circuit.

Section 2 Menu Reference

2-2-13 Edit Menu - Grid

This command is effective only with the simulation panel and used to change Grid show/hide and set the Grid width.



<Options>

- Show grid:
Check this option to show the grid . Uncheck to hide.
- Snap to grid:
Check this option to adjust parts such as a switches and lamps on the simulation panel to the grid. If you move or resize parts while this option is checked, they are automatically adjusted to the grid.
- Grid setting:
Set the grid size by dot.

Section 2 Menu Reference

2-2-14 Edit Menu - Align

This command is effective only with the simulation panel and used to align multiple parts such as switches and lamps that are arranged on it.

<Options>

- Left: All selected parts are aligned to the left.
- Center: All selected parts are aligned to the center.
- Right: All selected parts are aligned to the right.

- Top : All selected parts are aligned to the top.
- Middle: All selected parts are aligned to the middle.
- Bottom: All selected parts are aligned to the bottom.

2-2-15 Edit Menu - Split Program

This command is used to split a program (POU) into two programs. Use this command when the size of the program exceeds the maximum capacity of one POU. This function is only for the ladder language.

When you execute this command on an arbitrary position in a program, the line of the cursor position and the following lines are cut and another program is newly created.

Section 2 Menu Reference

2-3 View Menu

The View menu contains the following commands:

- Status Bar ⇨ Switches the display of the status bar ON/OFF.
- Tool Bar ⇨ Switches the display of the tool bar ON/OFF.

- Project View ⇨ Displays the project view window.
- Instruction Jog ⇨ Displays the instruction jog bar.
- Find Result ⇨ Displays the find result.
- Cross Reference Window ⇨ Displays the cross reference window.
- Message Window (Output/Error/Information) ⇨ Displays the message window.
- Paste result ⇨ Displays the result of program conversion.

- Tag Rows ⇨ Sets tag rows to display.
- Address Rows ⇨ Sets address rows to display.
- Monitor Data Rows ⇨ Sets monitor rows to display.

- Display Tag / Display Description ⇨ Switches between tag display and description display on a program

- Default ⇨ Displays default of monitor data.
- Integer ⇨ Displays monitor data in integer.
- Hexadecimal ⇨ Displays monitor data in hexadecimal.

- Display Grid Lines ⇨ Shows or hides the grid lines on a ladder circuit.

- Program No ⇨ Shows or hides program Nos. the project view window.
- Sort Program ⇨ Arranges the display order of the programs in the “Unassigned Programs” and the “Function Blocks.” The “Unassigned Programs” and the “Function Blocks” are on the project view window. The display order in “Program” is not changed.


- Zoom ⇨ Changes the zoom setting of displayed lines.
- Synchronize zoom rate ⇨ Changes the zoom rates of multiple ladder circuits that are simultaneously opened in synchronization.

Section 2 Menu Reference

2-3-1 View Menu - Status Bar / Tool Bar

These commands are used to show or hide the “Status Bar” and the “Tool Bar.”

- ◆ To show or hide each item,
click [View] > [Status bar] or
click [View] > Tool Bar > [Standard], [Online], [Window], [Break point], [Condition monitor], or [Sampling trace].




Section 2 Menu Reference

2-3-2 View Menu - Project View / Instruction Jog

The Project View and the Instruction Jog are displayed by default. These commands are used when you close the displays and want to reopen them.

- ◆ To display each item,
click [View] menu > [Project View] or
click [View] menu > [Instruction Jog].



Section 2 Menu Reference

2-3-3 View Menu -


Find Result / Cross Reference Window / Message Window / Paste Result

These windows are automatically opened when the operation is done such as a search or cross reference creation. These commands are used when you close the displays and want to reopen them.

- ◆ To display each item,
 - click [View] menu > [Find Result],
 - click [View] menu > [Cross Reference Window],
 - click [View] menu > [Message Window] and [Output],
 - click [View] menu > [Message Window] and [Error],
 - click [View] menu > [Message Window] and [Information], or
 - click [View] menu > [Paste Result].


(1) Find Result

This command is used to display the find result of "Find Instructions" and "Find Address" (when the scope of search is "All Programs").



(2) Cross Reference Window


This command is used to display the result of the cross reference creation.



Section 2 Menu Reference


(3) Output

This command is used to display the result of the program conversion.




(4) Error

This command is used to display the error list if there is an error after program conversion.



(5) Information

This command is used to display the result of the program conversion and the list of information such as the number of program steps and the number of timers/counters being used.



Section 2 Menu Reference

(6) Paste result

This command is used to display the result of pasting a MICREX-F or FLEX-PC program using the conversion function.

Section 2 Menu Reference

2-3-4 View Menu - Tag Rows / Address Rows / Monitor Data Rows

These commands are used to change the number of rows of tags (or Descriptions), addresses, and monitor data.


- ◆ To change the number of rows of each item, execute any of the following procedures.
 - Click [View] menu > [Tag Rows] > Hide, 1 Row, 2 Rows, 3 Rows or 4 Rows.
 - Click [View] menu > [Address Rows] > 1 Row, 2 Rows, 3 Rows, 4 Rows or 5 Rows.
 - Click [View] menu > [Monitor Data Rows] > 1 Row, 2 Rows, or 3 Rows.

* For a Tag (or Description), up to 8 characters can be displayed per row. The characters exceeding the specified number of rows are not displayed.


* For Monitor data, up to 8 digits can be displayed per row.

To monitor data exceeding 8 digits, select 2 Rows or 3 Rows for "Monitor Data Rows." If data exceeding 8 digits is displayed in a row, the last decimal is displayed as "~."

<Example of one-row display>



<Example of two-row display>



Section 2 Menu Reference

2-3-5 View Menu - Default/ Integer/ Hexadecimal


These commands are used to change the representation of monitor data.

- Default ⇒ Represents monitor data in a specified format by the operand automatically.
For example, multiply instructions has the following three types.
 - MUL: Integer format (with sign) [INT] / double-precision integer (with sign) [DINT]
 - MUL_UAI: Integer format (without sign) [UINT] / double-precision integer (without sign) [UDINT]
 - MUL_R: Integer format (double-precision floating-point format) [REAL]When you use MUL or MUL_UAI, monitor data is represented in an integer number.
When you use MYL_R, monitor data is represented in a double-precision floating-point number.
- Integer ⇒ Represents monitor data in a signed decimal number independently of the data format of the operand.
- Hexadecimal ⇒ Represents monitor data in a hexadecimal number independently of the data format of the operand.

Section 2 Menu Reference

2-3-6 View Menu - Program No.

This command is used to show or hide program Nos. in the project view window.



Section 2 Menu Reference

2-3-7 View Menu - Sort Program

This command is used to change the display order of the programs in “Unassigned Programs” and “Function Blocks” on the project view window.

Since programs in “Program” relate to the execution order (they are executed from the top), the display order is not changed.

The programs can be sorted in any of the following four orders:


- Sort by Name in Ascending Order ⇒ Arranges alphabetically by program name in ascending order.
The order is number (1,2,3...) and alphabet (a to z).
- Sort by Name in Descending Order ⇒ Arranges alphabetically by program name in descending order.
- Sort by Number in Ascending Order ⇒ Arranges by program No. in ascending order.
- Sort by Number in Descending Order ⇒ Arranges by program No. in descending order.

Section 2 Menu Reference

2-3-8 View Menu - Zoom

This command is used to change zoom rate of the active window.

◆ Click [Edit] menu > [Zoom]. The following dialog box opens. Select a zoom rate, and then click the [OK] button.



* To specify the zoom rate, select "Customize", and then enter a zoom value in the text box. Range: 10 to 400%.
If you select "Auto," the display is automatically adjusted to window size.

Section 2 Menu Reference

2-3-9 View Menu - Display Tag / Display Description

These commands are used to show or hide tags and descriptions on a program. The tags and descriptions cannot be displayed at the same time.

If you select [View] > [Tag Rows] > [Hide], neither tags nor descriptions are displayed.

2-3-10 View Menu - Display Grid Lines

This command is used to select whether or not to display the grid lines (borders of cells) on a ladder program.

2-3-11 View Menu - Synchronize zoom rate

When multiple ladder programs (or multiple ST ladder programs or data monitor screens) are simultaneously opened, the zoom rates can be changed in synchronization.

Section 2 Menu Reference

2-4 Project Menu

The “Project” menu contains the following commands:


- Local Device Setting ⇒ Sets a device only effective for specific programs.
- Model Change ⇒ Changes settings of the PLC type.
- Security ⇒ Sets a password to protect contents and sets read only.
- Verify ⇒ Verifies the program displayed on the PLC or loader and the project saved as a file in the computer.
- Import ⇒ Reads the project information (such as a program, tag, line comment, system definition) saved as a file by the “Export” command.
- Export ⇒ Saves an open project information (such as a program, tag, line comment, system definition) as a file.
- Cross Reference ⇒ Creates a cross reference.

Section 2 Menu Reference



2-4-1 Project Menu - Local Device Setting

This command is used to set a device only effective for specific programs.

- ◆ Click [Project] menu > [Local Device Setting]. All programs in the project are displayed. Select a program to be specified as a local device setting and click the [Edit] button.



- ◆ The “Modify” dialog box opens. To set the range of the local device, set “Start Address” and “Data Size.”




* The non-retain memory and retain memory can be specified as a local device. The range starting from the Start Address to the address determined by Local Area (the number of words) can be specified as a local device for the currently open program. Only an even number can be specified for the start address and local area.

Section 2 Menu Reference

2-4-2 Project Menu - Model Change


This command is used to change the PLC model currently assigned to the resource of the project file.

- ◆ Click [Project] menu > [Model Change]. The “Model Change” dialog box opens. Change the PLC model and PLC memory capacity, and then click the [OK] button.




(1) When “Initialize system definition” is unchecked

- ◆ The model change confirmation dialog box appears. Click the [Yes] button to change the model. After model change, the system definition screen opens. Close it, and model change is done.



(2) When “Initialize system definition” is checked

- ◆ The following dialog box appears.



- ◆ Click the [Yes] button to initialize the system definition. After initialization of the system definition, the system configuration definition screen opens. Close it, and model change is done.

* If you change the model, “Memory allocation setting” is initialized.

Section 2 Menu Reference

2-4-3 Project Menu - Security - Protection Programs

This command is used to set a password on a specific program and protect it from being opened.


If you set protection, the password is retained in the project file until you cancel it. To open the program, the correct password is required. This command can protect both project files saved in computer and transferred to the PLC.

* The program cannot be opened. However, tag names can be read or written. (Except the following devices)

T0 to T8191, TR0 to TR8191, C0 to C8191, F


<How to protect a program>

- ◆ Click [Project] menu > [Security] > [Protection Programs]. The following dialog box opens. Check the program to protect and click the [OK] button.




“All function” button is shown only when the project contains a function.

- ◆ The password entry dialog box appears. Enter a password, and then click the [OK] button.



* Set a password from 1 to 20 characters using hexadecimal numbers (0 to 9, A to F, case insensitive).

- ◆ The following dialog box appears. Click the [Yes] button to set protection. When protection is set, the project becomes unconverted. To load the project to the PLC, execute [Conversion] > [Conversion All] after setting protection.




Section 2 Menu Reference

- ◆ Password setting is complete.




You can check whether the program is protected on the project view window. The protected program is shown with a key mark and cannot be browsed or changed.




<How to release protection>


- ◆ Click [Project] menu > [Security] > [Release protection program]. The password entry dialog box opens. Enter the password and click the [OK] button.



- ◆ The following dialog box appears. Click the [Yes] button to release the protection. When protection is released, the project becomes unconverted. To load the project to the PLC, execute [Conversion] > [Conversion All] after releasing the password.



- ◆ The protection has been released.



Section 2 Menu Reference


2-4-4 Project Menu - Security - Read Only

This command is used to set a password on a specific project and protect it from being changed. (Read Only)

If you set protection, the password is retained in the project file until you cancel it. To write the password-protected project, the correct password is required. This command can protect both project files saved in the PC and transferred to the PLC.


<How to set Read Only>

- ◆ Click [Project] menu > [Security] > [Set Read Only]. The following dialog box opens. Enter the password and click the [OK] button.




- * Set a password from 6 to 32 characters using hexadecimal numbers (0 to 9, A to F, case insensitive) and special characters (+, -, =, /).

- ◆ The dialog box to promote conversion appears. Click the [Yes] button to set the password.




- ◆ When you change the program and save it as a file or transfer it to the PLC, the password entry dialog box appears. Enter the password and click the [OK] button.




Section 2 Menu Reference

<Release Read Only>

- ◆ Click [Project] menu > [Security] > [Release Read Only]. The following dialog box opens. Enter the password and click the [OK] button.



- ◆ The dialog box to promote conversion appears. Click the [Yes] button to convert the project.






Section 2 Menu Reference

2-4-5 Project Menu - Verify

This command is used to compare the currently open project with the project file saved in the PC.

- ◆ Click [Project] menu > [Verify]. The following dialog box opens. Click the [Browse] button, select a project file, and then click the [OK] button. After returning to the "Verify" dialog box, click the [Verify] button.



Section 2 Menu Reference


- ◆ Verification result is displayed.

Verification				
State	Data Type	Current Project	Project 'DeviceB.zpja'	
! Modified	System Definition	System Structure Definition	System Structure Definition	
! Modified	System Definition	System Running Definition	System Running Definition	
✓ Common	System Definition	System Digital Output Setting	System Digital Output Setting	
! Modified	System Definition	CPU Running Definition	CPU Running Definition	
! Modified	System Definition	CPU Memory Border Definition		
! Modified	System Definition		SRM Band Ratio Definition	
! Modified	System Definition		Memory Border Definition	
! Modified	System Definition		CPU Running Definition 2	
! Modified	System Definition	I/O Group Definition 1	I/O Group Definition 1	
! Modified	System Definition		I/O Group Definition 2	
! Modified	System Definition		I/O Group Definition 3	
✓ Common	System Definition	Direct I/O Fail-Soft Operation Setting	Direct I/O Fail-Soft Operation Setting	
! Modified	System Definition	Remote I/O Master 0 Fail-Soft		
! Modified	System Definition		Ethernet Definition	
✓ Common	System Definition	Direct I/O HOLD Definition	Direct I/O HOLD Definition	
! Modified	System Definition	Direct I/O Running Mode	Direct I/O Running Mode	
! Modified	System Definition	Remort I/O Master 0 Running Definition		
✓ Common	Project	Manual_Intro_A74	DeviceB	More >
! Modified	Task	Default : Default	Default : Default	More >
! Modified	Program (POU Number:0)	Ladder0	Ladder0	More >
! Modified	Circuit	Ladder0 - 1	Ladder0 - 1	More >
! Modified	Program (POU Number:1)	Ladder1	Ladder1	More >
! Modified	Circuit	Ladder1 - 1	Ladder1	More >
! Modified	Program (POU Number:2)	Ladder2	Ladder2	More >
! Modified	Circuit	Ladder2 - 1	Ladder2	More >
! Modified	Program (POU Number:3)	Ladder1_0		More >
! Modified	Circuit	Ladder1_0 - 1		More >
! Modified	Program (POU Number:4)	LD3		More >
! Modified	Circuit	LD3 - 1		More >

Verification result
 White : Common
 Orange : Modified
 Gray : Not exist

Section 2 Menu Reference

Explanation of Icon



Icon	Explanation
System Definition	Used to show/hide System definition in the "Data Type" column.
Programs	Used to show/hide Circuit in the "Data Type" column.
Common	Used to show/hide Common in the "State" column.
Modify	Used to show/hide Modified in the "State" column.
Filter line strings	Used to enter a filter keyword.
Filter	Enter a filter keyword, and then click this button to filter the list. Only the items that includes the entered keyword are shown. Click this button again to cancel the filter.
Update the latest status	Used to verify one more time


Section 2 Menu Reference

◆ Double-click a row displaying “Circuit” to display the mismatched line.

State	ES0/ES1	Data Type	Current Project	Project 'MachineA.zpj3'
✓	-	System Definition	Direct I/O HOLD Definition	Direct I/O HOLD Definition
✓	-	System Definition	Direct I/O Running Mode	Direct I/O Running Mode
✓	-	Project	MachineB	MachineA
✓	-	Task	Default : Default	Default : Default
!	-	Program: (0)	Ladder0	Ladder0
!	-	Circuit	Ladder0 - 3	Ladder0 - 3
✓	-	Program: (1)	Ladder1	Ladder1
✓	-	Circuit	Ladder1	Ladder1



- 1) [Vertical disposition] button
- 2) [Open Editor] button
- 3) [Scroll Synchronization] button




4) [Select Mismatch] bar

* This screen is only for confirmation of mismatched lines (only display). They cannot be edited here. Mismatched lines are displayed in light orange. In a mismatched line, a mismatched spot is indicated in dark orange in units of addresses or instructions.

Section 2 Menu Reference


1) [Vertical disposition] button

Click this button to show the verification source project and destination file side by side vertically. When you click the button again, the projects are shown one above the other horizontally.



2) [Open Editor] button

Click this button to open the program in the verification source project.




3) [Scroll Synchronization] button

When this button is turned ON, you can scroll both source and destination program windows together.

Section 2 Menu Reference

4) [Select Mismatch] bar

When there are multiple mismatches, double-click the orange part of the bar to display the mismatch spot.



Section 2 Menu Reference

2-4-6 Project Menu - Import

This command is used to import the followings created in another project to the currently open project.


(1) Program, (2) System Definition, (3) Tag Project, (4) Tag, (5) Line Comment, (6) Initial Value, (7) Array/ Structure, (8) Simulation (9) Instruction List

* (9) Instruction List is dedicated to FLEX-PC (T type) users and used for data linkage with CAD manufactured by SINWA Electric Corporation.

(1) Program


- Programs, function blocks and functions registered in another project file are imported.
- When a function block (or a function) is called in the program, it is also automatically imported. When the "Program Protection" is set in the program or function block (or function), it cannot be imported.
- If the import destination has the same program name as the import source, it is overwritten. If program types (program / function / function block) are different, the import is not done.
- If the import source and destination have the same program No., an unused program No. is assigned to import the program. However, if there is no unused program No., the import is not done.

◆ Click [Project] menu > [Import] > [Program]. The following dialog box opens. Click the [Browse] button.




Section 2 Menu Reference

◆ Select an import source file and click the [Open] button.




◆ Select an import source file and click the [Import] button.




* When importing FBs starting with "_" that are offered by Fuji Electric (e.g. _Cfrp2.Zpj) including standard expansion FBs, make sure to click the [Check The Hierarchy Under] button to select and import all the items.

Section 2 Menu Reference

- ◆ The confirmation dialog box appears. Click the [OK] button to start the import.
 - When there is no program to be overwritten



- When there is a program to be overwritten




- ◆ The following dialog box appears when the import is complete.




Section 2 Menu Reference

(2) System Definition


- System definition registered in another project file is imported. The system definition of the currently open program is overwritten.
 - If the import source and import destination have a different CPU, the memory allocation setting is initialized.
- ◆ Click [Project] menu > [Import] > [System Definition]. The following dialog opens. Select an import source file, and click the [Open] button.



- ◆ The confirmation dialog box appears. Click the [Yes] button to start the import.



- ◆ When the import is complete, the system definition is displayed. Confirm the contents, and then close the system definition.




Section 2 Menu Reference

(3) Tag project

Tag project file is imported to the currently open project.

- ◆ Click [Project] menu > [Import] > [Tag project]. The following dialog box opens. Select an import source file (*.Tpj), and click the [Open] button.




Section 2 Menu Reference

(4) Tag

- A tag file (*.csv or *.txt) exported from another project file is read and added to the currently open project. If a tag has been already registered in an address, it is overwritten by the read tag.

◆ Click [Project] menu > [Import] > [Tag]. The “Import Tag” dialog box opens.



1) Set a tag file name to import. Click the [Browse] button and select a tag file.

2) Select a target program.

- All tags: Global devices (M, L, X, Y, SM) of all programs are imported.
- Selected tag: Programs can be individually selected. Only one program can be selected. If you select <Common>, global devices (M, L, X, Y, SM) of all programs are imported. If you select a specific program, local devices (T, C) of that program are imported.

◆ Select items to import, and then click the [Import] button. When the import is complete, the following dialog box appears.




Section 2 Menu Reference


(5) Line Comment

- This command is used to edit all created line comments in a batch. (for example, when replacing line comments in Japanese to in English). Export the line comment file (*.TXT, *.csv) from a project file, edit it in the text editor, and import it to the project.

◆ Click [Project] menu > [Import] > [Line Comment]. The following dialog box opens. Click the [Browse] button.




◆ When the import is complete, the following dialog appears.




Section 2 Menu Reference

(6) Initial Value

- An Initial value file (*.CSV) exported from another project file is read and added to the currently open project. If an initial value has already been registered in an address, it is overwritten by the read initial value.
- ◆ Click [Project] menu > [Import] > [Initial]. The following dialog box opens. Select an import source file and click the [Open] button.



- ◆ When the import is complete, the following dialog box appears.



Section 2 Menu Reference



(7) Array / Structure

Array/Structure definition in another project is imported.
For more details, refer to Appendix 4-5.

Section 2 Menu Reference


(8) Simulation

- Contents of a simulation folder registered in another project file (simulation panel, AFB) are imported. Only StandardV3 files can be selected. If there is a folder that has the same name in the import destination, the name is automatically changed and the import is done.
- ◆ Click [Project] menu > [Import] > [Simulation]. The following dialog box appears. Click the [Browse] button and select an import file.




Section 2 Menu Reference

- ◆ Files in the simulation folder of the import source are listed. Check items to import and then click the [Import] button.



- ◆ When the import is complete, the following dialog box appears.



Section 2 Menu Reference

2-4-7 Project Menu - Export

This command is used to export the followings from the currently open project.


- (1) Tag Project, (2) Tag, (3) Line Comment, (4) Initial Value, (5) Cross Reference, (6) Device Information, (7) Ladder Data, (8) Instruction List

* (8) Instruction List is dedicated to FLEX-PC (T type) users and used for data linkage with CAD manufactured by SINWA Electric Corporation.


(1) Tag Project

Tag and line comment data are exported in the text format (tag in csv file). Exported data can be edited by a text editor or excel.

- ◆ Click [Project] menu > [Export] > [Tag Project]. The following dialog box opens. Enter a tag project name, and then click the [Save] button.



↓ Tag and Line comment files are created as shown below.




Section 2 Menu Reference

(2) Tag

- Tag information is exported as a tag file (*.CSV or *.txt) from the currently open project file.

◆ Click [Project] > [Export] > [Tag]. The following dialog box opens.



1) Select a program to export


- All tags: Global devices (M, L, X, Y, SM) of all programs, and local devices (T,C) of each program are exported.
- Selected tag: Programs can be individually selected. Only one program can be selected.
If you select <Common>, global devices (M, L, X, Y, SM) of all programs are exported.
If you select a specific program, local devices (T, C) of that program are exported.

2) Set a tag file name. Click the [Browse] button, select a storage folder, and enter a file name.

3) Select target devices.

- All address: All devices with a tag are exported.
- Input/Output address: X and Y devices with a tag are exported.
Export unassigned address: All the X and Y devices that are defined by system definition are exported.
- Memory address: Devices with a tag except X and Y devices are exported.


◆ Select items to export, and then click the [Export] button. When the export is complete, the following dialog box appears.




Section 2 Menu Reference

(3) Line Comment

- This command is used to edit all created line comments in a batch. (for example, when replacing line comments in Japanese to in English). Export the line comment file (*.TXT, *.csv) from a project file, edit it in the text editor, and import it to a project.
- ◆ Click [Project] menu > [Export] > [Line Comment]. The following dialog box opens. Enter a file name, and then click the [Save] button.




- ◆ When the export is complete, the following dialog box appears.




Section 2 Menu Reference

(4) Initial Value

- Initial value information is exported as an initial value file (*.CSV) from the currently open project file.
- ◆ Click [Project] menu > [Export] > [Initial Value]. The following dialog box appears. Enter a file name, and then click the [Save] button.



- ◆ When the export is complete, the following dialog box appears.



Section 2 Menu Reference


(5) Cross Reference

- Cross reference information is exported as a cross reference file (*.CSV) from the currently open project file.


- ◆ Click [Project] menu > [Export] > [Cross reference]. When a cross reference is not created completely, the following dialog appears. Click the [Yes] button.



- ◆ The following dialog box opens. Select a folder to save a cross reference file, enter a file name, and then click the [Save] button.



- ◆ When the export is complete, the following dialog box appears.



Section 2 Menu Reference

(6) Device Information


Device information of the currently open project is saved as a file.

This information is used for:


- 1) Device information for POD (UG/MONITOUCH series) to share devices with Standard loader.
* For the POD operations, refer to the manual of POD.
- 2) Device information for Communication middleware.

Note: This device information file can be used in the UG series loader (Type: UG00S-CW) version 3.2.2.1 or later.

◆ Click [Project] > [Export] > [Device Information]. Enter a file name, and then lick the [Save] button.



◆ Device information files are created. Device information consists of multiple folders and files as shown below.




Section 2 Menu Reference

(7) Ladder Data

Ladder data information used for POD (UG/MONITOUCH series) ladder monitor function is exported as a file.


- ◆ Click [Project] menu > [Export] > [Ladder Data]. The following dialog box opens. Enter a file name, check a program name to export, and then click the [Export] button.



When the export is complete, the following dialog box appears.



- ◆ Ladder data file are created. Ladder data consist of multiple folders and files as shown below.



Program type	Monitor (Export) Yes/No
Standard FB	No
Password protected program	No
ST program	No
AFB	No
Other programs	Yes

Section 2 Menu Reference

2-4-8 Project Menu - Cross Reference

This command is used to create a cross reference of the currently open project.

A cross reference shows the addresses used in the program, tag names corresponding to them, types of read and write, instruction words, program names, and line Nos.

◆ Click [Project] Menu > [Cross Reference] > [Create Cross Reference]. The Cross Reference window opens.

Double-click this cell to sort.

Device	Tag	Access	Instruction	Symbol	Type	Program	Line No.	Device Pos.	Setting Value
X1.0	IN0	Read	LD	- -	Program	Ladder0	1	1	
X1.2	IN2	Read	AND	- -	Program	Ladder0	1	3	
X1.2	IN2	Read	LD	- -	Program	Ladder0	2	1	
X1.4	IN4	Read	LD	- -	Program	LD1	4	1	
X1.5	IN5	Read	AND	- -	Program	LD1	6	3	
X1.6	IN6	Read	LD	- -	Program	LD1	1	1	
X1.7	IN7	Read	AND	- -	Program	LD3	8	4	
DX1.2		Read	MOVE		Program	LD1	1	2	
WX1.1		Read	MOVE		Program	LD1	5	2	
Y2.4	OUT4	Write	OUT	-()-	Program	LD1	4	6	
Y2.5	OUT5	Write	OUT	-()-	Program	LD1	7	2	

Double-click an arbitrary row to display the corresponding line

[Filter] button: Click this button to display the following dialog box. Check items to filter, and enter an address to display with filtering or select an item. And then, click the [OK] button. Only the items meeting the conditions are displayed.

Filter

Device Access Instruction/Symbol Type Program

M0 Write -()- Program FCTD

OK Cancel



Device	Tag	Access	Instruction	Symbol	Type	Program	Line No.	Device Pos.	Setting Value
M0	Flicker_Out	Write	OUT	-()-	Program	LD1	3	6	
M0	Flicker_Out	Write	OUT	-()-	Program	LD3	3	6	

[Update] button: Click this button to update the cross reference display.

[Trace Back] button: When multiple rows in the cross reference are double-clicked, the corresponding circuits are displayed in order. Use this button to return to the previously selected row.

[Trace Forward] button: This button has the opposite function of the [Trace Back] button.

Section 2 Menu Reference

2-5 Online Menu

The "Online" menu contains the following commands.

- Communication Setting ⇨ Makes communication setting with the PLC.
- Simulation Mode ⇨ Performs offline simulation of the PLC.
- PLC Operation (Run/Stop, Load) ⇨ Performs various kinds of operations to the PLC.
- Monitor ⇨ Performs online monitoring of the PLC.
- Load the changed program into PLC ⇨ Used when you edit circuits during online operation
- Data Modify ⇨ Changes device memories.
- Break Point ⇨ Makes a break point setting.
- Condition Monitor ⇨ Makes a condition monitor setting.
- Sampling Trace ⇨ Makes a sampling trace setting.
- Program Operation ⇨ Enables or disables the programs loaded to PLC
- Task Execution Time Measurement ⇨ Measures time of task execution.
- Data Monitor ⇨ Performs the device monitoring.

The following three commands have been removed in the version V3.0.6.24 because they may cause a fault depending on the usage.

- Read Data ⇨ Reads a device condition saved as a file in the computer to a loader.
- Save Data ⇨ Saves a device condition on a loader as a file in the computer.
- Load Data to PLC ⇨ Transfers the device condition saved as file in the computer to PLC.

<Description>

Only the device memories whose data are being monitored are read from the memory of the PLC by the "Save Data" command. Device memories that are not being monitored are saved as zero.

If the data saved here is written to the PLC by the "Load Data to PLC" command, zero is written to the memory area that is not being monitored. Depending on how the system is operating, your important data may be deleted. For this reason, the above commands have been removed in the version V3.0.6.24.

When you want to save data, alternatively use the SX control utility function described in Appendix 1.


Section 2 Menu Reference

2-5-1 Online Menu - Communication Setting


This command is used to make communication settings with the PLC.

(1) Direct communication with connected PLC

- ◆ Click [Online] menu > [Local Device Setting]. The "Communication Setting" dialog box opens. Click the [Setting] button.



- ◆ The [setting] dialog box opens. Select a type of the communication port.



* SPB supports only "COM port."

Section 2 Menu Reference


<In the case of USB>

Select "USB" to connect to a USB port built-in the CPU.

When you install a loader software and use the online tool with a USB for the first time, the requirement screen of the USB driver appears.

The USB river (ScUsb.inf) is stored in "/Driver/MICREXSX", in the Install folder of the loader software.



For more details of USB driver installation, refer to "Appendix 9 USB Driver Installation."



<In the case of COM port>

Select "COM port" to connect to a CPU loader port using a dedicated cable by Fuji Electric or to connect via a general purpose communication module.

Set the port number of the loader according to the port number of the computer.



When connecting to a loader port, you do not need to change the above settings.

* Dedicated cable:

For SPH:

- Combination of NP4H-CVU and NP4H-CB2 (USB connection) or
- Combination of NW0H-CNV and NP4H-CB2 (RS-232C connection)

For SPB:

- Combination of NP4H-CVU and NW0H-CA3 (USB connection) or
- Combination of NW0H-CNV and NW0H-CA3 (RS-232C connection)

Section 2 Menu Reference

<In the case of Ethernet>

Select "Ethernet" to connect to the Ethernet port built-in the CPU or connect via an Ethernet module.

Set the IP address and port number of the connection partner.

The default settings are as follows. Partner IP address: 192.168.0.1, Partner port No.: 507.

The order is "Target IP address", a space, and "Target port No."

Example: 192.168.0.1 507 (Integer value)

The screenshot shows a 'Setting' dialog box with a title bar containing a close button. It is divided into two main sections. The top section, titled 'CommunicationPort', contains five radio button options: 'USB', 'COM port', 'Ethernet', 'Communication board', and 'Modem'. The 'Ethernet' option is selected. The bottom section, titled 'Setting', contains a text input field labeled 'IP Address:' with the value '192.168.0.1.507' entered. At the bottom of the dialog are 'OK' and 'Cancel' buttons.

<In the case of Modem>


Select "Modem" to connect via a modem. Install the modem driver to be used first. Then select it from the list and enter the telephone number to connect.

The screenshot shows a 'Setting' dialog box with a title bar containing a close button. It is divided into two main sections. The top section, titled 'CommunicationPort', contains five radio button options: 'USB', 'COM port', 'Ethernet', 'Communication board', and 'Modem'. The 'Modem' option is selected. The bottom section, titled 'Setting', contains two dropdown menus. The first is labeled 'Modem:' and has 'WAN Miniport (L2TP)' selected, with a 'Setting...' button to its right. The second is labeled 'Phone number:' and has '048-548-****' selected, with a 'Register' button to its right. Below these are two radio button options: 'Tone' (selected) and 'Pulse'. At the bottom of the dialog are 'OK' and 'Cancel' buttons.

Section 2 Menu Reference

<In the case of communication board>

Select "communication board" to connect via a board that supports the extended slot of the computer.



Parameter setting of the communication board differs according to the board type as show below.

- 1) SX bus board
There is no parameter.
- 2) PCI bus P-link board
"Communication partner point P station No."
Example: 15 (decimal notation)
- 3) PCI bus PE-link board
"Communication partner point PE station No.", "Own No."
Example: 63 0 (decimal notation)
- 4) ISA bus PLC board
There is no parameter.
- 5) PCI bus PLC board
There is no parameter.
- 6) PCI bus FL-net board
"Partner IP address", space, "Own IP address"
Example: 192.168.250.5 192.168.250.1 (decimal notation)
- 7) FL-net board (LAN board)
"Partner IP address", "Own IP address", "A = IP address", "B = IP address"
(Enter a space between each address.)
Example: 192.168.250.5 192.168.250.1 A=192.168.250.1 B=192.168.250.2 (decimal notation)
* Parameters other than "Partner IP address", "Own IP address" can be omitted.
* The allowable ranges of the node number (host address) in the "Own IP address" is 1 to 64.
* Be sure to make "Own IP address" agree with the IP address in the LAN board.
Note: The LAN board is only supported by NP1L-FL1. NP1L-FL2 and FL3 do not support the LAN board.
To connect to NP1L-FL2/FL3, use an FL-net board.

◆ When the setting is done, click the [OK] button to return to the previous screen. Click the [OK] button to close the "Communication setting" dialog box.

Section 2 Menu Reference

(2) Loader network communication

<Overview>

In a link system using the P/PE-link module, FL-net module, Ethernet interface module, and general-purpose communication module (RS-485) of MICREX-SX series, you can perform remote operations (e.g. program download/upload, monitor, test functions) from the loader connected with one CPU module to the CPU modules in 3-layer SPH system.

You can also perform remote operations from the loader connected with another CPU module. The maximum number of remote operation routes is two (at the time of simultaneous operation).

In addition, in a simplified CPU link using a communication adapter (RS-485) of SPB series, you can perform remote operations from the loader connected to the basic unit with station No. 0 to another basic unit. (one layer and one route only)

* A loader network using the simplified CPU link is supported by all types and all versions of basic units/communication adapters.

<Applicable versions>

To perform remote operations with a 3-layer 2-route loader network, use a communication module with the following software version.


Module		Version
CPU module	SPH300	Software version V38 or later
	SPH2000/3000	All versions
	SPH200	Software version V37 or later
Communication module	P-link module	Software version V33 or later
	PE-link module	Software version V33 or later
	FL-net module	Software version V30 or later
	Ethernet module	Software version V30 or later
	General-purpose communication module (RS-485)	Software version V30 or later

* Setting of "(1) Direct communication with connected PLC" is necessary even when using loader network communication. The loader network communication setting is explained below.


Section 2 Menu Reference

<Loader network setting>


- ◆ Click [Online] menu > [Communication Setting]. The "Communication Setting" dialog box opens. Click the [Setting] button.



- ◆ The "Setting" dialog box opens. Select a module type to be used, local SX bus station No. (or CPU No.) and SX bus station No. (or address) of the connection partner, and then click the [OK] button.




- ◆ The following dialog box appears. Click the [OK] button.




Section 2 Menu Reference

- ◆ The first level setting of the loader network is now complete.
To access the next level CPU, click the [Setting] button and perform communication settings.



Section 2 Menu Reference

The buttons of loader network setting




Section 2 Menu Reference

1) [Communication test]: Performs communication test in the set loader network.

- When the communication is established successfully, the following dialog box appears.




- When the communication fails, the dialog box shows the route where the communication fails, as shown below.



Section 2 Menu Reference


2) [Enhanced setting]: Makes settings of the time out interval of loader network communication and communication data size.




Set the time out and data size according to the network type to be used. Confirm your network type, and set the following values. You usually do not need to pay attention since the loader automatically sets the optimum values when the network is set.

Network	Timeout (ms)	Data size (byte)
P-link	11,000	200
PE-link	11,000	200
Ethernet	11,000	492
RS485	11,000	492
FL-net	11,000	492
LE-net	11,000	104
Simplified CPU link	11,000	492

3) [Registration]: Registers the setting of loader network communication with a name.



4) [Load/ Delete]: Loads or deletes the setting of the registered loader network communication.



Section 2 Menu Reference


2-5-2 Online menu - Simulation mode

This command is used to simulate PLC operation in offline mode. For more details, refer to Appendix 3.

Section 2 Menu Reference

2-5-3 Online menu - PLC Operation (Run/Stop, Load)

This command is used to perform various PLC operations such as Run/Stop PLC, Write/Read Program, and failure diagnosis.



2-5-3-1 PLC operation buttons

The followings explains the functions of the buttons.

(1) Batch operation / Individual operation

- Batch operation: All the CPUs in an SX-bus system (in the same configuration) are controlled. Check this option to control all the CPUs in a multi CPU system in a batch. [Run], [Initial Run], [Stop], and [Reset] commands are effective.
- Individual operation: One CPU to which the loader is connected is controlled. All the commands are effective.

(2) Stop

This button is used to stop the working CPU. This function is available only when the CPU key SW is set at TERM.

(3) Run

This button is used to start a stopping CPU. This function is available only when the CPU key SW is set at TERM. A CPU in fatal fault cannot be started by this button. The non-retain memory is cleared at start-up.

(4) Initial Run

This button is used to initial-start a stopping CPU. This function is available only when the CPU key SW is set at TERM. A CPU in fatal fault cannot be started by this button. The difference from "Run" is that not only the non-retain memory but also the retain memory is cleared at start-up. The retain memory is not cleared in normal use. Therefore, this button is disabled by default to avoid using it by mistake. To use this function, click [Tool] menu > [Option]. On the "Options" dialog box, select "Online, and then check "Permit the use of Initial Run."

(5) Reset


This button is used to reset the CPU. The CPU needs to be reset (or switched ON/OFF) when you create a new program and download it to the PLC, or edit system definition and download programs to the PLC. This command is available only when CPU key SW is set at TERM.

*In a redundant system or a multi CPU system, do not perform reset operation when CPU 0 is disconnected.

Section 2 Menu Reference

(6) Load to PLC

This button is used to transfer the contents of the currently open project to the PLC. Be sure to execute conversion before the transfer.




The "Load to PLC" dialog box consists of the following options. Use the default settings normally. However, to use "Tag Project," "FB Parameter data," and "Module driver," the conditions explained below need to be satisfied.

- **Program:**
Programs in the project view window. Unassigned programs are not loaded.
- **Clear retain memory area:**
The retain memory in the CPU is cleared. Normally, do not select this.
- **Clear FB/SFB variable:**
Variables held in FB (function block) and SFB (system FB such as a counter FB, or Integral timer FB) are cleared. Normally, do not select this.
In SPH200, this option is disabled since the FB/SFB variables are forcibly cleared by the PLC when the program is loaded to the PLC.
- **System definition:**
System definition in the project view window
- **Zip file:**
Zipped program name / Tag / Line comment / System configuration are transferred.
Program name: Program name shown in the project view window
Tag: Device tag
Line comment: Line comment in a program
System configuration: Module name defined in system definition
- **Tag project:**
A tag project is loaded to the user ROM in the PLC. (Enabled when a user ROM is attached to the CPU.)
- **FB parameter data:**
This option is enabled when a PID FB is used.
- **Module driver:**
This option is enabled when an Ethernet / ADS-net / PC card / LON WORKS module is used.
* When you connect the loader to a general-purpose module (NP1L-RS*) and perform the download via it, the module driver cannot be loaded. (A general-purpose module does not support the download of a module driver.)

Section 2 Menu Reference

(7) Load from PLC

This button is used to read the contents of the PLC.



The "Load from PLC" dialog box consists of the following options. Use the default settings normally.

- **Load in ZIP File:**

A ZIP file (Program names, tag names, line comments, and system constructions) is read.

Zip file: Check this option to read a zip file from the PLC.

Tag project: Check this option to read a tag project file saved in the user ROM attached to the CPU. (Enabled when a user ROM is attached to the CPU and a tag project is saved in it.)

Project: Check this option to read a zip file stored in a project file (*.Zpj3) saved in the computer.

- **Reflect Real Structure:**


Uncheck this option to read a program from a working system.

For example, when you purchase a new CPU and have not loaded system definition yet, or when you have executed memory clear, no system definition exists in the CPU. If a CPU without system definition is started, the CPU automatically recognizes the modules connected to the SX bus system and creates system definition. To read the contents of the PLC in such a condition, check this option.

Section 2 Menu Reference

(8) Verify with PLC

This button is used to compare the currently open project with the contents of the PLC. "Tag project" is enabled when a user ROM is attached to the CPU.



◆ The verification result is displayed.

Verification				
State	Data Type	Current Project	Project CPU0	
✓ Common	System Definition	System Structure Definition	System Structure Definition	
✓ Common	System Definition	System Running Definition	System Running Definition	
✓ Common	System Definition	System Digital Output Setting	System Digital Output Setting	
✓ Common	System Definition	CPU Running Definition	CPU Running Definition	
✓ Common	System Definition	CPU Memory Border Definition	CPU Memory Border Definition	
✓ Common	System Definition	I/O Group Definition 1	I/O Group Definition 1	
✓ Common	System Definition	I/O Group Definition 2	I/O Group Definition 2	
✓ Common	System Definition	I/O Group Definition 3	I/O Group Definition 3	
✓ Common	System Definition	Direct I/O Fail-Soft Operation Setting	Direct I/O Fail-Soft Operation Setting	
✓ Common	System Definition	Direct I/O HOLD Definition	Direct I/O HOLD Definition	
✓ Common	System Definition	Direct I/O Running Mode	Direct I/O Running Mode	
✓ Common	System Definition	Processor Link 0 Running Definition	Processor Link 0 Running Definition	
✓ Common	Project	Loadernet_01	CPU0	More >>
! Modified	Task	Default : Default	Default : Default	More >>
✓ Common	Program: (0)	Ladder0	Ladder0	More >>
! Modified	Circuit	Ladder0 - 3	Ladder0 - 3	More >>
! Modified	Program: (1)	Ladder1	PG00001	More >>
! Modified	Circuit	Ladder1 - 3	PG00001 - 3	More >>
! Modified	FB Instance	Address Allocation	Address Allocation	

The verification result is classified by color.


- White: Common
- Orange: Modified
- Gray: Not exist

For more details of verification, refer to "2-4-5 Project Menu - Verify."

Section 2 Menu Reference

(9) Clear

This button is used to clear the contents of the PLC.



Select the items you want to clear.

To clear all the contents of the PLC, check "Resource initialization." Even if a password or read only is set, the contents can be cleared.


Section 2 Menu Reference

(10) User ROM

This button has the following three functions: Verify, Security, and Export user ROM File to Text File. This button is enabled when a user ROM is attached to the PLC.

(10) -1 Verify

This command is used to compare the currently open project with the contents of the user ROM attached to the PLC.



◆ The verification result is displayed.

State	Data Type	Current Project	Project User ROM	
✓	Common	System Definition	System Structure Definition	System Structure Definition
✓	Common	System Definition	System Running Definition	System Running Definition
✓	Common	System Definition	System Digital Output Setting	System Digital Output Setting
✓	Common	System Definition	CPU Running Definition	CPU Running Definition
✓	Common	System Definition	CPU Memory Border Definition	CPU Memory Border Definition
✓	Common	System Definition	I/O Group Definition 1	I/O Group Definition 1
✓	Common	System Definition	I/O Group Definition 2	I/O Group Definition 2
✓	Common	System Definition	I/O Group Definition 3	I/O Group Definition 3
✓	Common	System Definition	Direct I/O Fail-Soft Operation Setting	Direct I/O Fail-Soft Operation Setting
✓	Common	System Definition	Direct I/O HOLD Definition	Direct I/O HOLD Definition
✓	Common	System Definition	Direct I/O Running Mode	Direct I/O Running Mode
✓	Common	System Definition	Processor Link 0 Running Definition	Processor Link 0 Running Definition
✓	Common	Project	Online_32	User ROM More >>
!	Modified	Task	Default : Default	Default : Default More >>
✓	Common	Program: (0)	Ladder0	Ladder0 More >>
!	Modified	Circuit	Ladder0 - 3	Ladder0 - 3 More >>
!	Modified	Program: (1)	PG00001	Ladder1 More >>
!	Modified	Circuit	PG00001 - 2	Ladder1 - 2 More >>
!	Modified	FB Instance	Address Allocation	Address Allocation

The verification result is classified by color.

- White: Common
- Orange: Modified
- Gray: Not exist

For more details of verification, refer to "2-4-5 Project Menu - Verify."

Section 2 Menu Reference

(10) -2 Security

This command makes the user ROM attached to the PLC read-only.

For more details of read only setting, refer to "2-7-1 Tools Menu - User ROM Utility."


Section 2 Menu Reference

(10) -3 Export user ROM File to Text File


The contents of the file (data) written into the user ROM attached to the PLC by F_WRITE FB are outputted as a text.

- ◆ Attach a user ROM card to the CPU module and establish access to the user ROM (UROM_LED lights up).
In the following dialog box, set the items below.
"User File": Enter the file name in the user ROM.
"Text File": Click the [Browse] button and specify the folder to save and the storage file name.
Then, click the [Export] button.

* Up to 20 histories regarding the export source and exported files are stored.




- ◆ When outputting a text file is complete, the following dialog box appears. To check the content of the text file, click the [Yes] button.



<Text file format to output>

The file format to output is shown below. Use your text editor to show it.



Section 2 Menu Reference

(11) Password

This button is used to set a password.

The password has the following two functions.

1) To set a program as read only


2) To set access level, and limit each operation (Run/Stop, Load, Edit working program) depending on the set access level.

For more details, refer to the "Appendix 5."

Section 2 Menu Reference

(11) Calendar

This button is used to show the calendar build-in PLC and make settings of it.




When you open the "Calendar" dialog box, the current date and time of the PLC is displayed. Click on the part of "year/month/day/hour/minute/second," the display is inverted. Enter a value or click the up and down button on the right to select a value, and then click the [Set] button. The date and time is set in the PLC. Click the [Synchronizes with PC] button to set the date and time in synchronization with your computer.

Even if the PLC is disconnected, this date and time is retained and updated by the PLC battery. The setting range is 1970/01/01 00:00:00 to 2069/12/31 23:59:59.

Section 2 Menu Reference

(13) Redundancy Control

This button is used to replace a CPU to be connected and switch between a working CPU and a standby CPU in a redundant system.





(14) Execution time

This button is used to measure the execution time and execution cycle of a program. For more details, refer to "2-5-11 Task execution time measurement."

Section 2 Menu Reference

2-5-3-2 Failure Diagnosis button

When you click this button, the "Failure diagnosis" dialog box opens. The failure diagnosis function displays the failure status of the PLC.



Section 2 Menu Reference


(1) Display overview




The "Failure diagnosis" dialog box consists of the system configuration display section and the diagnostic information display section.

The system configuration display section shows in which module a failure occurred in visual form.

The diagnostic information display section shows failure information in detail.

The display contents are refreshed (updated) automatically at fixed intervals.



- System configuration display section ⇒ Displays the system configuration in a tree form. A mark is displayed on the icon at failure positions. (Fatal fault: , Nonfatal fault: , Fatal and nonfatal faults: )
- Diagnostic information display section ⇒ Displays the system RAS and detailed RAS as text data.
- Configuration display selection ⇒ Choose "Bus connection composition" or "User definition composition." The default setting is "User definition composition."
- History information selection ⇒ Choose "Current RAS", "1 previous generation", "2 previous generations", or "3 previous generations." The default setting is "Current RAS."
- [File save] ⇒ Saves the RAS information file.
- [File view] ⇒ Displays the RAS information file.
- [File delete] ⇒ Deletes the RAS information file.
- [Check configuration]
 - ⇒ Checks whether the module configuration registered in the system definition matches the actual configuration and indicates the mismatch items.
- [Failure analysis] ⇒ Analyzes the status of the PLC system and displays error description, location and remedies.
- [Close] ⇒ Closes the Failure diagnosis dialog box.
- [Help] ⇒ Displays Help of the failure diagnostic function.

Section 2 Menu Reference

(2) System configuration display section

The system configuration display section has the following two modes, selectable from the "Configuration" combobox.

1) User definition composition

System configuration information that is set in the system definition and then loaded to the PLC by the user is displayed in a tree form.


Data is displayed by loading the system configuration information from the CPU.

2) SX Bus connection composition




Actual configuration of modules connected to the SX bus is loaded from the CPU and displayed in a tree form.

Only modules directly connected to the SX bus are displayed in order of the SX bus station number.

For the CPU and processor link module, the SX station number and the CPU number are displayed.




<Display specifications>

- If a system fault is detected, a mark corresponding to the degree of the fault is displayed on the icon.
(Example: Fatal fault: , Nonfatal fault: , Fatal and nonfatal faults: )
- Icon display for modules is the same as that for the system definition.
- "Base board" and "Power supply" are not displayed.
- The default setting of the configuration display selection is "User definition composition." If "User definition composition" does not exist (if the system definition has not yet been downloaded), "SX bus connection composition" is displayed.
- At the time of initial display, the CPU module (CPU number: 00) is selected.
- If communication is disconnected during RAS information display, a blank is displayed.

Section 2 Menu Reference

(3) Diagnostic information display section

The failure diagnostic display section displays detailed fault information for the module selected in the system configuration display section.



<Display specifications>

- The display contents are grouped by tabs. The items of each tab depends on the selected module.
- The starting tab is "System RAS," which displays the system RAS information in the CPU module (CPU number: 00) at the time of initial display.
- The tabs are displayed in one or two rows depending on the module.
- If communication is disconnected during RAS information display, a message saying "Communication error" appears.
- "Current RAS", "1 previous generations", "2 previous generations", or "3 previous generations" is selected depending on the RAS history. The default setting is "Current RAS."

<History display>

- When the previous RAS ("1 previous generation", "2 previous generations", or "3 previous generations") is selected as RAS history, the fault history data is loaded from the CPU and then displayed.
- If there is no history data (all 0s), the following display results.
 - <Message data display items>
 - RAS with "message + value": Same display as the case where there is history data.
 - RAS with "message only": "No data" is displayed.
 - <Binary data display items>
 - Displays all 0s.

<Search function>

- The text search combobox and the search start button are provided at the bottom of the diagnostic information display section, allowing text search for the contents currently displayed in the diagnostic information display section.
- The search start position is the row at the current cursor position in the diagnostic information display section. When the cursor is not displayed, it is the top position.
- The search direction is Downward only. The cursor move to the row containing a matched character string.
- Each item name of the selected tab is automatically inserted in the "Text Retrieval" list box, making it easier to jump to each item.
- When search character strings are entered, up to five search character strings are memorized, allowing you to perform search again using a previously used search character string even after activation of failure diagnosis next time. When the number of search character strings exceeds five, the oldest one is deleted.

Section 2 Menu Reference


(4) RAS information file operation

The information in the Failure diagnosis dialog can be saved in a disk file. The RAS information file can be displayed and deleted. Each operation can be performed using each file operation button in the Failure diagnosis dialog box.

1) File save

This button is used to save the data displayed in the Failure diagnosis dialog in a file.

- ◆ Click the [File save] button on the "Failure diagnosis" dialog box. The "Save RAS File" dialog box opens.
- ◆ Specify the target location and each item and then click the [Save] button. The data are saved in the specified file.



<Preservation item>

Specify the data to be saved using "System configuration information", "Diagnosis details", and "Dump list of system memory." By default, "User definition" is selected for "System configuration information" and "Selection module" is selected for "Diagnosis details".



- System configuration information
The contents in the system configuration display section are saved. Select "All," "User definition," or "SX bus connection composition."
- Diagnosis details
The contents in the diagnostic information display section are saved. Select "All modules," "Selection module," or "Only the display data."
- Dump list of system memory
System memory data are saved as hexadecimal text data.

Section 2 Menu Reference

2) File view

This button is used to display the contents of a RAS information file.


- ◆ Click the [File view] button in the "Failure diagnosis" dialog box. The "View RAS file" dialog box opens.
- ◆ Specify a target RAS information file and then click the [View] button. The specified RAS information is displayed.



3) File delete

This button is used to delete a RAS information file.

- ◆ Click the [File delete] button in the "Failure diagnosis" dialog box. The "Delete RAS file" dialog box opens.
- ◆ Specify a target RAS information file and then click the [Delete] button. The specified RAS information file is deleted.



Section 2 Menu Reference

4) Format of save file

The file name and data formats for RAS information files are shown below.
 The file name is "****.RAS" (**** is specified by the user) and data are all text data.
 Data are saved in order of the configuration information data and the diagnostic information data.


<Save data>

System configuration type	"SX bus connection composition" or "User definition"
Configuration information data	Tree information title "" tree information "" Row 1 data Row 2 data : : Last row data
Diagnostic information data (for each tab information)	Diagnostic information title "" Diagnostic Information "" RAS history (Current, 1 previous generation, 2 previous generations, and 3 previous generations) 1st tab name Data in the 1st tab 2nd tab name Data in the 2nd tab : : Last tab name Data in the last tab


(5) Configuration check function

If the system configuration registered in the system definition does not agree with the actual configuration, a fatal fault occurs in the system, which cannot start to run. In this case, a "System configuration error" message is displayed on the system RAS. To operate the SX system normally, it is necessary to match the system definition with the actual configuration.

- ◆ Click the [Check Configuration] button on the "Failure diagnosis" dialog box. The "Check Configuration" dialog box opens.
- ◆ On the dialog box, the contents of the module registration in the system definition and the actual configuration are displayed. If there is a mismatch between them, the mismatch spot is displayed in red.



Section 2 Menu Reference




* The above example shows that a module that has not been registered in the system definition exists in the actual configuration.

<Differences of SX bus station numbers between user definition composition and bus connection composition>

If the SPH system is reset when a system configuration error occurs due to a configuration definition mistake or module failure, etc., numbers beginning with 1 are assigned to the SX bus stations in their connected order on “bus connection composition” box. Note that if the CPU or power supply is reset due to a system configuration error after arbitrary SX bus station numbers are set as shown in the figure below, the SX bus station numbers of “user definition composition” do not match those of “bus connection composition”.

In the example below, different SX bus station numbers are displayed as follows:

DC/AC input 16 points	User definition composition: 10	↔	Bus connection composition: 1
Relay output 16 points	User definition composition: 20	↔	Bus connection composition: 2
Sink-type output 16 points	User definition composition: 30	↔	Bus connection composition: 3
Ethernet module	User definition composition: 1	↔	Bus connection composition: 4



<Measures>

- 1) To match “user definition composition” with “bus connection composition”, it is recommended to assign SX bus station numbers in their connected order.
- 2) Even if an error occurs in the system during operation, “user definition composition” matches “bus connection composition” until the system is reset. Perform failure diagnosis before resetting the system.

Section 2 Menu Reference

(6) Failure analysis function

This function automatically analyzes the status of the PLC system from the system memory and RAS information in the CPU and displays the error description, cause, remedies and location.

Note: This function can be used only with SPH300 series of CPUs.

1) Example of displaying failure analysis results

Error description display area
All the errors detected in the PLC system are displayed. By clicking each error description, the remedies, fatal failure information and failure position of the error are displayed.

Remedy display area
The probable causes and remedies of the error selected on the "error description display area" are displayed.

Fatal failure information display area
If the error is a fatal failure, its name, cause and time of occurrence are displayed. If the error is a nonfatal failure, this area is not displayed.

Module type	System definition	Real configuration
	0x02	0x04


Failure position display area
The failure position is displayed.

Click the tab to change over the window.


Section 2 Menu Reference

2) Display specifications of the failure analysis screen

- ◆ Click the [Failure analysis] button to perform failure analysis and display the result.



Section 2 Menu Reference



Note 1: If two or more fatal failures occur, only the description of the first detected error is displayed on the "fatal failure" tab window.

<Display specifications of the failure analysis screen>

1) Icon

Icon	Description
	Fatal failure has occurred.
	Nonfatal failure has occurred.
	Both fatal and nonfatal failures have occurred.
	Set as "no equipment" in the system definition.



2) Display color

Display color and example	Description
Background color: yellow, Text color: black CPU : CPU-0 : High Performance CPU32 : NP1PS-32	This module is disconnected. (or fatal failure has occurred.)
Background color: yellow, Text color: black Direct I/O : SX Station-2 : Sink Output 16points : NP1Y16T09P6	This module is registered in the system definition, however, does not exist in the actual configuration.
Background color: gray, Text color: blue Direct I/O : SX Station-2 : *Digital Output 32points	This module exists in the actual configuration, however, is not registered in the system definition.

Section 2 Menu Reference

3) Automatic execution of failure analysis

If an error occurs in the system, failure analysis can be automatically executed by simply clicking the [Failure diagnosis] button.



Section 2 Menu Reference



Close

Failures were detected as follows

The system configuration definition is different from an actual configuration.

Check the following items

1. Please confirm the system configuration again by [Check configuration] in the failure dia
2. Is the SX bus number of the module with the SX buse number (POD, servo, I/O termina
3. Is the type of the mounted base board the same as the base board in the system definiti
4. Please confirm the setting of the SX bus number of the module with the SX bus number
5. Has the power supply of all modules been turned on?

Fatal Failure

System definition error 2009-08-12-00:45:37.000

Number of SX bus module error

	System definition	Real configuration
Number of connect	4	3

Fatal Failure Failure Position

Analysis done.

<How to set>

- ◆ Click [Tool] menu > [Option]. The "Options" dialog box opens. Select "Online" from the category, and check "Show the failure analysis automatically."

Options

Category:

- General
- Directories
- Project
- Online
- Conversion
- Backup

PLC Operation

- Show the failure analysis automatically
- Permit the use of Initial Run

Monitor

- Verify before the monitor is started

Load to PLC

- Permit load to PLC only the program

Initial setting...

Load the changed program into PLC

- Show the confirmation before download to PLC

Load from PLC

Automatic import of the Ex.FB


- Don't import automatically
- Import automatically
- Import without a confirmation message automatically

OK Cancel

Section 2 Menu Reference

2-5-4 Online - Monitor

This command is used to monitor the PLC online. During online monitoring, you can check the ON/OFF status of PLC contacts and coils, and the usage of the device memory.





* During the monitoring, you cannot edit the program by default. To edit a program that is being monitored, click [Tool] menu > [Option]. Then, on the "Options" dialog box, select "Online" from the category, and check "Allow editing of being monitored."

Section 2 Menu Reference

2-5-5 Online menu- Load the changed program into PLC

This command is used change a PLC program partly online (online program change function). This function is available when you open the same project as the PLC and make a change to the program. Only the changed program is loaded to the PLC. A program can be changed either when the PLC is working or stopped. The CPU key SW must be set at TERM.



If you have performed any of the following operations, the "Load the changed program into PLC" command cannot be used.

- Changing the system definition
- Changing the task property
- Adding/removing the task
- Adding a program to the task
- Adding an unassigned program to the task
- Moving a program under the task to Unassigned Programs
- Changing a program name
- Changing a program number
- Changing a function block number
- Adding/changing/removing a function block parameter
- Deleting a program
- Deleting a function block
- Adding/changing/deleting an initial value
- Importing an initial value
- Adding/changing/deleting Array, Structure definition

Note 1: When you execute the "Load the changed program into PLC" command for SPH300 CPU, an available program space of 8192 or more steps is required in the CPU.

When you execute the "Load the changed program into PLC" command for SPH200 CPU, an available program space of 4096 or more steps is required in the CPU.

Section 2 Menu Reference

2-5-6 Online menu - Data modify

This command is used to modify data memory of the PLC online. Data memory can be modified either when the PLC is working or stopped. The "Data modify" command has the following two functions: [Data modify] and [Force ON/OFF].


- [Data modify]:

This function is mainly used to change the internal memory data.


Input address data cannot be changed by this command.

Output address data can be changed by this command. However, this command can be executed only once. When the CPU is working and the output address is used as a coil or specified as a transfer destination in the program, it is overwritten by program operation. This is also true for the internal memory.

Example of data modification (Bit)



Example of data modification (Word)




Section 2 Menu Reference

- [Force On/Off], [Forcible setting cancel], [Forcible setting all cancel]:

These commands are used to forcibly set ON or OFF an I/O memory, or cancel the forcible ON/OFF setting. The status of the forcible ON/OFF is cancelled by canceling operation from the loader, turning ON/OFF the CPU power, and resetting the CPU. It is not canceled by stopping and starting the CPU.


Forcible ON/OFF setting of the internal memory is not possible.

Example of Forcible setting



* SPB, Board (SPB) does not support the force On/Off function.

* In SPH300, if you check "ON" for "Compulsion setting hold state," the forcible ON/OFF setting is not canceled by turning ON/OFF the CPU power or resetting the CPU. To cancel it, the canceling operation from the loader is necessary.



Section 2 Menu Reference

<Data format to be entered into new value>

Data type	Input range	Input example
BIT (BOOL)	ON, OFF	ON, OFF
INT	-32768 to 32767	INT#123, 123
DINT	-2147483648 to 214748647	INT#123, 123456
UINT	0 to 65535	UINT#123
UDINT	0 to 4294967295	UDINT#123456, 123456
REAL	$-2^{128} < N \leq -2^{-126}$, $0, 2^{-126} \leq N < 2^{128}$	1.23, 1.3E-5
TIME	0ms to 4294967295ms 0ms to 49d17h2m47s295ms	TIME#10s, 10000
DATE	1970-01-01 to 2106-02-07	2000-12-31, DATE#2005-04-01
TOD	0:00:00 to 23:59:59	17:15:00, TOD#12:12:12
DT	1970-01-01 to 2106-02-07-6:28:15	2005-2-14-12:23:00, DT#2005-11-03-00:10:03
STRING	Impossible to input	-
WORD	H0000 to HFFFF	H1234
DWORD	H00000000 to HFFFFFFF	H12345678

Section 2 Menu Reference

2-5-7 Online- Break Point

The break point function is used to stop execution of the PLC under specified conditions. There are two types of break points: [Break point] and [Condition break point]. In SPH200/300, only one point can be set (either of the two types of break points). In SPH2000/3000, up to 32 points can be set (total of the two types of break points). After stopping the PLC, you can execute the program step by step using "Step Execute" function. You can also restart the program from the stop position.

To use the break point function, set the CPU key switch at TERM, and load the program to the PLC if it has been changed after connected online.

When you perform any of the following operations, the break point is canceled.

- Stopping the PLC (SPH300 only)
- Setting the CPU key switch to any position other than TERM
- Turning ON/OFF the CPU power or resetting the CPU

<Functions of break point>


Function		Specification	SPH200 /300	SPH2000 /3000
Multi-point breakpoint		Up to 32 points of break points can be set for one project.	X	✓
Logical concatenation of break stop condition		For one device, up to 4 points of break stop conditions by a specified value of data can be concatenated with AND or OR.	X	✓
Break point		After an instruction set as the breakpoint is executed.	✓	✓
Condition break point	Bit (BOOL) data match (=1, =0)	=1: When the specified bit (BOOL) data is turned ON =0: When the specified bit (BOOL) data is turned OFF	✓	✓ *
	Rising/falling edge of bit (BOOL) data	Rising edge: When the specified bit (BOOL) data is changed from OFF to ON. Falling edge: When the specified bit (BOOL) data is changed from ON to OFF.	✓	✓ *
	Data comparison match	When the specified data meets the specified conditions Comparison conditions (=, <>, <, >, <=, >=)	✓	✓ *
	Reading/writing to data (READ/WRITE)	After reading to the specified data After writing to the specified data	✓	X

* When a specified device is executed, a judgment on the condition is made.

Section 2 Menu Reference

<The buttons concerned with Break Point>

The buttons concerned with break points are shown below.





- [Break Point]:
This button is used to set a break point for the instruction at the cursor position.
- [Condition Break Point]:
This button is used to set a break point for the address at the cursor position with a condition.
- [Step Execute]:
This button is used to execute the program stopped by the break point step by step. FB contents are not executed step by step, but in a normal way.
- [Step in to function block]:
This button is used to execute the program stopped by the break point step by step. FB contents are also executed step by step.
- [Execute from the stopping direction]:
This button is used to restart the program stopped by the break point from the stop position.
- [Break point window]:
This button is used to open the "Breakpoints" window.

Section 2 Menu Reference

<Break Point>

A break point targets instruction positions. The cursor position at the time of execution of this function becomes a break point. The instruction specified as a break point changes its back color to pink to indicate the break point.

- ◆ Place the program window into a monitoring state and select a device to be set as a break point. Then, click [Online] > [Break point] > [Break point] to set a break point (the background color is pink.). Program execution will be stopped at the break point. (the background color is turned into yellow)




Section 2 Menu Reference

<Condition break point>

Devices that can be set as a trigger point is the I/O memory, standard memory, retain memory, system memory, user FB memory, and system FB memory (T, C, TR).


- ◆ Place the program window into a monitoring state and select a device to be set as a break point. Then, click [Online] menu > [Break point] > [Condition break point]. The following dialog box opens. Select a stop condition, and then click the [Set] button to set the condition break point.

<Bit (BOOL) data>




Select stop condition from the following:
=1, =0, rising or falling

<Word/double-word data>



Select stop condition from the following:
=, <, >, <=, or >=.
As comparable data, 10 digits, 16 digits, word address, or double word address shown on the list can be set .


You can check the registration status of break points on the "Breakpoints" window.



Section 2 Menu Reference

<Condition break point for SPH2000/3000>

In SPH2000/3000, when a device at the specified line position is executed and it is set as a stop condition, the execution is stopped. Even if there are many same devices (M0) as shown below, the break condition is that M0 is ON when the specified line position "Line Number 5 - 1" is executed.



Section 2 Menu Reference


<Logical concatenation of break points> (for SPH2000/3000 only)

In SPH2000/3000, up to four points of break stop conditions by a specified value of data can be concatenated with AND or OR for one variable.


<Concatenation setting example>

The following explains how to set a break condition to stop the program when the device "WM2" is 1000 or 2000<=WM2<=3000.


- ◆ First, set the condition of "WM50=1000", "WM50>=2000", and "WM50<=3000".




- ◆ Link "WM50>=2000" and "WM50<=3000" by AND condition.
Click "WM50>=2000" and "WM50<=3000" while pressing the <Ctrl> key. While selecting these two click the [AND] button.



- ◆ "WM50>=2000" and "WM50<=3000" are linked by AND condition.



- ◆ Link ("WM50>=2000" and "WM50<=3000") and "WM50=1000" by OR condition.
Click ("WM50>=2000" and "WM50<=3000") and "WM50=1000" while pressing the <Ctrl> key. While selecting these two, click the [OR] button.




Section 2 Menu Reference

- ◆ ("WM50>=2000" and "WM50<=3000") and "WM50=1000" are linked by OR condition. Check the box of this line.

Position	Condition
<input type="checkbox"/> Ladder1 Line Number 7 - 2	WM50 = 1000
<input type="checkbox"/> Ladder1 Line Number 7 - 2	WM50 >= 2000
<input checked="" type="checkbox"/> Ladder1 Line Number 7 - 2	WM50 <= 3000
<input type="checkbox"/> Ladder1 Line Number 7 - 2	(WM50 >= 2000 AND WM50 <= 3000)
<input checked="" type="checkbox"/> Ladder1 Line Number 7 - 2	(WM50 = 1000 OR (WM50 >= 2000 AND WM50 <= 3000))

- ◆ The following dialog box appears. Click the [Yes] button.





- ◆ The break point is set.

Position	Condition
<input type="checkbox"/> Ladder1 Line Number 7 - 2	WM50 = 1000
<input type="checkbox"/> Ladder1 Line Number 7 - 2	WM50 >= 2000
<input type="checkbox"/> Ladder1 Line Number 7 - 2	WM50 <= 3000
<input type="checkbox"/> Ladder1 Line Number 7 - 2	(WM50 >= 2000 AND WM50 <= 3000)
<input checked="" type="checkbox"/> Ladder1 Line Number 7 - 2	(WM50 = 1000 OR (WM50 >= 2000 AND WM50 <= 3000))

Section 2 Menu Reference

<Canceling break point>

To cancel a break point, uncheck the box on the "Breakpoints" window.





Section 2 Menu Reference

<Step Execute>

This function is used to execute a program in units of instructions, starting from the break point.

There are two types of step execute buttons.

-  [Step execute]: By clicking button, instructions of a program are executed one by one. When a user FB is on the step execute position, the FB contents are not executed one by one, but in a normal way.
-  [Step in to function block] : By clicking button, instructions of a program are executed one by one. When a user FB is on step execute position, the FB contents are also executed one by one.

<Execute from the stop position>

This function is used to restart execution of a program stopped by a break point from the stop position. The program restarts from the current condition.

When the break point is not canceled and the break condition is met, the program is stopped again.

Section 2 Menu Reference

2-5-8 Online - condition monitor

The condition monitor function is used to capture up to 512 points of devices based on the specified trigger point condition. Although the monitoring is stopped, the program continues working. Register an address to capture first, otherwise, condition monitor results cannot be displayed.

To use the condition monitor function, set the CPU key switch at TERM, and load the program to the PLC if it has been changed after connected online.

When you perform any of the following operations, the condition monitor is canceled.

- Setting the CPU key switch to any position other than TERM
- Turning ON/OFF the CPU power or resetting the CPU
- Stopping the monitoring.
- Switching between working and standby CPUs.

<Available monitoring stop conditions>


Function		Specification	SPH200 /300	SPH2000 /3000
Multi-point condition monitoring stop		For one project, up to 32 points of condition monitoring stop points can be specified.	X	✓
Logical concatenation of monitoring stop conditions		For one device, up to 4 points of monitoring stop conditions by a specified value of data can be concatenated with AND or OR.	X	✓
Monitoring stop condition	Program address stop	After an instruction set as the breakpoint is executed.	X	✓
	Bit (BOOL) data match (=1, =0)	=1: When the specified bit (BOOL) data is turned ON =0: When the specified bit (BOOL) data is turned OFF	X	✓ *
	Rising/falling edge of bit (BOOL) data	Rising edge: When the specified bit (BOOL) data is changed from OFF to ON. Falling edge: When the specified bit (BOOL) data is changed from ON to OFF.	✓	✓ *
	Data comparison match	When the specified data meets the specified conditions Comparison conditions (=, <>, <, >, <=, >=)	X	✓ *

* When a specified device is executed, a judgment on the condition is made.

Section 2 Menu Reference

<The buttons concerned with condition monitor>

The buttons concerned with condition monitor are shown below.



- [Execute condition monitor]:
This button is used to execute condition monitor.
- [Finish condition monitor]:
This button is used to exit from condition monitor.
- [Stop on the cursor position]:
This button is used to set a trigger of condition monitor at the cursor position.
- [Condition stop]:
This button is used to set a condition for the address at the cursor position and stop by the condition.
- [Monitor device registration]:
This button is used to register a device to monitor during the condition stop.
- [Condition monitor window]:
This button is used to open the "Condition Monitor" window.

Follow the procedure below to execute condition monitor.


- 1) Monitor device registration
- 2) Trigger setting (Finish on the cursor position, or condition stop)
- 3) Condition monitor execution

Section 2 Menu Reference

<Monitor device registration>

Up to 512 points of devices can be registered.

- ◆ Place the program window into a monitoring state and select a device to register.
Click [Online] menu > [Condition monitor] > [Register device], and then the monitor device is registered.



The screenshot shows a software window titled "Condition Monitor" with a standard Windows-style title bar (minimize, maximize, close buttons). Below the title bar is a toolbar with several icons. The main area of the window is divided into two tabs: "Trigger Point" and "Monitor Device". The "Monitor Device" tab is active and contains a table with two columns: "Variable" and "Instance". The table lists four registered devices, each with a checked checkbox in the "Variable" column.


Variable	Instance
<input checked="" type="checkbox"/> DM22	RESOURCE:DEFAULT:Ladder2
<input checked="" type="checkbox"/> M20	RESOURCE:DEFAULT:Ladder2
<input checked="" type="checkbox"/> WM40	RESOURCE:DEFAULT:Ladder2
<input checked="" type="checkbox"/> WM50	RESOURCE:DEFAULT:Ladder2

Section 2 Menu Reference

<Stop on the cursor position>

This button is used to make settings so that the monitoring is stopped when the instruction at the cursor position is executed.

- ◆ Place the program window into a monitoring state and select a device to stop monitoring.
Click [Online] > [Condition monitor] > [Trigger setting] > [Cursor Position Stop]. The monitor stop device is set.




Section 2 Menu Reference

<Condition Stop>

The device which can be set as condition stop is I/O memory, standard memory, retain memory, system memory, user FB memory, and system FB memory (T, C, TR).


- ◆ Place the program window into a monitoring state and select a device to stop monitoring.
Click [Online] menu > [Condition monitor] > [Trigger setting] > [Condition stop]. Then, the condition stop is set.

<Bit (BOOL) data>




Select stop condition from following:
=1, =0, rising or falling

<Word/double-word data>



Select stop condition from the following:
=, <>, <, >, <= or >=
As comparable data, 10 digits, 16 digits, word address, or double-word address shown on the list can be set .

You can check the registration status of condition stop on the "Breakpoints" window.




* With SPH2000/3000, up to 32 trigger points can be specified. In addition, as with break points, up to 4 triggers can be logically connected for one device. Follow the same procedure used for break points.

Section 2 Menu Reference

<Condition monitor execution>

- ◆ Place the program window into a monitoring state, and then click [Online] menu > [Condition monitor] > [Condition monitor execute]. The condition monitor is set on waiting for a trigger. When the trigger is approved, the monitoring is stopped.



The bar is displayed in purple.

"Condition monitor [Hold]" is displayed on the status bar.

- * When the monitoring is stopped, the status (ON/OFF, device data) of the devices registered for condition monitor is only shown. The status of other devices is not displayed.

Section 2 Menu Reference

<Condition monitor stop>

- ◆ While the condition monitor is working, to finish the condition monitor and return to the normal monitor, click [Online] menu > [Condition monitor] > [Terminate condition monitor].

Section 2 Menu Reference

2-5-9 Online - Sampling Trace

This function is used to sample and display the status of a specified device (memory address).

Note: The sampling trace function is supported by the following CPUs.

NP1PS-117, NP1PS-117R and NP1PS-74R: software version V61 or later

NP1PS-245R: software version V64 or later

SPH2000/3000: all versions

<Devices for sampling trace>

The following device can be specified as a sampling device.

	Bit	Word	Double word
Input memory	X	WX	DX
Output memory	Y	WY	DY
Non-retain memory	M	WM	DM
Retain memory	L	WL	DL
System memory	SM	WSM	DSM
Timer	T	–	T
Counter	C	C	–

<Number of points which can be registered>


Up to 32 points of devices can be registered for sampling trace, counting a bit, a word, and a double word as one point.

<Operating procedure>

(1) To register sampling device

◆ Click [Online] menu > [Sampling trace] > [Sampling trace]. The [Sampling trace] dialog box opens.


First, specify a device for the sampling trace. Right-click on the area surrounded by a dashed line shown below, and select [Add sample target].




* The devices M, L, and SM can be registered on this dialog box. For other devices, X, Y, T, and C, refer to <Registration procedure during online monitor> explained below.

Section 2 Menu Reference

- ◆ The address entry box is displayed on the bottom. Enter a device address to sample, and press the <Enter> key. Then, the tag entry box appears. Enter a tag name, and press the <Enter> key. (The tag name is optional.) This tag is different from the tag entered on a program and used only for sampling trace. The list to select the data type appears. Select the data type and press the <Enter> key.



- ◆ The device for sampling trace is registered. Following the above procedure, add and register other devices for sampling as many as you need.



* When you trigger sampling trace by the status change of a device, also register the device. When using a manual trigger, the registration is not necessary.


Section 2 Menu Reference

<Notes on registration of a sampling trace device>

The devices M, L, and SM can be registered even offline. You need to register other devices, X, Y, T, and C during online monitor. In addition, the address of the device must be used by a program. Registration procedure during online monitor is explained below.

<Registration procedure during online monitor>


- ◆ Place the cursor on a device to register as a sampling trace during online monitor, right-click on it, and then select "Register Device to Sampling Trace" from the menu.



Section 2 Menu Reference

(2) Trigger condition setting

- ◆ Check a device to set for trigger condition. Check "Trigger condition" and select a device address and condition from the list. (This setting is not necessary when using a manual trigger)



Only one trigger condition can be set.

With SPH2000/3000, up to 4 points of conditions can be combined by AND, OR condition.

Section 2 Menu Reference

<Trigger conditions>

Function		Specification	SPH300	SPH2000 /3000
Logical concatenation of trigger conditions		For one device, up to 4 points of sampling start conditions by a specified value of data can be concatenated with AND or OR.	X	✓
Trigger condition	Bit (BOOL) data match (=1, =0)	=1: When the specified bit (BOOL) data is turned ON =0: When the specified bit (BOOL) data is turned OFF	✓	✓
	Rising/falling edge of bit (BOOL) data	Rising edge: When the specified bit (BOOL) data is changed from OFF to ON. Falling edge: When the specified bit (BOOL) data is changed from ON to OFF.	✓	✓
	Data comparison match	When the specified data meets the specified conditions Comparison conditions (=, <>, <, >, <=, >=)	✓	✓

<Comparison data>

When the trigger condition is specified only with a comparison operational expression (only with word/double-word data), set a comparison data in the comparison data field based on the following table.

Data type	Input range	Input example	Display example after input
BIT (BOOL)	0,1	Cannot be input.	–
INT	-32768 to 32767	INT#123, 123	INT#123 (INT# is prefixed.)
DINT	-2147483648 to 2147483647	DINT#100, 100	DINT#1000 (DINT# is prefixed.)
UINT	0 to 65535	UINT#1000, 1000	UINT#1000 (UINT# is prefixed.)
UDINT	0 to 4294967295	UDINT#1000, 1000	UDINT#1000 (UDINT# is prefixed.)
REAL	Single-precision floating decimal point	REAL#10, 10.0, 1.3E-05	10.0, 1.3E-05 (REAL# is omitted.)
TIME	0ms to 49d17h2m47s295ms (4294967295ms)	TIME#10s, 10s, 1s500ms, 10000ms	10000ms (All values are expressed in millisecond.)
DATE	01-01-1970 to 02-07-2106	DATE#2003-2-1, 2003-02-14	2003-02-14 (DATE# is omitted.)
TOD	0:00:00 to 23:59:59	TOD#17:00:00, 17:00:00	17:00:00 (TOD# is omitted.)
DT	01-01-1970 0:00:00 to 02-07-2106 6:28:15	DT#2003-02-09-4:00:00, 2003-02-09-04:00:00	2003-02-09-4:00:00 (DT# is omitted.)
STRING	–	Cannot be input.	–
WORD	0000 to FFFF	H0000, H1234, HABCD, 0, 1234, ABCD	ABCD (H is omitted.)
DWORD	00000000 to FFFFFFFF	H00000000, H12345678, HABCDEF10, 0, 12345678, ABCDEF10	ABCDEF10 (H is omitted.)


* Input values are automatically changed depending on the data type as shown in "Display example after input" in the list above.

Section 2 Menu Reference


<How to cancel trigger condition>

To cancel a trigger condition, follow the procedure below.

- ◆ Select a blank from the address list of Trigger condition.




- ◆ Uncheck the box.



Section 2 Menu Reference

- ◆ The trigger is canceled.




Section 2 Menu Reference


<How to set multi-point trigger condition>

You can set multiple trigger conditions and trigger by combination of AND, OR condition. This is called multi-trigger. Only SPH2000/3000 support this function.

- ◆ Check the address to set for the target of multi-point trigger. Check "Data condition," and click the [Advanced] button.




- ◆ The "Advanced setting" dialog box opens. Select a trigger condition and "Linkage logic" (AND/OR), and then click the [OK] button.



Section 2 Menu Reference


- ◆ The multi-point trigger condition is set.



Section 2 Menu Reference

(3) Trace condition setting

Set the sample timing, total number of samples, and trigger points as trace conditions.



<Sampled when: the sample timing>

- [Scan end]: Sampling is performed when every scanning (default task) is done.
- [Period of]: Sampling is performed in the set cycle. The setting range is 1 to 32000ms (0.5ms * N), and you can specify the value that is an integral multiple of SX bus takt.

<Total sample number: total number of samples>

Set the total number of samples. A value equal to or greater than 3 in the range displayed on the right can be set. The value displayed on the right changes depending on the number of sampling devices.

<Trigger point>


Move the slide bar horizontally to set a trigger point. The value displayed on the screen is the sampling data number to download before operating trigger. When using a manual trigger, this setting is disabled. (The trigger point is fixed to 0.)

Section 2 Menu Reference


(4) Sampling trace execution

<Manual trigger>

- ◆ Click the [Connect the PLC] button, and then the [Manual trigger] button.




- ◆ The message saying "Triggered !" appears, and sampling starts.




Section 2 Menu Reference

- ◆ When the sampling is done, the message changes to "Reading." Reading of sampling data is started.




- ◆ When the reading of sampling data is done, the message changes to "Online." Sampling data is shown as a graph.




Section 2 Menu Reference

<Condition trigger>

- ◆ Click the [Connect the PLC] button, and then the [Execute] button.



- ◆ The message saying "Waiting to be triggered" appears.



Section 2 Menu Reference

- ◆ When the trigger condition is approved, the message saying "Triggered !" appears. Sampling is started.

The screenshot shows the 'Sampling Trace' window for '48E_Data10.swfa'. The window title is 'Sampling Trace [48E_Data10.swfa]'. The top right corner shows 'NP1PM-48E' and a yellow status bar with 'Triggered!' and a green progress indicator. The main area is a grid with a blue sawtooth waveform. The left sidebar shows a table of data samples:

Name of data	Date and time
<input type="checkbox"/> Sample-1	2009/08/12 16:25:29
<input type="checkbox"/> Sample-2	2009/08/12 16:26:22

The 'Sample target' table is also visible:

Sample target	Data type
<input checked="" type="checkbox"/> DM2	DINT
<input checked="" type="checkbox"/> M40	BOOL
<input type="checkbox"/> Y3.0	BOOL
<input checked="" type="checkbox"/> C0	INT
<input checked="" type="checkbox"/> M50	BOOL

The bottom control panel includes 'Sampling settings' and 'Graph view settings'. Under 'Sampling settings', 'Trigger condition' is checked, 'M50' is selected, and 'Rising Edg' is chosen. The 'Total sample number' is 3276, and the 'Trigger point' is 1650. Buttons for 'Connect the PLC', 'Execute', 'Manual trigger', and 'Reset' are present.

- ◆ When the sampling is done, the message changes to "Reading." Reading of sampling data is started.

The screenshot shows the 'Sampling Trace' window in the 'Reading...' state. The status bar now displays 'Reading...' with a green progress indicator. The blue sawtooth waveform is still visible on the grid. The interface elements, including the data tables and control panel, are identical to the previous screenshot.

Section 2 Menu Reference

- ◆ When the reading of sampling data is done, the message changes to "Online," and the sampling data is shown as a graph.

The screenshot displays the 'Sampling Trace' window for 'NP1PM-48E'. The interface is divided into several sections:

- Top Left:** A table listing sampled data points.
- Top Center:** A 'Sample target' table with checkboxes for various variables.
- Top Right:** A graph showing the sampled data points over time. A vertical red dashed line indicates the current sampling point.
- Bottom Left:** 'Sampling settings' including a 'Trigger condition' set to 'M50' with a 'Rising Edg' trigger.
- Bottom Center:** 'Sampled when' options for 'Scan end' and 'Period of'.
- Bottom Right:** 'Total sample number' set to 3276, and control buttons like 'Connect the PLC', 'Execute', 'Manual trigger', and 'Reset'.

Name of data	Date and time
<input type="checkbox"/> Sample-1	2009/08/12 16:25:29
<input type="checkbox"/> Sample-2	2009/08/12 16:26:22
<input type="checkbox"/> Sample-3	2009/08/12 16:30:14

Sample target	Data type
<input checked="" type="checkbox"/> DM2	DINT
<input checked="" type="checkbox"/> M40	BOOL
<input type="checkbox"/> Y3.0	BOOL
<input checked="" type="checkbox"/> C0	INT
<input checked="" type="checkbox"/> M50	BOOL

Total sample count: 3 <= 50

Address:

Sampling settings: Trigger condition (Advanced) | M50 | Rising Edg

Sampled when: Scan end | Period of: ms


Total sample number: 3276 <= 3276 | Trigger point: 1 | 1650

Buttons: Connect the PLC, Execute, Manual trigger, Reset, Comm. settings


Section 2 Menu Reference

(5) Displaying the result of a sampling trace

The screen displaying the result of a sampling trace is as follows.



<Saving data Icons>



- [New]: This button is used to clear a sampling trace setting and a data list of sampling.
- [Open]: This button is used to open a file saved by "Save" or "Create setting file." (Either file is Extension. swfa)
- [Save]: This button is used to save the data of sampling data list, and the setting of sampling trace. (Extension. swfa)
- [Create setting file]: This button is used to save the setting of sampling trace.


<Sampling data list>

Every time when sampling trace is completed, temporary data is created. This data can be created up to 50. When exceeding 50, sampling trace cannot be done. To avoid that, delete it by using the key as needed.

Section 2 Menu Reference

<Save sampling data as csv>


Sampling data can be saved as csv. Check data to save as csv in the sampling data list, right-click it, and then select "Export as CSV file" from the menu.



Section 2 Menu Reference

<Graph view settings>

Click the [Graph view settings] tab. The "graph view settings" screen is displayed. Click the device to change settings. To show or hide the graph, check or uncheck the box of the device.



"Zero level check" icon
 "Default" icon

- [Vertical]: You can adjust the fineness of scale on the vertical axis and specify the color of the graph.
- [Horizontal]: You can adjust the fineness of the scale on the horizontal axis.
- [Cursor]: Move the vertical cursor on the graph and click the [Measure] button. The value of the coordinate is displayed.

Section 2 Menu Reference


2-5-10 Online - Program Operation

This command is used to select and perform one or more programs assigned in one resource (CPU module). Debugging work can be done for each program using this function.

Note: The program operation function cannot be used during execution of other test functions (break point, step execution, condition monitor). However, other test functions can be used after execution of the program operation function.

Before using this function, execute [Online] menu > [Monitor] to place the program window into a monitoring state.

- ◆ Click [Online] menu > [Program operation]. The [Program Operation] dialog box opens. The programs whose box is checked are valid. Uncheck the box of the program to be invalid, and click the [OK] button.




Note: The invalid program is canceled when the power of the CPU module is reset (OFF to ON). All programs become valid, and all programs assigned to the resource start to work.

Section 2 Menu Reference

2-5-11 Online - Task execution time measurement

This command is used to display the execution time of all working tasks, and the current/minimum/maximum value of the execution cycle. (Unit: μ s)



ES0/ES1	TaskName	TaskType	Current Time	Min Time	Max Time	Current Cycle	Min Cycle	Max Cycle
-	Default	Default	27	26	93	1000	975	1026

Current time / Min time / Max time: These are the execution times of the program.

Current cycle / Min cycle / Max cycle: These are the cycles where the program is performed. The program is executed in synchronization with the bus tact; It is same as scan time.


The target of Min time, Max time, Min cycle, and Max cycle is a period from the execution of "task execution time measurement" to the present.

Section 2 Menu Reference


2-5-12 Online - Data monitor

This command is used to monitor PLC devices.


- ◆ Click [Online] menu > [Data monitor] > [Data monitor 1]. The data monitor screen opens.
- * Up to four data monitor screens can be opened: Data Monitor 1 to 4



- ◆ Place the cursor on the address row, enter [X1.0], and then press the <Enter> key. The status of X1.0 is displayed. (A value of 0 indicates ON; a value of 1 indicates OFF.)














- ◆ Enter an addresses to monitor by following the above procedure.



- * The following addresses can be monitored. Check the status of timers and counters on the program screen.
 - Bit address: X, Y, M, L, SM, S, ENO
 - Word address: WX, WY, WM, WL, WSM, WS
 - Double word address: DX, DY, DM, DL, DSM

Section 2 Menu Reference

Icons on the data monitor screen

-  [Display next address]: Displays an address added +1 to the address below the cursor.
-  [Display data fill]: Displays continuous addresses starting from the address below the cursor.
-  [Clear data]: Deletes an address below the cursor.
-  [Clear all data]: Deletes all displayed addresses.
-  [Bit ON]: Executes Overwrite ON for bit.
-  [Bit OFF]: Executes Overwrite OFF for bit.
-  [Force ON]: Executes Force ON for bit. The target is the area of X, Y.
-  [Force OFF]: Executes Force OFF for bit. The target is the area of X, Y.
-  [Force reset]: Resets Force ON/OFF.
-  [Force setting detail]: Displays the status of Force ON/OFF as a list.
-  [Save data display setting]: Saves data display setting specified by the user.

Section 2 Menu Reference

2-6 Conversion menu

The "Conversion" menu contains the following commands:

- Conversion ⇒ Converts only the changed part of a program. The conversion time is short compared with that "Conversion All" command. Use this command to make the conversion time shorter when you make a small program change to a program.
- Conversion All ⇒ Converts the whole program. Usually use this command.
 - * Do not use the "Conversion" and "Conversion All" commands when you change a program online. If you execute either, a machine code (code for PLC operation) is created.
- Program Check ⇒ Checks the syntax of the whole program. No machine code is created. Use this command to check the syntax of a program before changing it online.
- ST Syntax Check ⇒ Checks only the syntax of a program created in ST language.

Section 2 Menu Reference

2-6-1 Conversion menu - Conversion / Conversion All


These commands are used to convert programs.

The syntax of a program and the consistency of I/O and addresses set in the system definition are checked, and then program data to load to the PLC (machine code) is created. Make sure to execute "Conversion" or "Conversion All" before loading a program to the PLC.

- ◆ Click [Conversion] menu > [Conversion] or [Conversion All]. The program is converted. Whether the conversion is completed normally is indicated in the status bar on the bottom of the screen.

<When conversion is normally completed>

When the status bar shows "Error : 0," the conversion is normally completed. If warning is not 0, see the contents of the warning and check whether the system has any problem.



When the conversion is normally completed, information on the program such as program steps, the number of timers/counters used can be checked on the "Information" window. (If the conversion is failed, this window does not appear.)

Resource	Program Name	Program Type	Step	User FB	Edge	Counter	Timer	Add up timer	Other FB	Instance nests
	Ladder0	Program	39 step	0	0	0	1	0	0	-
	Ladder1	Program	41 step	0	0	0	1	0	0	-
Total		Program : 2	80 step	0	0	0	2	0	0	0
		Function block : 0								
		Function : 0								

<When conversion is abnormally completed>

If the program has some errors, the "Error" window appears as shown below. The program cannot be converted and needs to be corrected. Double-click the row of the explanation part, and the corresponding line is displayed.


Type	Explanation	Program Name	Circuit No./Line No.	Device No.
✖	"X3.0" is address out of range.Please confirm the IO constitution of the system definition.	Ladder0	1	1
✖	"Y2.12" is address out of range.Please confirm the IO constitution of the system definition.	Ladder0	3	6

The screenshot also shows the status bar at the bottom left with 'Error : 2, Warning : 0' in a red box, and '0.1K' in the status bar.

Section 2 Menu Reference

2-6-2 Conversion menu - ST Syntax Check

This command is used to check the syntax of a program created in ST language. An active program is checked.



2-6-3 Conversion menu - Program Check

This command is used to check the syntax of the whole program. No machine code is created. Use this command to check the syntax of a program before changing it online. ST syntax is also checked.

Section 2 Menu Reference

2-7 Tools menu

The "Tools" menu contains the following commands:


- User ROM utility ⇒ Initializes a user ROM (CF/SD card), or reads and writes a program.
- Address Assignment ⇒ Creates the address conversion rule to convert a program for MICREX-F or FLEX-PC to SX.
- SX Control Utility ⇒ Starts SX Control Utility software.
- Shortcut key ⇒ Changes the assignment of shortcut keys.
- Customize Instruction Jog ⇒ Changes the Instruction Jog.
- Options ⇒ Makes optional settings about the loader software operation.

Section 2 Menu Reference

2-7-1 Tools menu – User ROM Utility

This command is used to initialize a user ROM (CF card), or read and write a program. Connect a user ROM to the computer using a commercial card reader and writer.

◆ Click [Tool] menu > [User ROM utility]. The following dialog box opens.



Operation items of a user ROM are as follows:


- Load to User ROM: Transfers a program from the loader to a user ROM.
- Load from User ROM: Transfers a program from a user ROM to the loader
- Verify with User ROM: Compares the currently open program with a program in a user ROM.
- Maintenance: Initializes a user ROM.
- Security: Sets a password on a user ROM

Section 2 Menu Reference


(1) Download to User ROM

This function transfers a program from the loader to a user ROM.

- ◆ Check items to download (usually check all items.), select a drive to download (a drive to which the user ROM is assigned), and then click the [Load to User ROM] button.



- ◆ The confirmation dialog box appears. Click the [OK] button.



- ◆ The dialog box showing download completion appears. Click the [OK] button.




*Only one program can be saved in a user ROM.

Section 2 Menu Reference


(2) Load from User ROM

This function transfers a program saved in the user ROM to the loader.


Select the transfer source drive (the drive to which the use ROM is assigned), and then click the [Load from User ROM] button.



- ◆ The confirmation dialog box appears. Click the [OK] button.



- ◆ The dialog box showing loading completion appears. Click the [OK] button.




Section 2 Menu Reference


(3) Verify with User ROM

This function compares a loader program with a program of a user ROM.

- ◆ Check items (usually check all items.) to verify, select the drive of the use ROM (the driver to which the user ROM is assigned), and then click the [Verify with User ROM] button.



- ◆ The confirmation dialog box appears. Click the [OK] button.



- ◆ The verification result is displayed.


State	Data Type	Current Project	Project User ROM	
✓ Common	System Definition	System Structure Definition	System Structure Definition	
✓ Common	System Definition	System Running Definition	System Running Definition	
✓ Common	System Definition	System Digital Output Setting	System Digital Output Setting	
✓ Common	System Definition	CPU Running Definition	CPU Running Definition	
✓ Common	System Definition	CPU Memory Border Definition	CPU Memory Border Definition	
✓ Common	System Definition	SRM Band Ratio Definition	SRM Band Ratio Definition	
✓ Common	System Definition	CPU Running Definition 2	CPU Running Definition 2	
✓ Common	System Definition	I/O Group Definition 1	I/O Group Definition 1	
✓ Common	System Definition	I/O Group Definition 2	I/O Group Definition 2	
✓ Common	System Definition	I/O Group Definition 3	I/O Group Definition 3	
✓ Common	System Definition	Direct I/O Fail-Soft Operation Setting	Direct I/O Fail-Soft Operation Setting	
✓ Common	System Definition	Remote I/O Master 0 Fail-Soft Operation Setting	Remote I/O Master 0 Fail-Soft Operation Setting	
✓ Common	System Definition	Ethernet Definition	Ethernet Definition	
✓ Common	System Definition	Direct I/O HOLD Definition	Direct I/O HOLD Definition	
✓ Common	System Definition	Direct I/O Running Mode	Direct I/O Running Mode	
✓ Common	System Definition	Remort I/O Master 0 Running Definition	Remort I/O Master 0 Running Definition	
✓ Common	Project	Project1	User ROM	More >>
! Modified	Task	DEFAULT : Default	Default : Default	More >>
! Modified	Program: (0)	PG00000	Ladder0	More >>
! Modified	Circuit	PG00000 - 2	Ladder0 - 2	More >>
! Modified	FB Instance	Address Allocation	Address Allocation	

The verification result is classified by color.

- White : Common
- Orange : Modified
- Gray : Not exist

Section 2 Menu Reference

Explanation of Icons




Icon	Explanation
System Definition	Used to show/hide "System definition" in the "Data Type" column.
Programs	Used to show/hide "Circuit" in the "Data Type" column.
Common	Used to show/hide "Common" in the "State" column.
Modify	Used to show/hide "Modified" in the "State" column.
Filter line strings	Used to enter a filter keyword.
Filter	Enter a filter keyword, and then click this button to filter the list. Only the items that includes the entered keyword are shown. Click this button again to cancel the filter.
Update the latest status	Used to verify one more time

* To check mismatched lines, follow the same procedure as in project verification. Refer to "2-4-5 Project Menu - Verify" for more details.

Section 2 Menu Reference

(4) Maintenance

This function formats a user ROM, clears projects in the user ROM and sets a password. Select the drive of the user ROM and click the operation item button.





(4)-1 Format

This function formats the user ROM. When you execute formatting, the contents in the user ROM are deleted all, and the CPU creates a folder and file to recognize programs.


* When using SPH300 software version earlier than V59, the OS of the computer used for formatting must be Windows 2000. A user ROM formatted by Windows XP or Vista computer cannot be recognized.

- ◆ Select the drive of the user ROM (the drive to which the user ROM is assigned), and then click the [Format] button. The warning dialog box appears. Confirm the contents and click the [OK] button to proceed to the next screen.




Section 2 Menu Reference

- ◆ The "Format" dialog box appears. Confirm the contents and click the [Start] button to proceed to the next screen.




When using SPH 300, select "FAT" for File system.

- ◆ The warning message appears. Confirm the contents and click the [OK] button to start formatting.



- ◆ When the formatting is completed, the following dialog box appears.




Section 2 Menu Reference


(4)-2 Clear

This function clears a program saved in a user ROM.

- ◆ Select the items to clear, and click the [Clear] button.



- ◆ When the program is cleared, the following dialog box appears.




Section 2 Menu Reference

(4)-3 Password


This function sets a password on a user ROM. If a password is set, the password is required to access to the user ROM. (The password is not required to format the user ROM. If the user ROM is formatted, both the program and password are cleared.)

<New registration of password>

- ◆ Click the [Registration] button on the following dialog box.




- ◆ The password entry dialog box appears. Enter a password, and then click the [OK] button.



* The password must be between 6 and 32 alphanumeric characters and symbols (+, -, =, /).

- ◆ The password is set.




Section 2 Menu Reference

<Entering the password>

To access (read/write/verify/clear/set as Read only) the user ROM where a password is set, you need to enter the password in the following dialog box.

◆ Enter the password in the following dialog box, and then click the "[OK] button.



* If you enter a wrong password and try to access to the user ROM, the following message appears.




Section 2 Menu Reference

<Changing the password>

This function changes the password registered for the user ROM to new one.

- ◆ Enter the registered password and a new password, and then click the [OK] button.



A dialog box titled "Change" with a close button (X) in the top right corner. It contains three input fields, each with a label and a masked password field (*****):

- Input password registered already: *****
- Input new password: *****
- Check and input new password: *****

Below the input fields is a note: "* Input password with 6 - 32 characters." At the bottom right are two buttons: "OK" and "Cancel".

- ◆ The password is changed.




Section 2 Menu Reference


<Canceling the password>

This function cancels the password registered for the user ROM.

- ◆ Click the [Cancel] button on the following dialog box.



- ◆ The password entry dialog box appears. Enter the password, and click [OK].



- ◆ The password is canceled.




Section 2 Menu Reference



(5) Security

This function sets read only for the user ROM.

- ◆ Select the drive of the user ROM (the drive to which the user ROM is assigned), and check "Read only." The dialog box to set a password appears. Enter a password, and then click the [OK] button.





* The password must be between 6 and 32 alphanumeric characters and symbols (+, -, =, /).



Even when "Read only" is set, data writing by application program (F_WRITE) is permitted by checking this box.

Section 2 Menu Reference

To permit writing to the user ROM, uncheck "Read only," and cancel the password.



Section 2 Menu Reference

2-7-2 Tools menu - Address Assignment

This command is used to define the address assignment rule to convert MICREX-F or FLEX-PC programs. For more details, refer to the user's manual "Replacement Manual MICREX-F to MICREX-SX <Convert> (FEH038)."

Section 2 Menu Reference

2-7-3 Tools menu - SX Control Utility

This command is used to start the SX Control Utility software. For more details, refer to Appendix 1.

Section 2 Menu Reference

2-7-4 Tool Menu- Shortcut key

You can customize shortcut keys that are assigned to each menu of the loader. For the shortcut keys, the combinations as shown below can be used.

(None)	F11
Shift	Ins, Del
Ctrl	A to Z, F1 to F3, F5, F7 to F12, Ins, Del, -
Alt	A to Z, F1 to F3, F5, F7 to F12, Ins, Del, -
Ctrl + Alt	A to Z, F1 to F12
Ctrl + Shift	A to Z, F1 to F12


* When the shortcut key you select has been already assigned to a function, and if you assign the key to another function, the originally assigned function has no shortcut key function.

Section 2 Menu Reference


<Setting a shortcut key>

Set a shortcut key following the procedure below.


- ◆ Select a command to register from the "Command" list.



- ◆ Select a "control key" to use, select a shortcut key from the list, and then click the [Apply] button.





- ◆ A shortcut key is set.



Section 2 Menu Reference

<Deleting a shortcut key>


To delete a shortcut key, select a command, and then click the key.



Section 2 Menu Reference

<Saving/reading a shortcut key>

This function is used to save the shortcut key setting as a file or read the saved setting.



* Shortcut key settings saved by Standard loader V2 cannot be used in Standard loader V3.

Section 2 Menu Reference

The table below shows the predetermined shortcut keys.


Function	Shortcut Key
New Project	Ctrl + N
Open	Ctrl + O
Save	Ctrl + S
Print	Ctrl + P
Undo	Ctrl + Z
Redo	Ctrl + Y
Cut	Ctrl + X
Copy	Ctrl + C
Paste	Ctrl + V
Find	Ctrl + F
Find Output Device	Ctrl + Alt + F
Insert Row	Shift + Ins
Delete Row	Shift + Del
Insert Column	Ctrl + Ins
Delete Column	Ctrl + Del
Project View	Ctrl + F1
Find Result	Ctrl + F2
Cross Reference Window	Ctrl + F3
Output Window	Ctrl + F5
Error Window	Ctrl + F7
Information Window	Ctrl + F8
Make Cross Reference	Ctrl + R
Trace Back Cross Reference	Ctrl + -
Trace Forward Cross Reference	Ctrl + Shift + -
PLC Operation	Ctrl + F10
Monitor	Ctrl + M
Data Modify	Alt + D
Forcible On/Off	Alt + S
Forcible Reset	Alt + R
Breakpoints Window	Ctrl + F9
Sampling Trace	Ctrl + T
Task Execution Time Measurement	Ctrl + E
Conversion	F11
Syntax Check	Ctrl + F11

Section 2 Menu Reference

2-7-5 Tool Menu- Customize Instruction Jog

This command is used to customize the "Instruction Jog" bar.

◆ Click [Tools] > [Customize Instruction Jog]. The following dialog box opens.




- Up: Selected group moves up.
- Down: Selected group moves down.
- Add Row: New group is added.
- Delete Row : Selected group deleted.
- Apply: Selected instruction is applied. Alternatively, you can select instruction and double-click it.
- Delete: Selected instruction is deleted. Alternatively, you can select instruction and press the [Del] key.
- Branch: Contact or Coil instruction is changed with branch (OR).
- Default: Goes back to the default setting.


Section 2 Menu Reference

<How to make new group>

- ◆ Click the [Add Row] button. A new group is added. Enter a group name.




- ◆ Assign [R_READ] to [F2] key. Select [R_READ] from the Instruction list, and double-click it or click the [Apply] button. [R_READ] is assigned to the [F2] key.



Section 2 Menu Reference

◆ Using the same procedure, assign other function keys.



* Default Group name and function key setting can also be changed.

Section 2 Menu Reference


2-7-6 Tools - Option

This command executes the option settings of the loader shown below.

- General ⇒ Makes the general settings of the loader.
- Directories ⇒ Sets the folder to open by default.
- Project ⇒ Makes the setting about projects.
- Online ⇒ Sets online operations.
- Conversion ⇒ Sets operations of conversion.
- Backup ⇒ Sets backup operations.
- System Definition ⇒ Sets operations for system definition registration

(1) General

You can make general settings of the loader.




- Language:
You can change the language of the loader. Choose Japanese or English.
- Address display mode:
If MICREX-F is selected, word addresses are expressed in decimal.
If FLEX-PC is selected, word addresses are expressed in hexadecimal.
- Last project is opened at the time of starting:
If this option is checked, the last opened project is opened when the loader is started.
- Reset the window layout:
The following items of the window layout are initialized.
Sub window size and layout in the main window.
Tool bar layout

Section 2 Menu Reference

(2) Directory


You can make settings of the file to open by default.




Section 2 Menu Reference

(3) Project

You can make settings of projects.




- Hide protected programs on the project view:
Check this option to hide protected programs (where a password is set by executing [Project] Menu > [Security] > [Protection Programs])
- Support non compressed project file:
Usually, a project is saved as a compressed type file (*.Zpj3). If this option is checked, you can also choose non compressed type (*.Spj3 file and folders) when saving a project.
When you use a PID expansion FB and set parameters, you need to choose non compressed type.
- Hide program name in the caption:
Choose whether or not to display a program name in the caption.



Section 2 Menu Reference

(4) Online


You can make settings of online operations.



- Show the failure analysis automatically:
When you open the failure diagnosis window, the failure analysis screen automatically opens if the PLC detects an error. Only SPH300 supports this function.
- Permit the use of Initial Run:
"Initial Run" of the "PLC operation" command is enabled. Note that the retain memory is cleared when "Initial Run" is executed.
- Verify before the monitor is started:
Before monitoring the PLC, the loader program is compared with the PLC program.
- Allow editing of being monitored:
A program can be edited during the monitoring. Instead, force setting operation of contacts and coils that can be made by double-click is disabled. To make force setting, use the right-click menu.
- Monitor is started automatically after load program:
After a program is loaded (all program transfer), monitoring is automatically started.
- Permit load to PLC only the program:
When a program is loaded to the PLC, the program and system definition are usually loaded in combination. If this option is checked, only a program can be loaded. When you change the system definition, make sure to load both the program and system definition.
- Show the confirmation before download to PLC:
When [Load the changed program into PLC] is executed, the confirmation dialog is shown.
- Permit to download Zip file:
When [Load the changed program into PLC] is executed, a Zip file (tag and program name information) is also loaded to the PLC.

Section 2 Menu Reference


- Restore the project name based on the Zip file:
Select whether or not to read the project name when a program is read from the PLC.



- Automatic import of the Ex. FB:
When standard expansion FBs or CSV interface FBs are used in the PLC or user ROM card, select whether or not to import them automatically.
 - [Don't import automatically]: Import is not performed automatically.
 - [Import automatically]: The import confirmation message is shown, and then import is performed automatically.
 - [Import without a confirmation message automatically]: Import is performed automatically without a confirmation message.

(5) Conversion

You can make setting of conversion operations.




Section 2 Menu Reference

- Program size:
Set the size of a program.
- FB instance size:
Set the data size of a user function block.
If the size set here is exceeded, an error occurs when the [Conversion] command is executed.
When "Maximum" is selected, the program and FB instance sizes are checked according to the maximum size of the target CPU.
The table below shows the maximum size of each CPU.

Series	Type	Program size	FB instance size
SPH2000	NP1PH-08	4096 *1	2048
	NP1PH-16		4096
SPH300	NP1PS-32/32R	8192 *2	4096 *3
	NP1PS-74/74R		
	NP1PS-117/117R		
	NP1PS-245R		4096
SPH2000	NP1PM-48R/48E	16384	16384 *4
	NP1PM-256E/256H	16384	16384
SPH3000 SPH3000MM	NP1PU-048E/128E/256E NP1PU2-048E/256E	16384	16384
SPB	NW0P20/NW0P30	2048	256
	NW0P40/NW0P60	4096	
Board (SPB)	NW3P08-41C	8192	
	NW3P16-42C		
	NW3P32-42C		

- *1 When the CPU version is earlier than V**30, the maximum size is 2048.
- *2 When the CPU version is earlier than V**62, the maximum size is 4096.
- *3 When the CPU version is earlier than V**63, the maximum size is 256.
- *4 When the CPU version is earlier than V**02, the maximum size is 4096.

- Permit use of step control:
Check this option to use SC (step control) instructions. In this case, the last 100 words of the retain memory (WL) is used for SC.
- The duplication of the timer / counter assumes it warning:
If timer/counter coil addresses are overlapped in the same program instance, it is handled as a warning. If this option is unchecked, it is handled as an error.
- Display a confirmation when running the conversion:
When you execute [Conversion] menu > [Conversion] or [Conversion All], the following message to confirm that "Load the changed program into PLC" command is disabled is displayed.




- Disable the conversion and conversion all:
The [Conversion] and [Conversion All] commands are disabled.

Section 2 Menu Reference

(6) Backup

You can make settings of backup operations.



- Backup project when load from PLC or load the changed program into PLC:
The project is automatically backed up when "Load from PLC" or "Load the changed program into PLC" is executed. In addition, when "Load the changed program into PLC" is executed, changed contents are saved as a log.
- AutoSave
The currently open program is automatically saved at certain intervals. You can set the interval between 1 to 99 minutes.

<Default save folder>

<My Document>/Fuji Electric/SX-Programmer Standard

The save folder can be changed.

<File name>

- UPLC001.Zpj3 (When "Load from PLC")
- DPLC001.Zpj3 (When "Load the changed program into PLC")
- DL001.Log (Log file)
- AUTO_SAVE001.zpj3 (AutoSave file)

The number prefixed to a file name is incremented like 001, 002, 003 by every saving. The file with the largest number is the oldest. "001" is the latest file.

"Quantity (1-99)" specifies the number of backup files. If the number of backup files exceeds this value, the oldest file is deleted.


Section 2 Menu Reference

(7) System Definition

You can make setting of operations for system definition registration.

If "Select the last insert module" is checked, the same type module that you inserted last time is automatically displayed when inserting a module in the system definition. This function is convenient to define multiple same type modules.


If unchecked, the module at the top of the list is displayed when inserting a module.



Section 2 Menu Reference

2-8 Window menu

In the [Window] menu, select a program or function block to bring to the front of other windows that are currently opened. Alternatively, you can click the tab.



- [Close All Document] ⇨ Closes all opened documents.

Section 2 Menu Reference

2-9 Help menu

The "Help" menu contains the following commands:


- User Manual ⇒ Opens the user's manual of the loader software.
- About ⇒ Shows the version of the loader.

Section 3 System Definition

In the system definition, set entire system operations, register modules to be used under the configuration, and set parameters.

3-1 System Definition of SPH Series

The following items are specified in the system definition of SPH series.




3-1-1 Registering Modules

(1) Module registration


With the MICREX-SX, you need to register all the modules to be used under one configuration. The following explains module registration procedures using the sample system configuration below.

<Sample system configuration>




Section 3 System Definition


- ◆ Double-click “System Definition” in the project tree. The system definition screen opens.




- ◆ Change the base board to a 8-slot base that is actually used. Select the base board, and then click the [Properties] button. The “Module property” dialog appears.



You can give the power supply module and base board any name up to 63 characters.




- ◆ Select “NP1BS-08 8slots Base” from the [Outline specification] list box, and then click the [OK] button. The base board changes to the 8-slot base.




Section 3 System Definition

- ◆ Register modules sequentially from the left of a base board. Since a power supply and a CPU module are registered by default, register the 16-point input module. To register (add) the module below the CPU module, select the CPU module, and then click the [Insert] button. The “Module insert” dialog box opens.





- ◆ Select the module (NP1X1606-W DC/AC Input 16points) according to the actual configuration. For the SX bus station No., any number from 1 to 238 can be specified. However, in general, 1, 2, 3, ... are assigned from the one on the right of the CPU module in order. Select a module, and then click the [OK] button. The module is registered.



Section 3 System Definition

- ◆ Register modules in the same manner. If you want to mount a module in the future and leave the slot unused as shown in the system configuration, specify the SX bus station number and the module to be mounted in the same manner as other modules, check “No equipment,” and then click the [OK] button.





* No equipment setting of modules/units registered in the system definition can be made or canceled in a batch on the system definition screen. To make or cancel the no equipment setting of the entire system, select “System structure,” and then click the “[No equipment batch setting] button or [No equipment batch release] button. Likewise, to make or cancel no equipment setting of modules/units on a base board, select the base board, and then click each button. For units connected to a remote I/O master module, select the remote I/O master, and then click each button.

Section 3 System Definition


(2) Module parameter setting

The following describes the procedure for setting parameters of MICREX-SX series modules, using input and output modules as an example. Refer to “3-1-2 CPU Parameter Setting” for parameter setting of CPU modules. For other modules, refer to the manual of each individual module.

- ◆ Select the module for parameter setting on the system definition screen, and then click the [Properties] button. The “Module properties” dialog box appears.



- ◆ Click the [Parameter] button. The parameter setting screen for the module appears. The parameter setting screen differs depending on the module type. The following shows the setting screen for the input module.



- ◆ Set each item and then click the [OK] button to return to the “Module properties” dialog box. Click the [OK] button to complete the registration.

Note: Parameter setting for each module can also be performed at the time of module registration.

Section 3 System Definition

<Parameter setting for output module>

Two parameters can be set for the digital output module.

1) HOLD Definition


If the system fails and the CPU module stops, this setting is used to retain the output condition immediately before the failure occurs or retain, while the CPU stops, the output condition immediately before the CPU stops.

2) System DO (Output) Definition

A bit which outputs the operating status of the system regardless of the application can be defined in each configuration. It is set to ON when the entire system is operating normally and OFF if a fatal fault occurs in the system or the system stops. When a nonfatal fault occurs in the system (the system is operating), it is not set to OFF. Only bit 0 of the output module can be set.

<Operating procedure>

- ◆ Select the digital output module for parameter setting on the system definition screen and then click the [Properties] button. The “Module properties” dialog box appears.
- ◆ Click the [Parameter] button. The “Direct I/O parameter setting” dialog box appears.





- ◆ To perform HOLD definition, select “HOLD mode.”
- ◆ To perform System DO definition, check “Select system digital output.”
- ◆ After setting parameters, click the [OK] button.

Section 3 System Definition


(3) Module deletion

The following describes the procedure for deleting a registered module.

- ◆ Select a module to be deleted on the system definition screen and then click the [Delete] button.



- ◆ Click the [Yes] button. The selected module is deleted.




Section 3 System Definition

3-1-2 CPU Parameter Setting


Parameter settings for the CPU module include “CPU running definition”, “Memory allocation setting”, “I/O group Setting”, “Fail-soft operation setting” and “Constant scanning setting (only for SPH2000/3000)”.

(1) CPU running definition

- ◆ Select a CPU on the system definition screen and then click the [Properties] button. The “Module properties” dialog box for the CPU appears.



- ◆ Click the [Parameter] button. The “CPU parameter” dialog box appears. The dialog consists of four tab pages. The “CPU running definition” tab page opens first.



Section 3 System Definition

(2) Memory allocation setting

Set the size of the data memory in the CPU module.


The default size of the data memory is predetermined for each CPU module, but you can change the size of individual memory area in 0.5-k word steps as needed. For more details of the memory of individual CPU modules, refer to the user's manual "Instruction (FEH588)."

1) SPH200/300 series

◆ Click the [Memory allocation setting] tab on the [CPU parameter] dialog box. The [Memory allocation setting] tab page opens.

For SPH300, all the remainder after setting these 3 memory capacities becomes the capacity of non-retain memory. For standard CPU modules, the user can set the capacity of non-retain memory, and the remainder becomes the memory capacity for initial data.

Edge detection, counter, addition timer and timer can also be set for system FB. The remainder becomes the area for other FBs.



Memory Type	Capacity (KW)	Range of word address
Non retain memory	8.0	WM0000000 - WM0008189
Retain memory	4.0	WL0000000 - WL0003995
User FB memory	4.0	
System FB memory	16.0	

System FB Memory Detail	Capacity	Unit
Edge detection	1024 Point x 2W	2048 W
Counter	256 Point x 4W	1024 W
Additional timer	128 Point x 8W	1024 W
Timer	512 Point x 8W	4096 W
Other system FB area		8192 W

◆ Enter the size of each memory in the text box, and then click the [OK] button. Click the [Default] button when you want to reset to default values.

Section 3 System Definition

2) SPH2000 series (NP1PM-48R/48E)

- ◆ Click the [Memory allocation setting] tab on the [CPU parameter] dialog box. The [Memory allocation setting] tab page opens. Make the settings for non-retain memory and other types of memory.

Callout 1: If memory other than non-retain general memory is changed, the non-retain general memory and memory selected via the automatic calculation button become a buffer, increasing or decreasing in size.

Callout 2: In the example of the right figure, when the multi-CPU non-retain memory, retain memory, multi-CPU retain memory, or user FB memory is changed, the system FB memory selected via the automatic calculation button automatically grows or shrinks.

Callout 3: If the number of edge detection, counter, or addition timer points is changed, the system-FB capacity other than that grows or shrinks.

Callout 4: Set whether to make a buffer when changing each memory, etc.

- ◆ Enter the size of each memory in the text box, and then click the [OK] button. Click the [Default] button when you want to reset to default values.
- * If inter-CPU memory access is performed using a processor bus on a SPH2000/3000 series multi-CPU system, the following memory area needs to be reserved.
 - For general memory: memory area must be reserved in multi-CPU non-retain memory.
 - For retain memory: memory area must be reserved in multi-CPU retain memory.

Section 3 System Definition

2) SPH2000 series (NP1PM-256E)

- ◆ Click the [Memory allocation setting] tab on the “CPU parameter” dialog box. The [Memory allocation setting] tab page opens. Make the settings for non-retain memory and other types of memory.

If the memory size is changed, the non-retain general memory and memory selected via the automatic calculation button become a buffer, increasing or decreasing in size.

In the example of the right figure, when the normal memory size, multi-CPU non-retain memory, multi-CPU retain memory, or user FB memory is changed, the system FB memory selected via the automatic calculation button automatically grows or shrinks.

In the example of the right figure, when the size of the retain memory, or user FB normal memory is changed, the system FB normal memory selected via the automatic calculation button automatically grows or shrinks.

Set whether to make a buffer when changing each memory, etc.

- ◆ To change the number of edge detection, counter, addition timer or timer points, click the [Detail] button. The “Detail of system FB memory” dialog box opens. By clicking the corresponding tab, display the “Detail of system FB memory” screen or “Detail of system FB normal memory” window.

On this dialog box, change the number of points of each item. When you change the number, the value of “Other system FB area” on the lower part of the screen is changed. Click the [OK] button to complete the setting.

- ◆ Click the [Default] button on the [Memory allocation setting] tab page when you want to reset to default values.

Section 3 System Definition


<Note>

With V07 or later software version of NP1PM-256E, the memory arrangement has been changed for high-speed access of the system FB memory.

In the user FB memory and system FB memory, the user FB normal memory and system FB normal memory are accessible at high speed. When using user FBs, the user FB normal memory and system FB normal memory are used first.

Software version of NP1PM-256E	
V06 or earlier	Not supported (conventional mode)
V07 or later	High-speed access supported

- ◆ When using V6 or earlier software version of NP1PM-256E, check "A CPU before V06 is used."
If checked, the following dialog box appears.



- ◆ Click the [OK] button to complete the setting.

Note: When using V6 or earlier software version of NP1PM-256E, be sure to check this option. Otherwise, programs cannot be loaded to the CPU.

Section 3 System Definition


(2) I/O group setting

Specify which task in which CPU controls input/output modules in the configuration.


This setting is important for the CPU module to access the input and output of the modules.

* When system definition is finished without I/O group setting, the I/O modules are automatically registered in the default task and a warning message appears.

- ◆ Click the [I/O group setting] tab in the “CPU parameter” dialog box. The “I/O Group Setting” tab page opens.



- ◆ Select (click) a module from the I/O List and then click the register button. The selected module is registered.



- ◆ Register all the modules to be controlled and then click the [OK] button.


* It not possible to assign the same output to more than two CPUs or tasks.

Section 3 System Definition

<Standard setting>

When only one CPU is registered in the configuration and only the "DEFAULT" task controls I/O, modules can be registered in a batch.

- ◆ Select "DEFAULT" for Level and then click the [Standard setting] button. The modules are automatically registered to the Input select box and the Output select box.



Note 1: Modules having input/output area, such as a high-speed counter and a positioning module, need to be registered in both the [Input select] list box and the [Output select] list box.


Note 2: In a multi-CPU system configuration, to reference output modules registered for other CPU modules, register the output modules in the [Input select] list box. Output modules that have already been registered in the [Output select] list box of another CPU module cannot be registered.

Section 3 System Definition


<Output detail setting>

In a multi-CPU system configuration, which CPU controls the module output can be specified on a bit or word basis.


- ◆ Select a module for “output detail setting” from [Output select] and then click the [Detail] button.



- ◆ When the digital output module is selected, the “Port mode IO Detail Setting” dialog box opens.




- ◆ Click and set OFF the button corresponding to the bit to be controlled by another CPU.




Section 3 System Definition

Note 1: The dialog box displayed when you click the [Detail] button differs according to the selected module.

<When the digital output module with pulse train output is selected>



<When the analog output module is selected>



Note 2: If you select a module that does not support "output detail setting," the dialog box for detail setting does not appear even if you click the [Detail] button.


Section 3 System Definition

<Input for referring output value>


In a multi-CPU system configuration, if you want to use the output of an output module used by another CPU as "Input" in an application program of the local CPU, register the bit or word to "Input select" for the I/O group of the local CPU.

Note: This function can be used only for an output module that is actually mounted. For output modules registered as "no equipment," the output memory (Y) does not work on a program of the local CPU.

- ◆ Select the output module to be referenced, click the [>>] button to register it to "Input select".




- ◆ Click the [Input for referring output value] button. The "Port mode IO Detail Setting" dialog box appears.



All bits are selected by default.

- ◆ Click and set OFF the button corresponding to the bit without output value reference..




Bit with output value reference

- ◆ Click the [OK] button.

Section 3 System Definition

Note: When referencing analog output or other output values, setting on a word basis is required. In this case, the “Memory mode IO Detail Setting” dialog box appears.




Section 3 System Definition


(3) Fail-soft operation setting

Even if a failure occurs in a module or unit on the SX bus and remote I/O (such as T-link), operations of other normal modules and units are continued. This operation is referred to as “fail-soft” operation

- ◆ Click the [Fail-Soft Operation Setting] tab in the “CPU parameter” dialog box. The “Fail-Soft Operation Setting” tab page opens.



- ◆ Select a module for fail-soft operation setting and then click the [Register] button.



- ◆ After registering the modules for fail-soft operation setting, click the [OK] button.

Note: For expansion units on a remote I/O, fail-soft operation is registered for each unit. Fail-soft operation cannot be registered in units of modules.

Section 3 System Definition

3-1-3 System Property

On the System properties dialog box, "System Running Definition", "Redundancy setting", and "Fail-soft operation setting" can be specified. The following describes the procedure for setting system running definition and fail-soft operation setting.

(1) System running definition

The system running definition includes SX bus tact time setting, configuration check wait time setting, and initialization mode selection.

1) SX bus tact time

The SX bus tact time refers to the interval of data communication with modules (such as an I/O module) connected to the SX bus.

For SX bus tact, select 0.5, 1, 1.5, 2, 2.5, ... 9.5, and 10ms. The default value is 1.0ms.

2) Waiting time for structure check

When the power of the system is turned on, the CPU module starts configuration check of all modules on the SX bus.

When all the modules has been activated within the time specified as "Waiting time for structure check", the system starts.

When the system consists of multiple bases and the power of each base is turned on at different timing, adjust the tact time with "Waiting time for structure check."

(The default value of "Waiting time for structure check" is 20 seconds. It can be specified within a range from 1 to 180 seconds.)

3) Waiting time mode for structure check

Wait structure agreement : Wait structure matches to actual system until "Waiting time for structure check" time.

Wait specified time : Wait until "Waiting time for structure check" time.

* This item is enabled in SPH200/300 only.

4) Initialization method


When the power of the system is turned on, the CPU module is initialized. This setting allows you to specify whether CPU module internal memory diagnosis is performed or not.

5) Start up system without CPU "0"

This setting allows you to specify whether the system is started up when "0" station does not exist in a system such as a redundant system.

Section 3 System Definition

- ◆ Select “System properties” in the system definition screen and then click the [Properties] button. The “System Running Definition” tab page of the “System properties” dialog box opens.




- ◆ Set each item and then click the [OK] button.

Section 3 System Definition

(2) Fail-soft operation setting

Even if some modules (modules under fail-soft operation, such as a servo module) cannot be powered on at the startup of the MICREX-SX system, the system can start up excluding such modules after the configuration check waiting time has elapsed. In this case, the system starts operation in the nonfatal fault condition.

- ◆ Click the [Fail-soft operation setting] tab in the “System properties” dialog box. The “Fail-soft operation setting” tab page opens.



- ◆ If there is any device under system fail-soft operation, select “Partial Fail-soft start up” and then enter the SX bus station number from which fail-soft operation is to be started.
- ◆ Click the [OK] button.

Section 3 System Definition

(3) System redundancy definition

If a failure occurs in a working CPU module, the standby CPU operates to continue PLC system operation. This configuration is referred to as CPU redundancy.


<Overview of redundant system>

1-to-1 redundant system

1-to-1 redundant CPU system has one standby CPU for one working CPU. Each of CPU0-CPU1, CPU2-CPU3, CPU4-CPU5, and CPU6-CPU7 indicates a pair of a working CPU and a standby CPU. Therefore, when building a multi-CPU 1-to-1 redundant system, up to four pairs of CPUs can be installed. The same application program must be downloaded to a working CPU and a standby CPU.

<Example of redundant system configuration>

Generally, the working CPU and standby CPU are mounted on different base boards and other modules to be controlled by the CPU are mounted on another base board, as shown below. If the working CPU fails and the standby CPU starts operation instead, this configuration enables you to replace the failed CPU while the standby CPU is operating.



* On the base board mounting the CPU, only the power supply and CPU are mounted.

Note: It is also possible to build a redundant system with an working CPU and a standby CPU mounted on the same base board. In this case, however, the standby CPU module cannot be replaced during system operation.


Section 3 System Definition

<System redundancy definition>


1) Module registration

Register modules and units that are actually mounted in the same manner as usual systems.

- ◆ Register modules according to the actual system configuration, as shown below.



For the CPU module that functions as Standby CPU by default, select "Standby CPU" for Resource name.




Section 3 System Definition


2) System redundancy definition

On the “Redundancy setting” screen of the “System properties” dialog box, select ON or OFF of redundancy and set details of redundancy.

- ◆ Select “System properties” on the system definition screen and then click the [Properties] button. The “System properties” dialog box appears.



- ◆ Click the [Redundancy setting] tab on the “System property” dialog box. The “Redundancy setting” tab page opens. Set each item and then click the [OK] button.



Section 3 System Definition

<Settings for redundancy system>

Settings for 1-to-1 redundant system are shown below. In a 1-to-1 redundant system, which CPU is paired with which one is predetermined and up to four pairs can be specified.

Select a pair of CPUs for 1-to-1 redundancy. Which CPU is paired with which one is predetermined as shown below.

Specify the memory copy range for the case of warm standby system with 1-to-1 redundancy. The range from the top of the memory area to the size specified here is the copy range.

1:1

Working	Standby
<input checked="" type="checkbox"/> CPU0 - CPU1 (C)	
<input type="checkbox"/> CPU2 - CPU3 (E)	
<input type="checkbox"/> CPU4 - CPU5 (G)	
<input type="checkbox"/> CPU6 - CPU7 (J)	

standby-mode

Cold	Warm
<input type="radio"/> Cold	<input checked="" type="radio"/> Warm
<input type="radio"/> Cold	<input type="radio"/> Warm
<input type="radio"/> Cold	<input type="radio"/> Warm
<input type="radio"/> Cold	<input type="radio"/> Warm

switch

Yes
<input type="checkbox"/> Yes
<input type="checkbox"/> Yes
<input type="checkbox"/> Yes
<input type="checkbox"/> Yes

Memory copy range

High	Normal	Retain
<input type="text" value="0"/> W(D)	<input type="text" value="100"/> W	<input type="text" value="200"/> W
<input type="text" value="0"/> W(F)	<input type="text" value="0"/> W	<input type="text" value="0"/> W
<input type="text" value="0"/> W(I)	<input type="text" value="0"/> W	<input type="text" value="0"/> W
<input type="text" value="0"/> W(K)	<input type="text" value="0"/> W	<input type="text" value="0"/> W

Select the standby mode.

Specify whether interlock selection is made or not in a multi-CPU system configuration.

Section 3 System Definition

3-1-4 Address inversion setting

This function inverts I/O addresses and P/PE-link bit addresses (0 bit ↔ F bit) displayed in the program or data monitor window.

<Use example 1>


When a MICREX-F series I/O is connected to the SX series T-link and you want to match the bit numbers of the I/O (terminal) with those of the CPU (program).

<Use example 2>

When SX and MICREX-F series are mixed in a P/PE-link system and you want to match the bit addresses viewed from MICREX-F with those in SX.

<Setting example>

On the system definition screen, click [Edit] menu > [Bit Inversion Setting].




The “Bit Inversion Setting” dialog box opens.

When “The background of the device is inversion display.” is checked, the device addresses are inversely displayed. In the following example, this option is checked.

• Example of “Bit Inversion Setting” screen of I/O


Check the modules the address of which you want to invert.



Section 3 System Definition


• Example of “Bit Inversion Setting” screen of P-link

The target is high-speed 1 area. Select block Nos. that you want to invert assuming that 1 block equals to 32 words. In the following example, the bit memory (M8.0 to M8.31F) of the block 0 (WM8.0 to WM8.31) is inverted.



• Example of “Bit Inversion Setting” screen of PE-link

The target is high-speed 1 area. Select block Nos. that you want to invert assuming that 1 block equals to 8 words. In the following example, the bit memory (M9.0 to M9.7F) of the block 0 (WM9.0 to WM9.7) is inverted.




Section 3 System Definition

<Example of address inversion>

When address inversion setting has been made, the target I/O memories and P/PE-link memories are inversely displayed as shown below.

• Example of inversion display of ladder



• Example of inversion display of data monitor

Data Monitor 1			
Address	Tag	F	0 F 0
X1.0.F			0
X1.0.E			0
M0			0
Y1.1.F			0
Y3.0			0
M8.F			0
M8.320			0
M9.F			0
M9.32F			0

Section 3 System Definition


<Special notes>

The address inversion function only inverses the display of addresses on the ladder screen and data monitor screen of the loader. Note that the actual memory addresses are not inverted.

	MSB			LSB	
Actual bit address	X1.0.F	X1.0.E	. . .	X1.0.1	X1.0.0
Address inversion is not set	X1.0.F	X1.0.E	. . .	X1.0.1	X1.0.0
Address inversion is set	X1.0.0	X1.0.1	. . .	X1.0.E	X1.0.F

Enter actual bit addresses on the ladder screen and data monitor screen.

When you enter a contact address "X1.0.F" for which address inversion is set, "X1.0.0" must be entered actually as shown below.




Section 3 System Definition


3-1-5 Bus tact Time check function

This function calculates a bus tact recommendation value in the loader according to the configuration set in the system definition.

- ◆ On the system definition screen, click [Tool] menu > [Bus tact Time check].



- ◆ The check result is displayed.




- Apply ⇒ Applies the check result to the SX bus tact of the system property.
Note: When using a periodic task, make sure that the period time must be a multiple of the bus tact.
When using the constant scan function, make sure that the set scan time must be a multiple of the bus tact.
- OK ⇒ Closes the check result window.
- Memo ⇒ Starts the note pad and pastes the check result in it.

Section 3 System Definition

3-2 System Definition of SPB Series

The following items are specified in the system definition of SPB series.




* This subsection describes the procedure of setting system definition. For more details of setting items of system definition, refer to the user's manual "Instruction (FEH202)."

3-2-1 Registering Units

(1) Unit registration


With the MICREX-SX, you need to register all the units to be used under one configuration. The following explains module registration procedures using the sample system configuration below.

<Sample system configuration>





Section 3 System Definition

◆ Double-click “System Definition” in the project tree. The system definition screen opens.




◆ Register units sequentially from the right of the basic unit in their connected order. Select the basic unit and then click the [Insert] button. The [Module insert] dialog box opens.





Section 3 System Definition

- ◆ Select the unit (NW0AX04-MR: Analog Input 4CH) according to the actual configuration. Units' station numbers are automatically determined according to their connected order. When you select a unit and then click the [OK] button, the unit is registered.



- ◆ Register units in the same manner.
Since only one communication adapter can be connected on the left side of the basic unit in a single SPB system, its station number is fixed to "8".



* The communication adapter is registered at the bottom of the system definition screen regardless of the registered order.

Section 3 System Definition

3-2-2 Basic unit parameter setting

The basic unit parameter setting includes five setting items: “CPU running definition,” “Memory allocation setting,” “I/O group setting,” “HI Counter Definition,” and “I/O Running mode”.

(1) CPU running definition

- ◆ Select the CPU for parameter setting on the system definition screen and then click the [Properties] button.

The “Basic unit parameter” dialog box opens.

The dialog box consists of five tab pages. Click the corresponding tab to open.

The “CPU running definition” status opens first. Set all necessary items.

The screenshot shows the 'Basic unit parameter' dialog box with the 'CPU running definition' tab selected. The dialog has five tabs: 'CPU running definition', 'Memory allocation setting', 'I/O group setting', 'HI Counter Definition', and 'I/O Running mode'. The 'CPU running definition' tab contains several settings:

- Watch Dog Timer setting:** Radio buttons for 'Default' (selected) and 'Specify'. A text box for 'WDT time' contains '4095' and is followed by 'ms'.
- I/O status latch function:** Radio buttons for 'Invalidity' (selected) and 'Effective'.
- Running specification at power on:** Radio buttons for 'RUN=Run/TERM=Run' (selected), 'RUN=Run/TERM=Last State', and 'RUN=Stop/TERM=Stop'.
- Battery less run:** Radio buttons for 'OFF' (selected) and 'ON'.
- LED display at built-in flash memory un-match:** Radio buttons for 'Not display' and 'Display' (selected).
- Compulsion setting hold state:** Radio buttons for 'OFF(Not hold)' (selected) and 'ON(Hold Compulsion setting)'. A text box next to the 'ON' option contains the message: 'This setting cannot be used with a present model.'
- Constant scanning setting:** Radio buttons for 'No(Scanning usually)' (selected) and 'YES'. A text box for 'Scan time' contains '0' and is followed by 'ms'.

At the bottom of the dialog are three buttons: 'OK', 'Cancel', and 'Help'.

Section 3 System Definition

(2) Memory allocation setting

- ◆ When you click the “Memory allocation setting” tab, the screen opens. Set all necessary items.

The screenshot shows the 'Basic unit parameter' dialog box with the 'Memory allocation setting' tab selected. The dialog has several tabs: 'CPU running definition', 'Memory allocation setting', 'I/O group setting', 'HI Counter Definition', and 'I/O Running mode'. The 'Memory allocation setting' tab contains the following fields and controls:

- Range of word address:**
 - Non retain memory: 40 x 64W = 2560W, WM0000000 - WM0002557
 - Retain memory: 16 x 64W = 1024W, WL0000000 - WL0000923
 - User FB memory: 0 x 64W = 0W
 - System FB memory: 64 x 64W = 4096W
- Initial data: Max 1631, with a 'Default' button.
- Detail of system FB memory:**
 - Edge detection: 512 Point x 2W, 1024 W
 - Counter: 128 Point x 4W, 512 W
 - Additional timer: 0 Point x 8W, 0 W
 - Timer: 256 Point x 8W, 2048 W
 - Other system FB area: 512 W

At the bottom of the dialog are 'OK', 'Cancel', and 'Help' buttons.

(3) I/O group setting

- ◆ When you click the “I/O group setting” tab, the following screen opens.
Each unit registered in the system definition is automatically assigned to “DEFAULT” task.
Set all necessary items.

The screenshot shows the 'Basic unit parameter' dialog box with the 'I/O group setting' tab selected. The dialog has the same tabs as the previous screenshot. The 'I/O group setting' tab contains the following fields and controls:

- Level: A dropdown menu set to 'DEFAULT' and a 'Standard setting' button.
- I/O List: A list box containing:
 - Basic Unit : Unit No.-0 : Resource : NW/
 - Expansion Unit : Unit No.-2 : Ry Output
- Input select: A text box with the value 'Input for referring output value'.
- Output select: A text box with the value 'Basic Unit : Unit No.-0 : Resource : NW/OP4' and 'Expansion Unit : Unit No.-2 : Ry Output 16p'.
- Navigation buttons: '>>[A]', '<<[R]', '>>[M]', and '<<[N]'.
- Detail..: A button to open a detail dialog.
- All cancel: A button at the bottom.

At the bottom of the dialog are 'OK', 'Cancel', and 'Help' buttons.

Section 3 System Definition

(4) High-speed counter setting

- ◆ When you click the “HI Counter Definition” tab, the following screen opens.
Set all necessary items.

The screenshot shows the 'Basic unit parameter' dialog box with the 'HI Counter Definition' tab selected. The dialog has a title bar with a close button. Below the title bar are five tabs: 'CPU running definition', 'Memory allocation setting', 'I/O group setting', 'HI Counter Definition', and 'I/O Running mode'. The main area is divided into sections. The 'Mode' section has two radio buttons: 'Single phase' (selected) and 'Two phase'. Below this, there are two columns of settings. The left column is for 'Single phase' and contains two identical blocks: 'Use channel 0' (checked) with a 'Scale' dropdown set to 'x 1' and an 'Auto reset' checkbox (unchecked); and 'Use channel 1' (checked) with a 'Scale' dropdown set to 'x 1' and an 'Auto reset' checkbox (unchecked). The right column is for 'Two phase' and contains a 'Scale' dropdown set to 'Pulse + direction'. At the bottom right are three buttons: 'OK', 'Cancel', and 'Help'.

(5) I/O running mode

- ◆ When you click the “I/O Running mode” tab, the following screen opens.
Set all necessary items.

The screenshot shows the 'Basic unit parameter' dialog box with the 'I/O Running mode' tab selected. The dialog has a title bar with a close button. Below the title bar are five tabs: 'CPU running definition', 'Memory allocation setting', 'I/O group setting', 'HI Counter Definition', and 'I/O Running mode'. The main area is divided into sections. The 'Software filter setting' section has two radio buttons: 'Not setting' and 'Setting' (selected). Next to 'Setting' is a 'Setting value' dropdown set to '3ms'. Below this is the 'Remote RUN/STOP bit setting' section, which contains four rows of bit settings labeled '0w', '1w', '2w', and '3w'. Each row has a grid of 16 buttons labeled 'F', 'E', 'D', 'C', 'B', 'A', '9', '8', '7', '6', '5', '4', '3', '2', '1', '0'. At the bottom right are three buttons: 'OK', 'Cancel', and 'Help'.

- ◆ After setting each parameter of the basic unit, click the [OK] button to complete the setting.


Section 4 Print

This section explains the functions associated with print.
The print commands are as follows.

- [Page setup]: Sets a page to print a project.
 - [Print]: Prints a project.
 - [Print preview]: Previews to print a project.
- * 1 Install the printer driver to use the print function
- * 2 It is not possible to print "I/O device list", "Device usage", "Device Cross reference" and "Initial setting list" with this function.
To print them, output a text file (csv format) by using the [Export] command in the [Project] menu, and open the file in Excel, and then print it.

4-1 Page Setup


◆ Click [File] menu > [Page Setup]. The following dialog box opens. Set paper size, orientation, margin, etc.



Section 4 Print

4-2 Print

- ◆ Click [File] menu > [Print]. The following dialog box opens.
Choose a printer, print items, the range, and the number, and then click the [OK] button to start printing.



Section 4 Print

(1) Print items


Print items are as follows.

- Program
- System definition
- Project tree
- Project properties
- AFB ladder

If you click the [Detail] button, you can perform the detailed settings.

(1)-1 Program

Items checked in the “Program List” are printed.



- [Monochrome Printing]:
Forcibly performs monochrome printing of a program. When “black and white” is selected in the printer settings and a program is printed, X and Y addresses, which are displayed in red on the screen, are difficult to see when printed. By selecting “Monochrome Printing,” the character color is forcibly changed to black to make a program easier to see when printed.
- [Protect Line Breakup]:
A line is printed on the next page to avoid printing on the current and next pages.
- [Print Line number in each section]:
If this option is unchecked, for line numbers (line number displayed to the left of each row), serial numbers starting with “0” are printed for each program, regardless of “SECTION” instructions. If this option is checked, serial numbers starting with “0” are printed for each part delimited by “SECTION” instruction.
Regardless of whether this option is checked, when there is “SECTION” instructions in a program, the program is delimited by them and each part is automatically printed on different pages.
- [Include Cross Reference]:
Adds cross reference to every line and print it. Choose “Grid style” or “In-circuit style.”
- [Address Rows] :
Select Hide or 1 to 12 Rows.
- [Tag Rows] :
Select Hide or 1 to 12 Rows. By switching between “Display Tag” and “Display Description,” description can be printed instead of tags.


Section 4 Print

<Printing cross reference>

An example of printing cross reference is shown below.

- When “Grid style” is selected and “Print Line number in each section” is unchecked

MachineA_Print Ladder0 [0] 1 Page



Device	Access	Instruction	Symbol	Type	ES0/ES1	Program	Line No.	Device Pos
N1	Read	SECTION		Program	-	Ladder0	1	1
N1	Read	SECTION		Program	-	Ladder1	1	1




Device	Access	Instruction	Symbol	Type	ES0/ES1	Program	Line No.	Device Pos
X1.0	Read	LD	- -	Function Block	-	FB0	1	1
X1.0	Read	LD	- -	Function	-	FCT0	1	1
X1.0	Read	LD	- -	Program	-	Ladder0	2	1
X1.1	Read	ANI	- / -	Program	-	Ladder0	2	3
X1.1	Read	LD	- -	Program	-	Ladder1	2	1
Y2.0	Read	OR	- -	Program	-	Ladder0	2	2
Y2.0	Write	OUT	-(-)	Program	-	Ladder0	2	4
Y2.0	Read	LD	- -	Program	-	Ladder0	3	1
Y2.0	Read	LD	- -	Program	-	Ladder1	3	1

- When “Grid style” is selected and “Print Line number in each section” is checked

MachineA_Print Ladder0 [0] 1 Page

SECTION 1



Device	Access	Instruction	Symbol	Type	ES0/ES1	Program	Line No.	Device Pos
N1	Read	SECTION		Program	-	Ladder0	N1:0	1
N1	Read	SECTION		Program	-	Ladder1	N1:0	1




Device	Access	Instruction	Symbol	Type	ES0/ES1	Program	Line No.	Device Pos
X1.0	Read	LD	- -	Function Block	-	FB0	N0:0	1
X1.0	Read	LD	- -	Function	-	FCT0	N0:0	1
X1.0	Read	LD	- -	Program	-	Ladder0	N1:1	1
X1.1	Read	ANI	- / -	Program	-	Ladder0	N1:1	3
X1.1	Read	LD	- -	Program	-	Ladder1	N1:1	1
Y2.0	Read	OR	- -	Program	-	Ladder0	N1:1	2
Y2.0	Write	OUT	-(-)	Program	-	Ladder0	N1:1	4
Y2.0	Read	LD	- -	Program	-	Ladder0	N1:2	1
Y2.0	Read	LD	- -	Program	-	Ladder1	N1:2	1


In the example above, “N1” indicates the No. of SECTION instruction and a number after “:” indicates line No. in the SECTION.

Section 4 Print

- When “In-circuit style” is selected and “Print Line number in each section” is unchecked




- When “In-circuit style” is selected and “Print Line number in each section” is checked




Section 4 Print

(1)-2 System definition

There is no setting item for system definition.



(1)-3 Project tree




- Calling relationship of Functions / Function Blocks: When using FBs, the interaction between the program and FB is printed.

Section 4 Print

(1)-4 Program property

The program properties of the items whose box is checked in the “Program List” are printed. The program properties include the following information.


- Program Name
- Program No.
- Type (Kind)
- Use of enable flag (ENO)
- Local device setup information
- Parameter list (only functions and function blocks)
- Array/structure declaration
- Information on memory in function blocks (only function blocks)



Section 4 Print

(1)-5 AFB Ladder

The items checked in the AFB ladder program list are printed.



For these setting items, refer to "(1)-1 Program."


(2) Page (print range)

Choose "All" (print all pages) or "Page appointment" (specify the target range to print). When you choose "Page appointment," use the preview function to confirm the print image.


Section 4 Print

4-3 Print Preview

◆ Click [File] menu > [Print Preview]. The “Print preview” screen opens.



Icon




- [Print]: Executes printing.
- [Zoom]: Zooms in the preview screen.
- [Consolidation]: Chooses the number of screens from 1/2/3/4/6.
- [Close]: Closes the print preview screen.

Section 4 Print


4-4 Circuit Print

This function is used to print a program by specifying the print range in units of lines on the screen.

- ◆ Open a program that you want to print, and drag the circuit No. part on the left side to select the lines. Then, right-click and select “Circuit Print.”



- ◆ The “Print” dialog box opens. Select a printer, and then click the [OK] button. The selected lines are printed.




Appendix 1 SX Control Utility

The SX control utility allows MICREX-SX system I/O and internal memory monitoring, data change, and data backup without starting the loader. This utility can also be used for I/O check in a system where no project is downloaded to the CPU module.


Appendix 1-1 Starting SX Control Utility

- ◆ Click [Start] of Windows > [All Programs] > [SX-Programmer Standard V3] > [Tools] > [SX Control Utility].
* Alternatively, you can click [Tools] menu > [SX Control Utility] on the loader.


- ◆ When the SX control utility is started, the following message appears.



- ◆ Click the [OK] button. The dialog box to confirm reading of the system configuration appears.




- ◆ Click the [OK] button to read the system configuration from the connected CPU module.




Appendix 1 SX Control Utility


- ◆ Click the [Yes] button to display the screen and start monitoring.
Click the [No] button to display the screen without starting monitoring.



Note 1: For a CPU module with no system definitions registered, the following message appears. The SX control utility recognizes the I/O modules of the connected system, creates system definitions, and downloads them.




- ◆ Click the [OK] button to create and download the system definitions to the CPU. Then, the following message appears.




- ◆ Click the [OK] button, reset the CPU, and then use the SX control utility.

Note 2: If communications with the CPU are not established when the SX control utility is started, the following message appears. In this case, check the connections with the CPU and communication settings for the SX control utility.



Appendix 1 SX Control Utility

Appendix 1-2 SX Control Utility Window



1) Mark display area

- Displays the mark settings.
When a mark is set for an address, this area shows a marker (O in light blue).
- Displays the reference input specification for output address.
When an output area has been defined as the reference input in I/O group setting of the system definitions, "R" is added to the address.

2) Address display area

Displays the addresses in the CPU memory in the order of CPU numbers and addresses. If the corresponding address has not been registered to an I/O group, it is not displayed. Modules registered as "no equipment" are displayed regardless of whether the I/O group setting is made, however, the binary display area is grayed out.

3) Data display area

- Binary display area
Displays binary data of the memory related to "Address display area."
<Detailed display of I/O group definition>
This area also displays detailed information of I/O group settings. Bits for which I/O groups have been set are displayed in the ordinary character display color (black) and the ones for which no I/O groups have been set are displayed in gray.
- Forcible set status display (valid only when forcible ON/OFF display is set)
Bits set for forcible ON/OFF are displayed with an underscore (red).
- Decimal display area
Displays decimal data of the I/O module related to "Address display area."
(The data type can be selected from signed integer, unsigned integer, or real number.)
- Hexadecimal display area
Displays hexadecimal data of the I/O module related to "Address display area."
- Time display area
The data that corresponds to the data in the address display area is displayed in time format (selectable from "T" (ms), "D" (year, month and day), "TOD" (hour, minute and second) and "DT" (year, month, day, hour, minute and second)).
- String display area
The data that corresponds to the data in the address display area is displayed in the form of character string (STRING type).

4) Monitor status display

Displays the monitor status (stopped or running).


Appendix 1 SX Control Utility

Appendix 1-3 SX Control Utility Operations

(1) Setting monitor ON/OFF


Start or stop monitoring.

- ◆ Start or stop monitoring by clicking the  [Monitor] button or  [Monitor (force having)] button.




(2) Setting bit data


You can overwrite or forcibly set/reset (force ON/OFF) bit data in the binary data display area. Force ON/OFF is valid only for actually existent I/O memories.



- ◆ Select a bit to set and click one of the following buttons:

 [Bits ON],  [Bits OFF],  [Force set], and  [Force reset].

- ◆ To release the forcibly set/reset I/O, select the forcibly set bit and click the  [Force release] button. To clear multiple I/Os set/reset forcibly, click [Data change] menu > [Force] > [Batch release].





Appendix 1 SX Control Utility

(3) Setting word data (16- or 32-bit data)

You can overwrite data on the word data in the decimal or hexadecimal display area on the “SX Control Utility” window.

- ◆ Click the decimal or hexadecimal display area of the memory to be overwritten, set decimal or hexadecimal data in accordance with the display area, and press the <Enter> key.



* Double-word data can also be set by switching word/double-word display by the 16 [16-bits display] and 32 [32-bits display] buttons.


Appendix 1 SX Control Utility

(4) Batch data change


You can change the data in multiple memories in a batch.

Note: Since data are set in a batch offline and then transferred to the CPU, you need to stop the CPU to use this function.

- ◆ Stop the monitoring on the SX control utility.




- ◆ Set data.





Data set in a batch

- ◆ Transfer the set data to the CPU. Click [Data change] menu > [Move to PLC...]. The "Move to PLC" dialog box appears.



* For a multiple-CPU configuration, select the CPU to which the data is transferred.

- ◆ Select the data transfer destination CPU and click the [OK] button. The following confirmation dialog box appears. Click the [OK] button to transfer the data to the CPU.



Click the [OK] button to complete the transfer operation.

Appendix 1 SX Control Utility

Appendix 1-4 CPU Memory Backup


The SX control utility can store backup data files (*.bup) for program memory, data memory, system definitions, etc. from the CPU into the computer.

Note: Backup files for programs and system definitions cannot be opened with the loader. Data stored in files are in SX-specific machine code.


(1) Data backup

Transfer the data in the CPU module to the computer.

- ◆ Stop the monitoring and click [Tool] menu > [BackUp]. The [Backup] dialog box opens.
- ◆ Set the transfer source CPU and the transfer destination file, and then select the backup data type from the list box.




- ◆ The backup range in the data memory area can be specified. When you select a data memory, the [Range setting...] button is enabled. Click it to display the "Range setting" dialog box. On this dialog box, specify the range and click the [OK] button.




Appendix 1 SX Control Utility

- ◆ Select the transfer source, transfer destination, and backup data, and then click the [Execution]. The following confirmation dialog appears. Click the [OK] button to start data transfer.




- ◆ When data transfer is completed, the dialog box appears, showing the transfer results.



(2) Data verify

You can compare the contents of the memory in the CPU with those of the backup file.

- ◆ On the [Backup] dialog box, select "Verify," and then select the verification source file, verification destination CPU, and data type to be verified. Then, click the [Execution] button.




- ◆ The following confirmation dialog box appears. Click the [OK] button to start verification.



Appendix 1 SX Control Utility


- ◆ When verification is completed, the dialog box appears, showing the verification results.




(3) Backup text file input/output function

You can save backup data as text files and display or edit the saved data with a commercially available text editor or spreadsheet program.

- ◆ First, read backup files that have been created with the [BackUp] command in the [Tool] menu. Click [File] menu > [Open backup file...]. The "Open backup file" dialog box opens.




- ◆ After selecting a backup file, click the [Open] button. The selected backup file is opened.




Appendix 1 SX Control Utility

- ◆ Then, click [File] menu > [Save as...]. The following dialog box opens. Check “Save the memory area data by the text form,” enter a file name for the file to be saved, and then click the [Save] button. The backup data is saved in the file, in the “tab delimited text” format.



<Saved file name and folder>

By the operations explained above, a folder and a file are created in the following structure.




Appendix 1 SX Control Utility

<Format of created text file>

The created text file is delimited by tabs in the following format.

* The figure shown below is an example when a file is opened with a text editor.




Appendix 2 System Software Utility

The system software utility is used to change the mode of supported programming language to “SX-mode” that conforms to IEC 61131-3, an international standard, or to update the SPB firmware. (SPB is set to “N-mode” at shipment.)

*** The Board controller (SPB) is fixed to “SX-mode” and does not support “N-mode.” Therefore, the system software utility is not required.**


<Necessary system configuration>



*For loader cable, either NN-CNV1 or NN-CNV3 can be used.


<Operating procedure>

- ◆ Click [Start] of Windows > [All Programs] > [SX-Programmer Standard V3] > [Tools] > [System Software Utility] to start the system software utility.



Note: Be sure to end other application programs before this utility is executed.

- ◆ Close other application programs, and then click the [OK] button. The currently connected SPB is checked, and then the following dialog box appears. (This checking takes approximately 18 seconds at the maximum.)




The status of currently connected SPB is displayed.


The system software to be updated is set. Set [Mode] to “SPB SX-mode”.

Appendix 2 System Software Utility

- ◆ Click the [System software Update Execution] button. The following confirmation dialog box appears. When an application program exists in the SPB, make a backup copy of it as needed.



- ◆ Click the [Yes [Y]] button to start the update of the system software.




Note: Be careful not to turn off the power switch of the system or disconnect the power cable while system software is being updated.

- ◆ When the update is completed successfully, the following dialog box appears. Click the [OK] button to finish the operation.



- * If the update does not finish successfully, change the setting of the baud rate and re-execute the update.



Appendix 3 Simulator Function

Appendix 3-1 Specifications of Simulation Function


The simulation has the following functions:

- Monitoring function in the ladder screen *
- Monitoring and data setting functions in data display/setting dialog *
- Simulation panel function
- Auto feedback function

* Operation and display specifications are the same as those of the online monitor.

Appendix 3-1-1 Screen configuration at simulation

In the following example, the ladder screen and the simulation panel are displayed for simulation.



* On the simulation panel, you can arrange push buttons for simulation and graphical objects for data setting/display to make simulation operation easier.

Appendix 3 Simulator Function

Appendix 3-1-2 Specifications of simulation function

Specification and function	Description
Simulation target	User program registered to tasks * User functions and user function blocks need to be used by the user program.
Restrictions on instructions	1) Below FBs have some restrictions. M_OPEN, M_SEND, M_RECEIVE, R_READ, R_WRITE, F_READ, F_WRITE For more details, refer to "Appendix3-1-3 Details of instruction operation restrictions." 2) As for expansion FBs provided by Fuji Electric, simulation cannot be performed normally.
Operation at FB monitoring	The path currently being used is displayed during monitoring of FBs currently being called (used) by multiple locations.
Simulation panel	Graphic objects are arranged in the Simulation tab page, allowing easy simulation operation. Graphic objects which can be arranged include "label", "button", "switch", "lamp",... For more details, refer to "Appendix 3-2-2 Using simulation panel."
Auto feedback screen	Allows creation of a circuit for automatic response to the AFB (auto feedback) tab page. Only one AFB tab can be used for on project. For more details, refer to "Appendix 3-2-3 Using auto feedback (AFB)."

Note 1: This simulation function is used to check program logic operations. It does not allow process simulation of the entire system.

Note 2: The accuracy of the timer is not ensured.

Note 3: About the simulation panel and AFB screen

(a) A simulation panel can be used by online connection with PLC actual device. However, it has to follow the actual device operation on I/O address (X, Y).

(b) AFB program is only valid during simulating. When programs are transferred to PLC actual device, AFB program is not transferred.

Note 4: Even if simulation is stopped, contents of all memories are hold. If you want to clear them, stop simulation and then click [Clear] button to clear.

Appendix 3 Simulator Function

Appendix 3-1-3 Details of instruction operation restrictions

Since the Standard loader performs the simulation function in the offline mode, operations are restricted with respect to communication-related FBs requiring a remote site to communicate with.

(1) M_OPEN, M_SEND, M_RECEIVE, R_READ, R_WRITE

When these FBs are executed, only parameter check is performed. If the parameters have no error, they work properly. (The completion bit of the FB is set ON.) No data is transferred.


Appendix 3 Simulator Function

Appendix 3-2 Simulation Procedure


Appendix 3-2-1 Basic simulation procedure

This subsection describes how to simulate a created program.


- ◆ Click [Online] menu > [Simulation Mode]. “SX Simulator” starts up.



- ◆ Click [Slot 0]. The “Select CPU Module” dialog box opens. Choose a CPU module to use, and click the [OK] button.





- ◆ The CPU is assigned to the simulator.





Appendix 3 Simulator Function

◆ Click [Online] menu > [PLC Operation]. The following dialog box opens. Transfer programs to the PLC. (The operation is same as online.)




Note1)



Note 1: In the simulation mode, the retain memory area and FB/SFB memory area are cleared when a program is transferred even if these options are unchecked.

Appendix 3 Simulator Function


◆ Click [Online] menu > [Monitor]. The program window is placed into a monitoring state.



Appendix 3 Simulator Function


Appendix 3-2-2 Using simulation panel

Use the simulation panel to make simulation easier.



(1) Objects which can be used in the simulation panel

Ten different objects can be arranged at any position in the simulation panel.




1) Label

This button is used to create characters. You can specify the character font, size, and color.

<Label setting dialog box>

Main setting items on the label dialog box are shown below.




Appendix 3 Simulator Function

2) Line

This button is used to create lines. You can specify the color and width.

<Line setting dialog box>

Main setting items on the line dialog box are shown below.




3) Rectangle

This button is used to create rectangles. You can specify the color and width.

<Rectangle setting dialog box>

Main setting items on the rectangle dialog box are shown below.




Appendix 3 Simulator Function

4) Ellipse

This button is used to create ellipses. You can specify the color and width.

<Ellipse setting dialog box>

Main setting items on the ellipse dialog box are shown below.



The screenshot shows the 'Properties' dialog box for an ellipse. It is divided into several sections: Appearance, Design, Layout, and Name. The Appearance section includes BackColor (Window), BorderColor (Black), and BorderWidth (1). The Design section shows the Name as 'Ellipse1'. The Layout section shows Location (577, 74) and Size (40, 40). The Name section explains that it indicates the name used in code to identify the object. A 'Close' button is at the bottom right. Three lines point from the text on the right to the BackColor, BorderColor, and BorderWidth fields.

Section	Property	Value
Appearance	BackColor	Window
	BorderColor	Black
	BorderWidth	1
Design	Name	Ellipse1
Layout	Location	577, 74
	Size	40, 40
Name	Indicates the name used in code to identify the object.	


5) Button

This button is used to create a button which turns on when clicked.

You can specify a bit device (mandatory) to be assigned to the button, button name, button operation (momentary or alternate).

<Button setting dialog box>

Main setting items on the button setting dialog box are shown below.



The screenshot shows the 'Properties' dialog box for a button. It is divided into several sections: Appearance, Data, Design, and Layout. The Appearance section includes BackgroundImage (none), BackgroundImageLa (None), ButtonOperation (Momentary), Display (Address), Font (MS UI Gothic, 9pt), ForeColor (ControlText), and Text (Start). The Data section shows Address (X1.0) and Value (0). The Design section shows the Name as 'Button1'. The Layout section shows AddressPosition (cpBelow), Location (38, 98), and Size (71, 22). The Name section explains that it indicates the name used in code to identify the object. A 'Close' button is at the bottom right. Five lines point from the text on the right to the ButtonOperation, Font, ForeColor, Name, and Address fields.

Section	Property	Value
Appearance	BackgroundImage	(none)
	BackgroundImageLa	None
	ButtonOperation	Momentary
	Display	Address
	Font	MS UI Gothic, 9pt
	ForeColor	ControlText
	Text	Start
Data	Address	X1.0
	Value	0
Design	Name	Button1
Layout	AddressPosition	cpBelow
	Location	38, 98
	Size	71, 22
Name	Indicates the name used in code to identify the object.	


Appendix 3 Simulator Function

6) Switch

This button is used to create a slide switch which turns on when clicked and off when clicked again. You can specify a bit device (mandatory) to be assigned to the button, switch size, button type (horizontal slide or vertical slide), and button name.

<Switch setting dialog box>

Main setting items on the switch setting dialog box are shown below.



Choose button operation
Horizontal
Vertical


Specify address of the bit device which turns on when the button is clicked.

7) Indicator

This button is used to create a Indicator which displays the ON/OFF status of the specified bit device. You can specify a bit device (mandatory) to be assigned to the Indicator, color when ON.

<Indicator setting dialog box>

Main setting items on the Indicator setting dialog box are shown below.



Specify color when the lamp is ON (device ON).

Enter address of the bit device.


Appendix 3 Simulator Function

8) Edit

This button is used to show / enter data for specific device in word or double-word. You can specify device address and data type (mandatory).

<Edit setting dialog box>

Main setting items on the edit setting dialog box are shown below.



Enter address of the device. (Word / Double-word)

Specify data type (INT/ DINT/ WORD/ DWORD, etc).


9) Slider

This button is used to set data to specific device in word or double-word.

You can specify device address, data type (mandatory), minimum value, maximum value, and color.

<Slider setting dialog box>

Main setting items on the slider setting dialog are shown below.



Specify color

Enter address of the device. (Word / Double-word)

Enter Maximum value

Enter Minimum value

Specify data type (INT/ DINT/ WORD/ DWORD, etc).

Appendix 3 Simulator Function

10) Timer/Counter

This button is used to create a display box which displays the setting and current value of a specified timer or counter. In addition to settings of the timer/counter to be displayed (mandatory), you can specify the display color at the time of time-up (count-up). The display box has two rows and the setting is displayed in the lower row and the current value in the upper one.

<Timer/counter setting dialog box>

Main setting items on the timer/counter setting dialog box are shown below.

Properties	
Appearance	
Display	Address
OnColor	Red
Data	
Address	T0
Instance	CONFIGURATION-RES
PouName	Ladder0
Value	0
Design	
Name	TimerCounter1
Layout	
AddressPosition	cpBelow
Location	257, 97
Size	76, 42
Name Indicates the name used in code to identify the object.	
Close	

Specify color of the box at time-up/count-up.

Specify address of the timer/counter (mandatory).


Specify task (Default/ Fixed/ Event) using the assigned timer/counter (mandatory).

Specify program using the assigned timer/counter (mandatory).


Appendix 3 Simulator Function

(2) How to create the simulation panel


The following describes how to create a button, indicator, and timer display in the simulation panel as shown below.




- ◆ Right-click "Simulation" in the project view window, and click [Insert] > [Insert Simulation Panel].



- ◆ The following dialog box opens. Click the [OK] button.




- ◆ Simulation panel opens.




Appendix 3 Simulator Function


- ◆ Create a button first. Click the [Button] button, move the mouse pointer to the simulation panel and left-click it. The button is arranged as shown below.




- ◆ Double-click the arranged button, and properties of the button are displayed. Enter the address of the button and the characters displayed on the button, and then click the [Close] button.



- ◆ The button setting is now complete.




- ◆ To change the size of a button, drag the "Handle" (the square dots) around the button. (Lamp, Timer/Counter etc. can be changed in the same manner.)




Appendix 3 Simulator Function


- ◆ Then, create a Indicator. Click the [Indicator] button, and move the mouse pointer to the simulation panel, and left-click it. The indicator is arranged as shown below.



- ◆ Double-click the arranged indicator, and properties of the indicator are displayed. Enter the address of the indicator, and click the [Close] button.




- ◆ The indicator setting is now complete.




Appendix 3 Simulator Function


- ◆ Create a timer next. Click the [Timer/Counter] button, move the mouse pointer to the simulation panel and left-click it. The timer is arranged as shown below.



- ◆ Double-click the arranged timer, and properties of the timer are displayed. Enter the address of the timer, and click the [Close] button.




- ◆ The timer setting is now complete.



Appendix 3 Simulator Function

(3) Simulation operation program


The following simple circuit was created for simulation operation check.




(4) Simulation operation check

After you create the simulation panel and simulation program, perform simulation.

Following the procedure described in Appendix 3-2-1, start the simulator, transfer the program, and perform monitoring.



◆ When you click the “Start” button, the indicator goes on (in red) allowing the timer current value to be monitored.



Appendix 3 Simulator Function

Appendix 3-2-3 Using auto feedback (AFB)


The auto feedback function is used to automate simulation of the created program.

For example, to perform simulation of communications with external devices, when the signal or program turns ON and the program created in auto feedback outputs a value to a desired device, simulation can be automated for improved efficiency.


(1) Creating an auto feedback circuit

Create an auto feedback circuit that receives the value of a desired device (except local devices) of the program under simulation, performs calculation, and returns a value to the simulation program.

- ◆ Right-click the "Simulation" in the project view window. Click [Insert] > [Insert AFB].



- ◆ The following dialog box opens. Click the [OK] button.




- ◆ The AFB screen opens. You can edit the AFB screen in the manner as the general program edit screen.



Appendix 3 Simulator Function

- ◆ Here, create the following circuit that receives a signal from “simulation operation program” in Appendix 3-2-2 (3), starts the timer, then returns the bit signal.




<Operation>

When this circuit receives the ON signal (M0 turns on for one scan) from the simulation operation program, the re-triggerable timer (T0) is activated. The re-triggerable timer is a timer that captures a rising edge of the input signal and turns ON the timer output bit for specified time interval. With this circuit, when the specified time interval has elapsed, the timer output turns OFF and then M2 (feedback signal to the simulation program) turns ON only for one scan.

Appendix 3 Simulator Function

(2) Changing the simulation program

Change the “simulation operation program” in Appendix 3-2-2 (3) so that the program exchanges signals with the auto feedback circuit.



<Changes>

- 1) Add contact M2 so that the on-delay timer (T0) starts when the feedback signal (M2 turns ON for one scan) is received from the auto feedback circuit.
- 2) Add a line which transfers the count-up signal of timer T0 to the auto feedback circuit.
Since on-delay timer T0 is a local device and therefore cannot be transferred to the auto feedback line as it is (T0), T0 is output to M1 and M1 is transferred to the auto feedback circuit.

(3) Checking auto feedback operation

After preparing the circuits (1) and (2) and a simulation panel by following Appendix 3-2-2 (2), execute the following procedure to perform simulation.

- 1) Start up simulation mode.
- 2) Transfer and reset programs.
- 3) Start up monitor.

Click the button [X1.0] on the simulation panel once.

The on-delay timer (T0) of the program for the simulation and the re-triggerable timer (T0) of the auto feedback circuit operate in alternate.

Appendix 4 Arrays/ Structures

Array can handle multiple word data (or bit data, or double-word data) as one data block.

Structure can handle combination of bit, word, double-word as one data block.

To use Array/ Structure, you need to define Array/ Structure. For more details, refer to Appendix 4-2.

Then, declare Array/ Structure. For more details, refer to Appendix 4-3.

Appendix 4 Arrays/Structures

Appendix 4-1 Specification of Arrays/Structures

Item	Specification	
Nesting depth	1 level (array of arrays, array of structures)	
Array	Max. No. of definitions	512 (User program: 256, Expansion FB provided by Fuji: 256) (Note 1)
	Max. No. of elements	32767 (16384 for 32 bit data type)
	Element No. specification	1 to specified No. of elements No. of elements: max. 32767 (16384 for 32 bit data type) * When element No. specification exceeds the range, upper limit or lower limit data is accessed.
	Max. No. of declarations	583 (Note 1) * "Declaration" means assigning a defined array to an address.
	Data type	Bit, word, double word, array (defined by user)
	Array name	ARY_n n : array definition No. (from 0 (decimal))
	Available memories (Note 2)	Entire program: I/O memory (W, Y), standard memory (M), retain memory (L) Inside of user FB: I/O memory (X, Y), standard memory (M), retain memory (L), memory for user FB (F), parameter (V), (I/O parameter only)
Structure	Max. No. of definitions	512 (User program: 256, Expansion FB provided by Fuji: 256) (Note 1)
	Max. No. of members	255
	Data type of member	Bit, word, double word, array (defined by user)
	Structure name	STR_n n : structure definition No. (from 0 (decimal))
	Member name specification	Member name indicating sign + member definition No. (from 1) * The member name definition No. is automatically assigned when the structure is defined. Member name identifying sign: R (bit), WR (word), DR (Double word), ARY_n (Array)
	Max. No. of declarations	584 (When No. of members: 1 and No. of structure definitions: 1) (Note 1) * "Declaration" means assigning a defined structure to an address.
	Available memories (Note 2)	Entire program: I/O memory (W, Y), standard memory (M), retain memory (L) Inside of user FB: I/O memory (X, Y), standard memory (M), retain memory (L), Memory for user FB (F), parameter (V), (I/O parameter only)

Note 1: Definitions and declarations of arrays and structures are stored in the program memory of the CPU. The amount of program memory used by arrays and structures is obtained by the following equation.

[Equation]

(Program memory used by arrays and structures)

$$= 4 + (\text{No. of array definitions}) \times 5 + (\text{Structure 0 No. of steps of definition}) + \dots + (\text{Structure n No. of steps of definition}) + (\text{No. of declarations of arrays and structures}) \times 7$$

$$* \text{No. of steps of structure definition} = (\text{No. of members}) + 3 (\text{steps})$$

[Sample calculation]

Supposing,

- No. of array definitions: 3,
- Structure 0 (No. of members: 10)
- Structure 1 (No. of members: 5)
- No. of declarations of arrays and structures: 5

then

$$(\text{Program memory used by arrays and structures}) = 4 + (3 \times 5) + (10 + 3) + (5 + 3) + (5 \times 7) = 75 \text{ steps}$$


Note 2: The system memory (SM), timer (T), counter (C), integrating timer (TR) and step control (SC) are not available.

Note 3: Information about definitions and declarations of arrays and structures is stored in the last user function No. which the CPU can obtain (SPH300: No. 511) and then in the program memory of the CPU. Therefore, when using arrays and structures, the last user function No. (SPH300: No. 511) cannot be used.


Appendix 4 Arrays/Structures

Appendix 4-2 Definition of Arrays/ Structures

- ◆ Right-click “Arrays/Struct” in the project view, and then click [Open]. The “Arrays/Structures” view and the “Array/Structure declares” list are displayed.



[Array/ Structure] view




[Array/ Structure declaration] list




Appendix 4-2-1 Array definition

- ◆ Right-click the array in the “Array/Structures” view, and click [Add array definition].




- ◆ The following dialog box opens. Set the number of array elements and data type, and then click the [OK] button.



* When you set array of arrays, choose the defined array from the data type.


- ◆ An array is defined.




Appendix 4 Arrays/Structures

Appendix 4-2-2 Structure definition


- ◆ Right-click the structures in the “Array/Structures” view, and click [Add structure definition].




- ◆ The following dialog box opens. Choose the data type of the first element of the structures, and click the [OK] button.




- ◆ The structure (STR_0) and the first element (R1) are defined.




- ◆ Define the second element of the structure. Right-click the first element, and click [Insert member of structure].



- ◆ The following dialog box opens. Choose the data type of the second element of the structure, and click [OK].



- ◆ The second element (WR2) is defined.




- ◆ Define the third and later elements in the same manner.

Appendix 4 Arrays/Structures

Appendix 4-3 Array/Structure Declaration

Assignment of a defined array or structure to an actual address is called “declaration.” Execute array/structure declaration on the “Array/Structure declares” list.

- ◆ Enter the top address on the “Array/Structure declares” list. And then, choose the defined array/structure from the “Array/Structure” list. When moving the mouse to another row, the range of the address is calculated and displayed automatically.



Start address	Array/Structure	Address range
WM100	ARY_0	WM100 - WM109
WM200	STR_0	WM200 - WM201
▶*		

* Setting of the top address:

When setting arrays of double-word and structures, set the top address as even number.

When setting arrays of bit, set the top address as 0 bit.


Appendix 4 Arrays/Structures

Appendix 4-4 Array/Structure Expression on Programs

On application programs, arrays and structures are represented as shown below.


[Array]

WM100[5]




[Structure]

WM100. WR2




[Array of arrays]

WM100[5][WM0]



[Array of structures]

WM100. WR2[3]





Appendix 4 Arrays/Structures

Appendix 4-5 Importing Array/Structure Definition


Import the array/structure definition in another project. If there is the definition that has the same name as the one to import, the definition is automatically imported under a different name.

- ◆ Click [Project] menu > [Import] > [Arrays/Structure]. The following dialog box opens. Click the [Select file] button, and select the file to import.




Appendix 4 Arrays/Structures

- ◆ The array/structure declaration is listed. Check the items to import and click the [OK] button.




- ◆ When the import is completed, the following message appears.



Appendix 4 Arrays/Structures

Appendix 4-6 Array/Structure Number

A number is assigned to Arrays/Structures.




Array/Structure numbers are classified as shown in the table below to avoid overlap between numbers used in “user program” and numbers used in “expansion FB” provided by Fuji.

Item	User program	Expansion FB
Array/structure No. that can be defined	0 to 255	256 to 511
Array/structure No. that can be used for declaration	0 to 511	0 to 511
Array No. that can be specified for data type of array	0 to 511	0 to 511
Array No. that can be specified for data type of structure member	0 to 511	0 to 511

* Users can change definition numbers or delete definitions of expansion FBs.

To change Array/Structure numbers, right-click an array or a structure in the “Arrays/Structures” view.



Appendix 5 Password Function

<Overview>

There are two types of passwords. You can choose to use either one of them. Password target is PLC. Set a password while the loader is connected to the PLC.

1) Standard password

If the standard password is set, the following operations are disabled: reading of a program from the PLC, loading of a program to the PLC, PLC program change, and PLC program verification.



2) 3-level access restriction

Depending on the access level set by the user, PLC operations (Start/Stop, Load program, Read program, Change program, etc.) are restricted. The 3-level access restriction function is supported by SPH300, SPB, and Board controller [SPB]. To set this function, you need to stop the PLC.

The password for user ROM is also available. For more details, refer to 2-7-1.

Appendix 5 Password Function

◆ Click [Online] > [PLC operation]. The following dialog box opens. Click the [Password] button to open “Password” dialog box.



Authentication: If a password is set to the PLC, click this button to perform authentication by the password.

Registration/Change: This button is used to set a new password, or change the set password.

Clear: This button is used to delete the set password.

Restriction Setting: This button is used to make detailed settings for 3-level access restriction function.

The key icon color shown on the “Password” dialog box indicates the password status.



Gray: Password is not registered.



Orange: Password is registered, and password is not authenticated.





Green: Password is registered, and password is authenticated.

Appendix 5 Password Function

Appendix 5-1 Standard password

Appendix 5-1-1 Registering password


Click the [Registration/Change] button. The “Registration/Change” dialog box opens. Enter a password and click the [OK] button.



* Set the password from 6 to 32 alphanumeric characters and symbols (+, -, =, /).

Uncheck “Access level effective.” If this option is checked, the 3-level access restriction function is enabled.

◆ The password is registered.



At this moment, the password is authenticated, and program change or other operations are enabled. Once you close the project window, authentication is reset, and program change or other operations are disabled. To perform these operations, you need to enter the password.


Appendix 5 Password Function

Appendix 5-1-2 Password authentication


Password authentication procedure differs depending on whether the project file is opened or not.

(1) When the project file is closed


- ◆ Click [Online] menu > [PLC operation]. The following dialog box opens. Click the [Password] button to open the “Password” dialog box.



- ◆ The key icon is shown in orange because the password is registered and not authenticated. Click the [Authentication] button.



- ◆ The “Authentication” dialog box appears. Enter the password and click the [OK] button.




- ◆ If the password is correct, the password is authenticated, and the key icon changes to green. Click the [Close] button.




Appendix 5 Password Function

(2) When the project file is opened


- ◆ Click [Online] menu > [PLC operation]. The following dialog box opens. Click the [Password] button to open the “Password” dialog box.




- ◆ The key icon is shown in orange because the password is registered and not authenticated. Click the [Authentication] button.



- ◆ The “Authentication” dialog appears. Enter the password and click the [OK] button.



- ◆ If the password is correct, the password is authenticated, and the key icon changes to green. Click the [Close] button.




Appendix 5 Password Function

Appendix 5-1-3 Changing password


Before the password is changed, password authentication (refer to Appendix 5-1-2) is necessary. The procedure differs depending on whether the project file is opened or not.

(1) When the project file is closed

- ◆ Click [Online] menu > [PLC operation]. The following dialog box opens. Click the [Load from PLC] button to read the program.




- ◆ After reading the program, click [Online] menu > [PLC operation]. The following dialog box opens. After this, the procedure is same as "When project file is opened."




Appendix 5 Password Function

(2) When the project file is opened


- ◆ Click [Online] menu > [PLC operation]. The following dialog box opens. Click the [Password] button to open the “Password” dialog box.




- ◆ The “Password” dialog box appears. Click the [Registration/Change] button.



- ◆ The “Registration/Change” dialog box appears. Enter a new password and click the [OK] button.



- ◆ The new password is registered.




Appendix 5 Password Function

Appendix 5-1-4 Clearing password


Before the password is cleared, password authentication (refer to Appendix 5-1-2) is necessary. The procedure differs depending on whether the project file is opened or not.

(1) When project file is closed.

- ◆ Click [Online] menu > [PLC operation]. The following dialog box opens. Click the [Load from PLC] button to read the program.




- ◆ After reading the program, click [Online] menu > [PLC operation]. The following dialog box opens. After this, the procedure is same as "When the project file is opened."




Appendix 5 Password Function

(2) When project file is opened.

- ◆ Click [Online] menu > [PLC operation]. The following dialog box opens. Click the [Password] button to open the “Password” dialog box.




- ◆ The “Password” dialog box opens. Click the [Clear] button.



- ◆ The following confirmation dialog box appears. Click the [Yes] button.



- ◆ The password is cleared, and the key icon changes to gray. Click the [Close] button.




Appendix 5 Password Function

Appendix 5-2 3-level Access Restriction Function

Appendix 5-2-1 Overview

The 3-level access restriction function restricts operations to the PLC at 3 different levels by setting passwords for access authentication. Users can change the range of access restrictions.



<Differences between standard password and this function>

The standard password function aims to maintain confidentiality and avoid falsification of projects. It contains online access restriction function, however, it only protects projects on the loader; the PLC itself cannot be protected. In addition, only one password can be set, therefore, it is not possible to set multiple access levels.

Appendix 5 Password Function

Appendix 5-2-2 Specifications of 3-level Access Restriction Function

(1) Target CPU

The 3-level access restriction function is supported by SPH300, SPB and Board Controller [SPB].

(2) Operating range for each access level

Available operations of Standard loader for each level (default) are shown below.

Note: For access restrictions that are not on the list below, use the standard password function.

Function		Level 3	Level 2	Level 1
Load	Program	✓	✓	X
	System definition / module driver	✓	X	X
	Data / ZIP file / parameter data	✓	✓	X
Download changes to PLC		✓	✓	X
User ROM	Loading of project	✓	✓	X
	Write-protection	✓	✓	X
	Export of user ROM file to text file	✓	✓	X
	Writing of tag project	✓	✓	X
	Import of tag project	✓	✓	X
Monitor		✓	✓	✓
Data modify		✓	✓	X
PLC information		✓	✓	✓
Task execution time measurement		✓	X	X
Memory clear (Note)	Program	✓	X	X
	System definition / data / ZIP file / resource initialization	✓	✓	X
Memory transfer		✓	✓	X
PLC calendar display		✓	✓	✓
PLC calendar setting		✓	✓	X
Debug	Breakpoint / step execution forcible ON/OFF	✓	✓	X
	Program operation / condition monitor / sampling trace			
Redundancy control		✓	✓	X
PLC run/stop		✓	✓	X
SX control utility	Backup - Transfer (PLC to file)	✓	✓	X
	Backup - Transfer (file to PLC)	✓	X	X
	Backup - Verify	✓	✓	✓
	Data change - Transfer to PLC	✓	✓	X
Password	Level 3 password setting	✓	X	X
	Level 2 password setting	✓	✓	X
	Password clear	✓	X	X
	Access restriction setting	✓	X	X
Failure diagnosis		✓	✓	✓

* For the shaded items (in) on the list above, access restriction setting cannot be changed.

Note: If you clear a program or system definition, all passwords are cleared.

Appendix 5 Password Function

(3) Functions to manage password

Operations required to manage the password (“Registration”, “Authentication”, “Change” and “Clear”) and the authority to perform them are as follows:

Function	Access level	Authority
1) Registration The password is registered for the PLC.	Level 3 user or No password registered	Allowed to register passwords for level 3 and level 2.
	Level 2 user	Allowed to register only a password for level 2.
	Level 1 user	Not allowed.
2) Authentication (logon) Logon operation to allow operations to the PLC.	Level 3 user	By performing password authentication for each level, operations for each level are allowed. * If password authentication is not performed, access level 1 is provided.
	Level 2 user	
	Level 1 user	
3) Change The registered password is changed.	Level 3 user	Allowed to change passwords for level 3 and level 2.
	Level 2 user	Allowed to change a password for level 2.
	Level 1 user	Not allowed.
4) Clear All registered passwords are cleared.	Level 3 user	Allowed to clear passwords for level 3 and level 2.
	Level 2 user	Not allowed.
	Level 1 user	Not allowed.
5) Restriction setting Operations for each level can be individually enabled/disabled.	Level 3 user	Allowed to change access restriction.
	Level 2 user	Not allowed.
	Level 1 user	Not allowed.

* Effective duration of password authentication

Once password authentication is completed, it is effective until the project file is closed.



Appendix 5 Password Function

Appendix 5-2-3 Operation procedure

Appendix 5-2-3-1 Registering password


◆ Click [Registration/Change] button on the “Password” dialog box. The “Registration/Change” dialog box opens. Check “Access level effective,” and you can enter level 3 and level 2 passwords. After entering passwords, click the [OK] button.

* To register a password, stop the PLC.



* Set the password from 6 to 32 alphanumeric characters and symbols (+, -, =, /).
Check “Access level effective.” If this option is unchecked, the standard password function is enabled.
It is possible to register only the level 3 password. (impossible to register only the level 2 password)




◆ The password is registered.



At this moment, the password is authenticated, and program change or other operations are enabled. Once you close the project file, authentication is reset, and the access level is changed to level 1 (Lowest level).

Appendix 5 Password Function

<Password registration patterns and access level>

No.	Password registration pattern	Authentication and access level after authentication
1	No password	No restriction (Level 3)
2	Password is registered. (Access level is not effective.) 	Authentication is performed with the registered password. → No restriction (Level 3) Password authentication is not performed. → Access rights when no password is entered in the Standard password function
3	Only password for level 3 is registered. (Access level is effective.) 	Authentication is performed with the registered password for level 3. → No restriction (Level 3) Password authentication is not performed. → Level 2 access right
4	Passwords for level 3 and level 2 are registered. (Access level is effective.) 	Authentication is performed with the registered password for level 3. → No restriction (Level 3) Authentication is performed with the registered password for level 2. → Level 2 access right Password authentication is not performed. → Level 1 access right

Note: If the same password is set for level 2 and level 3, access is allowed at level 2 after authentication. If you want to access at level 3, set different passwords for level 2 and level 3.


Appendix 5 Password Function

Appendix 5-2-3-2 Password authentication


The password authentication procedure differs depending on whether the project file is opened or not.

(1) When the project file is closed

- ◆ Click [Online] menu > [PLC operation]. The following dialog box opens. Click the [Password] button to open the “Password” dialog box.




- ◆ The key icon is shown in orange because the password is registered and not authenticated. Click the [Authentication] button.



* Indicates “Level 1” when password authentication has not been completed (initial state).

- ◆ The “Authentication” dialog box opens. Enter the level 2 or level 3 password and click the [OK] button. (In this example, the level 3 password is entered.)




- ◆ If the password is correct, the password is authenticated, and the key icon changes to green. Click the [Close] button.




Appendix 5 Password Function

(2) When the project file is opened

- ◆ Click [Online] menu > [PLC operation]. The following dialog box opens. Click the [Password] button to open the “Password” dialog box.




- ◆ The key icon is shown in orange because the password is registered and not authenticated. Click the [Authentication] button.




* Indicates “Level 1” when password authentication has not been completed (initial state).

- ◆ The “Authentication” dialog box opens. Enter the level 2 or level 3 password and click the [OK] button. (In this example, the level 3 password is entered.)



- ◆ If the password is correct, the password is authenticated, and the key icon changes to green. Click the [Close] button.



Appendix 5 Password Function


Appendix 5-2-3-3 Changing password

Before the password is changed, password authentication (see Appendix 5-2-3-2) is necessary. The procedure differs depending on whether the project file is opened or not.


* To change the password, stop the PLC.

(1) When project file is closed.

◆ Click [Online] menu > [PLC operation]. The following dialog box opens. Click the [Load from PLC] button to read the program.




◆ After reading the program, click [Online] menu > [PLC operation]. The following dialog box opens. After this, the procedure is same as "When the project file is opened."




Appendix 5 Password Function

(2) When the project file is opened


- ◆ Click [Online] menu > [PLC operation]. The following dialog box opens. Click the [Password] button to open the “Password” dialog box.





- ◆ The “Password” dialog box opens. Click the [Registration/Change] button.



- ◆ The “Registration/Change” dialog box opens. Enter a new password and click the [OK] button.



- ◆ If the PLC is running, the following dialog box appears. Click the [Yes] button to stop the PLC and set the new password.



Appendix 5 Password Function


Appendix 5-2-3-4 Clearing password

Before the password is cleared, password authentication at the level 3 is necessary. (Level 2 cannot clear the password.) The procedure differs depending on whether the project file is opened or not.


* To clear the password, stop the PLC.

(1) When project file is closed.

◆ Click [Online] menu > [PLC operation]. The following dialog box opens. Click the [Load from PLC] button to read the program.




◆ After reading the program, click [Online] menu > [PLC operation]. The following dialog box opens. After this, the procedure is same as "When the project file is opened."




Appendix 5 Password Function

(2) When the project file is opened



- ◆ Click [Online] menu > [PLC operation]. The following dialog box opens. Click the [Password] button to open the “Password” dialog box.



- ◆ The “Password” dialog box opens. Click the [Clear] button.



- ◆ If the PLC is running, the following dialog box appears. Click the [Yes] button to stop the PLC and clear the password.



Appendix 5 Password Function


Appendix 5-2-4 Changing access restriction setting

The currently set restrictions of online operations can be changed. Only the users with access level 3 can use this function. After performing password authentication, follow the procedure below. The procedure differs depending on whether the project file is opened or not.


* To change the access restriction setting, stop the PLC.

(1) When the project file is closed

- ◆ Click [Online] menu > [PLC operation]. The following dialog box opens. Click the [Load from PLC] button to read the program.




- ◆ After reading the program, click [Online] menu > [PLC operation]. The following dialog box opens. After this, the procedure is same as "When the project file is opened."




Appendix 5 Password Function

(2) When the project file is opened


- ◆ Click [Online] menu > [PLC operation]. The following dialog box opens. Click the [Password] button to open the “Password” dialog box.



- ◆ The “Password” dialog box opens. Click the [Registration/Change] button.




- ◆ The “Access Restriction Setting” dialog box opens.



Appendix 5 Password Function


- ◆ Select the access level to be changed, and then check functions to enable or uncheck functions to disable.



* Check the checkbox of the functions to access.


- ◆ After completing the setting, click the [OK] button.

* The setting contents are transferred to the PLC when the [OK] button is clicked. If the PLC is running, the following dialog box appears.



<Checking set items>


- ◆ Click the [Confirm Setup] button on the “Access Restriction Setting” dialog box to open the following window. You can check the current setting status.



Appendix 5 Password Function

<Initializing set items>

- ◆ Click the [Default] button on the “Access Restriction Setting” dialog box. The following dialog box appears. Click the [OK] button to reset the access restriction settings.




* For the default setting of the access restriction, refer to the table in “Appendix 5-2-2.”


<Exporting settings>

The settings of the selected access level can be saved under an arbitrary filename. (The extension is “.ARI”.) You can export the saved file and use it as a kind of template.

- ◆ In the “Access Level” list box on the “Access Restriction Setting” dialog box, select the access level to save in a file, and then click the [Export] button. The “Export” dialog box opens.



- ◆ Enter a file name and click the [Save] button.




Appendix 5 Password Function


<Importing settings>

You can import access restriction settings saved by the export function.

- ◆ In the “Access Level” list box on the “Access Restriction Setting” dialog box, select the access level to import, and then click the [Import] button. The “Import” dialog box opens.



- ◆ Select a file to import and click the [Open] button.



Appendix 5 Password Function

Appendix 5-3 Notes on Use

(1) When you forget password

If you forget the password, access at level 2 and level 3 is impossible.

(2) Position of key switch

Set the key switch of the CPU module to the "TERM" position. If the switch is set at the "RUN" or "STOP" position, you cannot register a password.

(3) State of PLC

When the PLC is in the following states, you cannot register a password for the access level 2 or 3.

- When the program and system definition have not been downloaded
- When the breakpoint function is used
- When the condition monitor function is used
- When the sampling trace function is used
- When a user ROM card is write-protected
- When in a N-to-1 redundant system

When a function No. where a password is stored has already been used

The function No. where the password is stored depends on the PLC type.

SPH300: 510, SPB: 14, Board controller [SPB] : 510

(4) Consumption of program memory

When registering passwords for access level 3 and level 2, 33 steps of program memory is consumed. If there is not 33 steps or more available space in the program memory, you cannot register a password.

In addition, when a program with maximum steps is downloaded to the PLC in which a password with the access level 2 or 3 is registered, the 3-level access restriction function is disabled and changed to the standard password function.

(5) Loading program

A project that uses the following No. cannot be loaded to the PLC for which a password of 3-level access restriction function is set:

SPH300: 510, SPB: 14, Board controller [SPB] : 510

(6) Setting password with user ROM utility

You cannot set a password of the 3-level access restriction function for the user ROM with the user ROM utility. To set a password for the user ROM, mount it on the PLC, set the key switch to the "UROM-TERM" position, and then set a password for the PLC.

(7) Setting password in multi-CPU system

In a multi-CPU system, set a password for each CPU. When you want to register the same password for all the CPUs, set it for each CPU.

Appendix 6 How to Use ST Language

Appendix 6-1 Overview of ST Language

Appendix 6-1-1 ST operators

Operators that can be used in ST language are listed below:

No.	Operation	Operator	Example
1	Parentheses	(expression)	
2	Function	Function name (parameter)	WM1 := BCD(WM0); WL100 := BMOV(WL0, 5);
3	Exponentiation	**	DM100 := DM0 ** REAL#3.0;
4	Logical not	NOT	Y2.0 := NOT X1.0;
5	Multiplication	*	DM10 := DM8 * DINT#1000;
6	Division	/	DM12 := DM12 / DINT#3;
7	Division remainder	MOD	WL10 := WM0 MOD 10;
8	Addition	+	WM2 := WM0 + WM1;
9	Subtraction	-	WM3 := WM2 - 100;
10	Comparison	<, >, <=, >=	M0 := WM100 > 100;
11	Equality	=	M1 := DM100 = DINT#10000;
12	Inequality	< >	M2 := WL200 <> 1000;
13	Logical Product	&, AND	M3 := M1 & X1.0;
14	Exclusive or	XOR	WM100 := WM99 XOR WL100;
15	Logical add	OR	WM0 := WX1.0 OR 16#00FF;

* Take note of data types available in each operator.

Appendix 6-1-2 ST statements

The following eight control statements are used in ST language.


Format	Description
:=	Assignment statement. Assigns the value of the expression, variable, or numeric value on the right-hand side to the variable on the left-hand side.
IF	Condition statement. Executes the executable statement if the conditional expression is true.
CASE	Condition statement. Selects the executable statement to be executed according to the value of the conditional expression.
FOR	Iteration statement. Repeatedly executes the executable statement according to the initial value, final value, and incremental or decremental value.
WHILE	Iteration statement. Repeatedly executes the executable statement while the loop condition is true.
REPEAT	Iteration statement. Repeatedly executes the executable statement until the loop condition is true.
RETURN	Return statement. Returns control from the called function or function block to the calling POU.
EXIT	Exit statement. Used to exit an iteration loop.

Appendix 6 How to Use ST Language

Appendix 6-1-3 Basic description specifications

(1) Basic syntax of instruction

The describing method in ST language is as follows:



<Sample programs>

ST language representation



Ladder language representation


WM0 := WM1;
Example of memory address




Y2.0 := X1.0;
Example of memory address



WM0 := 1000;
Example of constant



WM7 := WM5 + WM6;
Example of expression



WM3 := BCD (WM2);
Example of expression (function)



(2) Example of describing a multi-operation

In the Standard loader, monomial expressions are used for the representation of expressions. Therefore, a multi-operation that uses multiple operators must be described as follows:

Example of multi-operation

(WM0 + WM1 + WM2) / 3 = WM3



ST language representation

WM3 := WM0 + WM1;
WM3 := WM3 + WM2;
WM3 := WM3 / 3;

* To change multi-operation to single-operation, use "Multi operation input wizard." Refer to Appendix 6-3-2.

Appendix 6 How to Use ST Language

(3) Example of describing a sequential circuit

Sequential circuits can also be described in ST language.

Sample sequential circuit


ST language representation

Example of AND circuit




M2 := M0 & M1 ;

Example of OR circuit



M2 := M0 OR M1 ;

Example of latching circuit



MF := M0 OR M2 ;

ME := NOT M1 ;

M2 := MF & ME ;

Auxiliary relay

(4) Describing a comment

A comment is created above an instruction line.

(*Execute processing when M0 is turned ON*)

← A comment is created above an instruction line.

IF M0 = TRUE THEN

WL100 := WL101 + 100 ;

END_IF ;

Note: When creating a comment on the right of an instruction line:

IF M0 = TRUE THEN **(*Execute processing when M0 is turned ON*)**

← When a comment is created on the right of an instruction line, by confirming the edit of the ST editor, the comment is relocated below the circuit.

WL100 := WL101 + 100 ;

END_IF ;

Appendix 6 How to Use ST Language

Appendix 6-2 How to Use Control Statements

Appendix 6-2-1 Condition statements

The condition statement is a control statement to execute the selected instruction (executable statement) if certain conditions are met. Two types of condition statements, the IF statement and CASE statement, are provided.

(1) IF statement

For the IF statement, three types of syntaxes are provided according to the option to be executed.


<1) IF...THEN structure>

When the value of the conditional expression is TRUE, the executable statement is evaluated (executed). When the value of the conditional expression is FALSE, nothing is executed.

<Basic syntax>

```
IF <conditional expression> THEN
  <executable statement>;
END_IF;
```

<Flowchart>



* For the "conditional expression", a monomial expression whose operation result is a BOOL type value can be used. If you want to designate an operation result of a multi-operation as the condition, program as shown in the sample program 4.

<Sample program 1>

When M0 is ON, the conditions are met and the operation of "WL101 + 100 = WL100" is executed.



```
IF M0 = TRUE THEN
  WL100 := WL101 + 100 ;
END_IF ;
```

<Sample program 2>

When M0 is OFF, the conditions are met and the operation of "WL101 + 100 = WL100" is executed.



```
IF M0 = FALSE THEN
  WL100 := WL101 + 100 ;
END_IF ;
```

<Sample program 3>

When WL101 is less than 99, the conditions are met and the operation of "WL101 + 100 = WL100" is executed.



```
IF WL101 < 99 THEN
  WL100 := WL101 + 100 ;
END_IF ;
```

<Sample program 4>

When WL101 is "50 < WL 101 < 99", the conditions are met and the operation of "WL101 + 100 = WL100" is executed.



```
M0 := WL101 > 50 ;
M1 := WL101 < 99 ;
M2 := M0 AND M1 ;
IF M2 = TRUE THEN
  WL100 := WL101 + 100 ;
END_IF ;
```

Appendix 6 How to Use ST Language


< 2) IF...ELSE structure (choice between two) >

When the value of the conditional expression is "TRUE", the executable statement 1 is evaluated and when the value is "FALSE", the executable statement 2 is evaluated.

<Basic syntax>

```
IF <conditional expression> THEN
  <executable statement 1>;
ELSE
  <executable statement 2>;
END_IF;
```

<Flowchart>




< 3) IF...ELSIF structure >

When the value of the conditional expression 1 is "TRUE", the executable statement 1 is evaluated. When the value is "FALSE", the next conditional statement 2 is evaluated. Then, when the value of the conditional expression 2 is "TRUE", the executable statement 2 is evaluated. When the value is "FALSE", the conditional statement 3 is evaluated next. Thus, selectively branched processing can be realized.

<Basic syntax>

```
IF <conditional expression 1> THEN
  <executable statement 1>;
ELSIF <conditional expression 2> THEN
  <executable statement 2>;
ELSIF <conditional expression 3> THEN
  <executable statement 3>;
  ...
ELSE
  ...
END_IF;
```

<Flowchart>



Appendix 6 How to Use ST Language


(2) CASE statement

The condition expression of the CASE statement is used when the executable statement is selected by a single INT type value.

<Basic syntax>

```
CASE <conditional expression> OF
  <INT type selection value 1> :
  <executable statement 1>;
  <INT type selection value 2> :
  <executable statement 2>;
  .
  .
  .
  ELSE
  <executable statement 3>;
END_CASE;
```

<Flowchart>



<Method of expressing INT-type selection value>

INT-type selection values can be expressed by numeration or range.

- Expression by numeration ⇒ Delimit the selection values with commas (,) to register.
- Expression by range ⇒ Express the range with “..”.

Example of selection values expressed by numeration

Example of selection values expressed by range

```
1 CASE WMO OF
2 10: WLO := 0;
3 20: WL1 := WLO + 100;
4 21..29: WL1 := 100;
5 30: WLO := 101;
6 33,35,50: WL1 := WMO + WL1;
7 ELSE WL1 := 1000;
8 END_CASE;
```

Appendix 6 How to Use ST Language

Appendix 6-2-2 Iteration control statements

The iteration statement is used to execute one or more instruction repeatedly according to a certain condition.


(1) FOR statement

The FOR statement repeatedly executes the instruction (executable statement) according to the iteration count (word address).

<Basic syntax>

```
FOR <iteration count (word address)> := <initial value> TO <final value> BY <incremental value> DO  
  <executable statement>;  
END_FOR;
```

<Flowchart>



* A determination whether the iteration count has reached the final value or not is made before the executable statement. Therefore, at the instant when the iteration count has exceeded the final value, the next process begins.

Note: “-” (minus) cannot be used for the incremental value of the FOR statement. Be sure to prevent the result of the expression becoming a minus.


(2) WHILE statement

The WHILE statement repeatedly executes the executable statement while the value of the condition expression whose operation result is a BOOL type value is “TRUE”.

<Basic syntax>

```
WHILE <loop conditional expression> DO  
  <executable statement>;  
END_WHILE;
```

<Flowchart>



* Due to a loop, a determination is made before the executable statement. Therefore, if the value of the conditional expression has been “FALSE” from the beginning, the executable statement is never processed.

Appendix 6 How to Use ST Language

(3) REPEAT statement


The REPEAT statement repeatedly executes the executable statement until the value of the final conditional expression becomes "TRUE".

<Basic syntax>

```

REPEAT
  <executable statement>;
  UNTIL <final conditional expression>
END_REPEAT;
    
```

<Flowchart>



* In the REPEAT statement, a determination of the loop condition is made after the executable statement. Therefore, even if the final conditional expression is "TRUE", the executable statement is inevitably executed at least once.

(4) EXIT statement


The EXIT statement is only used in the iteration control statement (FOR, WHILE, and REPEAT statement). If the EXIT statement is executed, the loop processing can be terminated halfway through.

Appendix 6-2-3 RETURN statement

The RETURN statement is used in a user function or a user function block.

When the RETURN statement is executed, control is immediately returned from the user function or user function block to the main program.

<Flowchart of RETURN statement processing>




Appendix 6 How to Use ST Language

Appendix 6-2-4 Nesting structure of control statements

When another control statement is used in the control statement (condition statement or iteration statement), up to eight levels of nesting are allowed. (nesting structure)

<Example of nesting>

The following is an sample program of a function block operation that stores data in the INT-type array data from 1 to 100.



Note: Although up to eight levels of nesting are allowed (guaranteed operation), the program may become complicated if the nesting is deep. Therefore, when you program, it is recommended that the nesting depth should be four or five levels at the deepest.

Appendix 6 How to Use ST Language



Appendix 6-3 Operations of ST Language Editor

Appendix 6-3-1 Basic operations

(1) Adding a program


To create a program in ST language, select “ST” for the language type when the program is inserted.

- ◆ Select the position to insert a program in the project view window, and click [Edit] menu > [Insert Program]. The “Insert Program” dialog box opens. Enter a name, choose “ST” for the language, and then click the [OK] button.



Appendix 6 How to Use ST Language


- ◆ The program is added in the project view window.



(2) Programming

The basic operations for creating a program in ST language is explained below.

- ◆ Write a program in ST language on the program editing area.



- ◆ After writing a program, click [Conversion] menu > [Conversion]. The program is converted, and syntax check of ST language is also performed. If there is any syntax error, the error is displayed.


Type	Explanation	Program Name	Circuit No./Line No.	Device No.
✘	Invalid data type of the operation result!	ST1	1	
✘	Semicolon (;) is necessary for this line or the previous line.	ST1	4	

Error : 2 , Warning : 0

Appendix 6 How to Use ST Language

(3) Monitoring

A program created in ST language is monitored as shown below.



* For ST language programs, the device on the left of the assignment statement (:=) and, in the case of IF statement or WHILE statement, the leftmost device are monitored. In addition, for an FB or a function, the value of the device that is designated as the first operand is displayed.


Appendix 6 How to Use ST Language

Appendix 6-3-2 Applied operations

(1) Inserting an instruction using the wizard function

Control statements, FBs, functions can be inserted by using the wizard function.

- ◆ Place the cursor on the row to insert an instruction and then press the <F10> key, the “Instruction Enter” dialog box opens. Select a instruction and click the [OK] button to insert it as shown below. In “(* *)”, the data type of the device to be entered is displayed.



```
ST1*
1  IF WMO = 0 THEN
2      WM100 := 100;
3      WM101 := WM100;
4  END_IF;
5
6  TON_0(IN := (*BOOL*), PT := (*TIME*));
7  (*BOOL*) := T0000; (*TON.Q*)
8  (*TIME*) := T0000; (*TON.ET*)
9
```

Rewrite these with actual devices.


Appendix 6 How to Use ST Language

(2) Multi operation input wizard


In ST language, multi operators cannot be described; however, it can be changed to monomial expression if you use “Multi operation input wizard.”

- ◆ After entering multi operators on a worksheet, place the cursor on the row of multi operators. Click [Edit] menu > [Multi operation input wizard]. The “Multi operation input wizard” opens.

```
ST1*  
1 IF WM0 = 0 THEN  
2   WM100 := 100;  
3   WM101 := WM100;  
4 END_IF;  
5  
6 WM10 := (WM11 + WM12) * WM13;
```



- ◆ Assign the place displayed as “Tmp” to unused memory and then click the [OK] button.



Appendix 6 How to Use ST Language

- ◆ Multi operators are changed to monomial expression. The original multi operators are left as a comment.

```
ST1*
1  IF WM0 = 0 THEN
2      WM100 := 100;
3      WM101 := WM100;
4  END_IF;
5
6  (* WM10 := (WM11 + WM12) * WM13; *)
7  WM20 := WM11 + WM12;
8  WM10 := WM20 * WM13;
```

Appendix 6 How to Use ST Language

Appendix 6-3-3 Restrictions on program creation in ST language

(1) Display and Edit

- The indent is automatically adjusted to the fixed width.
- Blank lines are cut down and not displayed.
- A comment in a statement is displayed on another row.
- A multi-operation using two or more operators cannot be created on a single row. Use multi operation input wizard.

Appendix 7 Alternative Proposal

When using SPH2000/SPH3000 for replacement of MICREX-F series, various dedicated instructions (suffixed with “_MF”) are provided. Therefore, you do not need to read this section. Refer to “Convert Instructions (FEH588-1). SPH200/SPH300 series do not support instructions with “_MF.” Refer to the following proposals for the instructions that cannot be converted by program conversion.

Also when replacing FLEX-PC, refer to the refer to the following proposals for the instructions that cannot be converted by program conversion.

Appendix 7 Alternative Proposal

< MICREX-F series alternative proposal >

[Conversion Instructions]

Character String

[File Instructions]

Data Table Definition

Data

Data End

File Information

[Program Control Instructions]

Program Entry

Program End

Function Module Call

Function Module Start

Function Module End

[Index Register Control Instructions]

Push

Pop

Load Effective

Index Register Addition

Index Register Subtraction

* Instruction without alternative method

Appendix 7 Alternative Proposal

Character String

"Character String" instruction is not supported in SX-Programmer Standard. The alternative solution is explained.

1. The address is set by "PLC functions -> Initial data List". The character string is input to the initial value.

Appendix 7 Alternative Proposal

Data Table Definition/Data/Data End

"Data Table Definition/Data/Data End" instruction is not supported in SX-Programmer Standard. The alternative solution is explained.

"Data Table Definition/Data/Data End" is an instruction by which the user file used by the file instruction is registered as a data table, and data is set.

The data table differs from the file, and is an area only for reading.

In the alternative solution, it considers that the usual memory area is a data table, and the data between "Data Table Definition" and "Data End" is set.

Please transfer data by using "Move" instruction for a consecutive area in a usual memory area.

The characteristic only for reading has been achieved by always executing "Move" instruction.

Appendix 7 Alternative Proposal

Data Table Definition/Data/Data End Program Alternative

1	ON	MOVE	1000 →	WM 000001	0
2	ON	MOVE	2000 →	WM 000002	0
3	ON	MOVE	3000 →	WM 000003	0
4	ON	MOVE	-1000 →	WM 000004	0
5	ON	MOVE	-2000 →	WM 000005	0
6	ON	MOVE	-3000 →	WM 000006	0
7	ON	MOVE	100 →	WM 000007	0
8	ON	MOVE	200 →	WM 000008	0
9	ON	MOVE	300 →	WM 000009	0
10	ON	MOVE	-100 →	WM 00000A	0
11	ON	MOVE	-200 →	WM 00000B	0
12	ON	MOVE	-300 →	WM 00000C	0
13		END			

Appendix 7 Alternative Proposal

File Information

"File Information" instruction is not supported in SX-Programmer Standard. The alternative solution is explained.

"File Information" instruction" is an instruction to acquire the value of the changed file pointer if "FIFO" and "FIFO" instructions is executed.

The file pointer (word) is stored in the address of file area size +1 in the file area specified in First-In First-Out (FIFO) and first in last out (FILO), and acquire it in the transfer command, please.

Appendix 7 Alternative Proposal

Program Entry/Program End

"Program Entry/Program End" instruction is not supported in SX-Programmer Standard. The alternative solution is explained.

```
<<MICREX-F>>  
|-----[PROG N1: N2: N3 ]
```

"Program Entry/Program End" is an instruction to declare program initiation and the end. The program is registered in the project window in SX-Programmer Standard. Right-clicks by the program composition of the project tree displayed in the project window. "Insert" is selected, and the program is registered.

It is necessary to allocate to the task of the project tree to execute the registered program. Please register in the way according to the parameter of the program entry as follows.

N1=0:
Please allocate in the default task.

N1=50:
Please allocate in the fixed cycle task. at that time, please set the value of N2 in setting at the cycle.

N1=60 - 67:
Please allocate in the event task.

N1=510:
It is a block management division declaration not supported in SX-Programmer Standard. It is not possible to register.

N1=511:
It is a block definition declaration not supported in SX-Programmer Standard. It is not possible to register.

Appendix 7 Alternative Proposal

Function Module Call/Function Module Start/Function Module End

"Function Module Call/Function Module Start/Function Module End" instruction is not supported in SX-Programmer Standard. The alternative solution is explained.

1. "Function Module Call" can be substituted as a part call of the FB instance. Please set up the parameter set up by the DATA instruction of "Function Module Call" as parameter of part call of FB instance.
2. "Function Module Start" - "Function Module End" (Function module execution part) can be substituted as body section of the FB instance.

Appendix 7 Alternative Proposal

Push/Pop

"Push/Pop" instruction is not supported in SX-Programmer Standard. The alternative solution is explained.

In "MICREX-SX", the memory cannot be designated index.

In alternative solution, the offset based on the address stored by load effective address is stored as virtual index register. The address is not stored. Therefore, it is necessary to understand the address which the user stored.

It is possible to use only up to five of l, j, k, l, m in MICREX-F. Therefore, processing by which the content of the index register is saved is needed. But, there is no necessity in MICREX-SX only it is to memorize the offset in a usual memory area.

Therefore, even if "Push instruction" is used, the content of the index register need not be saved. Please newly set and use a virtual index register for the memory area which can be used.

Please use a virtual index register before "Push instruction" is used if "Pop instruction" is used.

<<Example>>

<<MICREX-F>>

<<Alternative solution>>

i	WM0001	: Virtual index register
---[PUSH i]---		: Nothing is done.
---[LEA BD0210: i]---	---[MOV 0 ->WM0010]---	: New virtual index

---[POP i]---		: Nothing is done.
i	WM0001	: Virtual index register before push

Appendix 7 Alternative Proposal

Load Effective Address

"Load Effective Address" instruction is not supported in SX-Programmer Standard. The alternative solution is explained.

In "MICREX-SX", the memory cannot be designated index.
Therefore, a user needs to understand the address set as the index register.

1. At instruction alternatives, the memory area used as a virtual index register is initialized by 0.
2. Please understand the address set in the index register by "MICREX-F".
(When referring to the index register, it is needed.)

Appendix 7 Alternative Proposal

Index Register Addition

"Index Register Addition" instruction is not supported in SX-Programmer Standard. The alternative solution is explained.

In "MICREX-SX", the memory cannot be designated index.
Therefore, a user needs to get to know the address set as the index register.

1. At instruction alternatives, the memory area used as a virtual index register is added.

Appendix 7 Alternative Proposal

Index Register Subtraction


"Index Register Subtraction" instruction is not supported in SX-Programmer Standard.
The alternative solution is explained.

In "MICREX-SX", the memory cannot be designated index.
Therefore, a user needs to get to know the address set as the index register.


1. At instruction alternatives, the memory area used as a virtual index register is subtracted.

Appendix 7 Alternative Proposal

Index Register Control Instructions Program Alternative



Appendix 7 Alternative Proposal



Appendix 7 Alternative Proposal

Instruction without alternative method(MICREX-F)

There is not an alternative method of the following instructions.

- Block Diagram
- Conversion to Seconds (SEC)
- Conversion from Seconds (TIM)
- Disabled/Enabled interrupted (DI, EI)

Appendix 7 Alternative Proposal

< FLEX-PC series alternative proposal >

[Basic Control Instructions]

Direct Input/Output

[Program flow Instructions]

Interruption pointer/End of Interrupt program

User Macro Commands

[Comparison Instructions]

Comparison

Double Comparison

[Range Comparison Instructions]

Range Comparison

Double Range Comparison

[Transfer Instructions]

8Bit Transfer

Digit Transfer

[Rotate/Shift/32Bit Rotate Instructions]

Rotate Right Carry n

Rotate Left Carry n

Double Rotate Right Carry n

Double Rotate Left Carry n

[Step Control Instructions]

Step Control

[Real Instructions]

Real Comparison

Real Range Comparison

[Time Instructions]

Time Comparison

Time Range Comparison

[Some instructions]

Some instructions which can not be pasted

* Instruction without alternative method

Appendix 7 Alternative Proposal

Direct Input/Output

"Direct Input/Output" instruction is not supported in SX-Programmer Standard. The alternative solution is explained.

1. The fixed cycle task is made according to the procedure of "Make of the fixed cycle task."
2. In this case, please set the priority of the task setting as high as possible (cyclic 0>3>task).
3. Program made by processing 1 is arranged in the fixed cycle task according to the procedure of "Registration of the program".
4. The time of the SX bus baton is set according to the procedure of "Set of the time of the baton".

Appendix 7 Alternative Proposal

Interruption pointer/End of Interrupt program

"Interruption pointer/End of Interrupt program" instruction is not supported in SX-Programmer Standard. The alternative solution is explained.

1. Make a program from "Interruption pointer" to " End of Interrupt program " into program.

[In case of fixed-cycle interrupt]

2. The fixed cycle task is made according to the procedure of "Make of the fixed cycle task."

3. Program made by processing 1 is arranged in the fixed cycle task according to the procedure of "Registration of the program."

[In case of interrupt by an interrupt module or counter count-up]

2. The event task is made according to the procedure of "Make of the event task."

3. Program made by processing 1 is arranged in the event task according to the procedure of "Registration of the program."

Appendix 7 Alternative Proposal

User macro commands

User macro commands instruction is not supported in SX-Programmer Standard. The alternative solution is explained.


1. The I/O parameter is set, and user macro commands caller program is converted into the call part of the FB instance.
2. The I/O parameter is set, and user macro commands executor program is converted into the body part of the FB instance.

Appendix 7 Alternative Proposal


User macro commands Program Alternative

[User macro commands caller program is alternative into the call part of the FB instance]

<< FLEX-PC N >>




<< MICREX-SX >>




Appendix 7 Alternative Proposal

[User macro commands executor program is alternative into the body part of the FB instance]

<< FLEX-PC N >>



<< MICREX-SX >>



Appendix 7 Alternative Proposal

Comparison

"Comparison" instruction is not supported in SX-Programmer Standard. The alternative solution is explained.

1. New program(FB) is made, and the input parameter(origin of comparison, destination of comparison) I/O parameter (comparison result flag1, 2) is set.
2. When it is "origin of comparison > destination of comparison," comparison result flag1 and comparison result flag2 are set in "OFF."
3. When it is "origin of comparison = destination of comparison," comparison result flag1 is set in "ON" and, comparison result flag2 is set in "OFF."
4. When it is "origin of comparison < destination of comparison," comparison result flag1 is set in "OFF" and, comparison result flag2 is set in "ON."

The following figures show the relation between the above-mentioned comparison result flag 1, 2.

Big and small relation	Comparison result flag1	Comparison result flag2
Origin of comparison > destination of comparison	OFF	OFF
Origin of comparison = destination of comparison	ON	OFF
Origin of comparison < destination of comparison	OFF	ON

<< FLEX-PC N >>

Seizing signal

|--] [-----[CMP S1 S2]-|


S1: Origin of comparison

S2: Destination of comparison

↓


Appendix 7 Alternative Proposal

<<Call processing when making to FB with SX-Programmer Standard>>



Appendix 7 Alternative Proposal

Comparison Program Alternative



Appendix 7 Alternative Proposal

Double Comparison

"Double Comparison" instruction is not supported in SX-Programmer Standard. The alternative solution is explained.

1. New program(FB) is made, and the input parameter (origin of comparison, destination of comparison) I/O parameter (comparison result flag1, 2) is set.
2. When it is "origin of comparison > destination of comparison," comparison result flag1 and comparison result flag2 are set in "OFF."
3. When it is "origin of comparison = destination of comparison," comparison result flag1 is set in "ON" and, comparison result flag2 is set in "OFF."
4. When it is "origin of comparison < destination of comparison," comparison result flag1 is set in "OFF" and, comparison result flag2 is set in "ON."

The following figures show the relation between the above-mentioned comparison result flag1, 2.

Big and small relation	Comparison result flag1	Comparison result flag2
Origin of comparison > destination of comparison	OFF	OFF
Origin of comparison = destination of comparison	ON	OFF
Origin of comparison < destination of comparison	OFF	ON

<< FLEX-PC N >>

Seizing signal

|---] [-----[DCMP S1 S2]-|


S1: Origin of comparison

S2: Destination of comparison



Appendix 7 Alternative Proposal

<<Call processing when making to FB with SX-Programmer Standard>>



Appendix 7 Alternative Proposal

Range Comparison

"Range Comparison" instruction is not supported in SX-Programmer Standard. The alternative solution is explained.

1. New program(FB) is made, and the input parameter(origin of comparison1, 2, destination of comparison) I/O parameter (comparison result flag1, 2, 3) is set.
2. When it is "origin of comparison1 > destination of comparison," comparison result flag1 is set in "ON" and, comparison result flag2, 3 is set in "OFF."
3. When it is "origin of comparison 1 <= destination of comparison," and "destination of comparison <= origin of comparison2," comparison result flag2 is set in "ON" and, comparison result flag1, 3 is set in "OFF."
4. When it is "destination of comparison > origin of comparison2," comparison result flag3 is set in "ON" and, comparison result flag1, 2 is set in "OFF."

The following figures show the relation between the above-mentioned comparison result flag1, 2, 3.

Big and small relation	Comparison result flag 1	Comparison result flag 2	Comparison result flag 3
Origin of comparison1 > destination of comparison	ON	OFF	OFF
Origin of comparison1 <= destination of comparison and destination of comparison <= Origin of comparison2	OFF	ON	OFF
Destination of comparison > Origin of comparison2	OFF	OFF	ON

<< FLEX-PC N >>

Seizing signal

|---] [-----[ZCP S1 S2 S]-|

S1: Origin of comparison1


S2: Origin of comparison2

S : Destination of comparison

↓


Appendix 7 Alternative Proposal

<<Call processing when making to FB with SX-Programmer Standard>>



Appendix 7 Alternative Proposal

Range Comparison Program Alternative



Appendix 7 Alternative Proposal

Double Range Comparison

"Double Range Comparison" instruction is not supported in SX-Programmer Standard.
The alternative solution is explained.

1. New program(FB) is made, and the input parameter(origin of comparison1, 2, destination of comparison) I/O parameter (comparison result flag1, 2, 3) is set.
2. When it is "origin of comparison1 > destination of comparison," comparison result flag1 is set in "ON" and, comparison result flag2, 3 is set in "OFF."
3. When it is "origin of comparison1 <= destination of comparison," and "destination of comparison <= origin of comparison2," comparison result flag2 is set in "ON" and, comparison result flag1, 3 is set in OFF."
4. When it is "destination of comparison > origin of comparison2", comparison result flag3 is set in "ON" and, comparison result flag1, 2 is set in "OFF."

The following figures show the relation between the above-mentioned comparison result flag1, 2, 3.

Big and small relation	Comparison result flag 1	Comparison result flag 2	Comparison result flag 3
Origin of comparison1 > destination of comparison	ON	OFF	OFF
Origin of comparison1 <= destination of comparison and destination of comparison <= Origin of comparison2	OFF	ON	OFF
Destination of comparison > Origin of comparison2	OFF	OFF	ON

<< FLEX-PC N >>

Seizing Signal

|---| [-----] [DZCP S1 S2 S]-|

S1: Origin of comparison1


S2: Origin of comparison2

S : Destination of comparison

↓

Appendix 7 Alternative Proposal

<<Call processing when making to FB with SX-Programmer Standard>>



Appendix 7 Alternative Proposal

8Bit Transfer


"8Bit Transfer" instruction is not supported in SX-Programmer Standard. The alternative solution is explained.

1. The logical product of the eight high-order bits or the eight low-order bits of origin of transfer is done.
 - * This processing extracts the origin of transfer eight high-order bits or eight low-order bits.
2. After the logical product is done, shifts left or right by 8bits.
3. The logical product of the eight high-order bits or the eight low-order bits of destination of transfer is done.
 - * This processing delete the destination of transfer eight high-order bits or eight low-order bits.
4. The logical add to data which did shift processing and destination of transfer is done.
 - * This processing is origin of transfer high rank byte or the eight low-order bits is forwarded to destination of transfer the eight high-order bits or the eight low-order bits.

Appendix 7 Alternative Proposal

8Bit Transfer Program Alternative


Example 1) When it is a origin of transfer is the eight high-order bits and destination of transfer is the eight low-order bits



Appendix 7 Alternative Proposal

8Bit Transfer Program Alternative


Example 2) When it is a origin of transfer is the eight low-order bits and destination of transfer is the eight high-order bits



Appendix 7 Alternative Proposal

8Bit Transfer Program Alternative


Example 3) When it is a origin of transfer is the eight high-order bits and destination of transfer is the eight high-order bits



Appendix 7 Alternative Proposal

8Bit Transfer Program Alternative

Example 4) When it is a origin of transfer is the eight low-order bits and destination of transfer is the eight low-order bits



Appendix 7 Alternative Proposal

Digit Transfer

"Digit Transfer" instruction is not supported in SX-Programmer Standard. The alternative solution is explained.

1. The logical product is done to digit of data which transfer a origin of transfer.
 - * This processing extracts necessary data from digit of the transfer data.
2. Right or left shifts to digit where data which did the logical product is transfer
3. The logical product is done to destination of transfer digit in the destination of transfer
 - * This processing delete destination of transfer digit.
4. The logical add to data which did shift processing and destination of transfer is done.
 - * This processing is forwarded to specified digit in the destination of transfer.

Appendix 7 Alternative Proposal

Digit Transfer Program Alternative

Example 1) The first digit from the third digit transfer from origin of transfer to the first digit of the destination of transfer

1	Example 1) The first digit from the third digit (unit of four bits) transfer from origin of transfer "WM000001" to the first digit (unit of four bits) of the destination of transfer "WM000003".			
	The first digit from the third digit is extracted from origin of transfer "WM000001".			
	M	WM	WM	
	000001	000001	000002	
2]	AND_AW	H0000	H0F00 → H0000
3	The work area "WM000002" is shifted right by eight bits.			
	M	WM	WM	
	000001	000002	000002	
4]	SHR	H0000	8 → H0000
5	The first digit of the destination of transfer "WM000003" is deleted.			
	M	WM	WM	
	000001	000003	000003	
6]	AND_AW	H0000	HFFF0 → H0000
7	The work area "WM000002" is transported to the destination of transfer "WM000003".			
	M	WM	WM	WM
	000001	000002	000003	000003
8]	OR_AW	H0000	H0000 → H0000
9	END			

Appendix 7 Alternative Proposal

Digit Transfer Program Alternative

Example 2) Two digits from the second digit transfer from origin of transfer to the fourth digit of the destination of transfer

1	<p>Example)2 Two digits from the second digit(unit of four bits) transfer from origin of transfer "WM000005" to the fourth digit(unit of four bits) of the destination of transfer "WM000007".</p> <p>Two digits from the second digit are extracted from origin of transfer "WM000005".</p>			
	M	WM	WM	
	000002	000005	000006	
2] [AND_AW	H0000	H0FF0 → H0000
3	The work area "WM000006" is shifted left by four bits.			
	M	WM	WM	
	000002	000006	000006	
4] [SHL	H0000	4 → H0000
5	The third digits and fourth digits of origin of transfer "WM000007" are deleted.			
	M	WM	WM	
	000002	000007	000007	
6] [AND_AW	H0000	H00FF → H0000
7	The work area "WM000006" is transported to the destination of transfer "WM000007".			
	M	WM	WM	WM
	000002	000006	000007	000007
8] [OR_AW	H0000	H0000 → H0000
9	END			

Appendix 7 Alternative Proposal

Rotate Right Carry n

"Rotate Right Carry n" instruction is not supported in SX-Programmer Standard. The alternative solution is explained.

1. "Rotation data" is stored in "Temporary."
2. The 0th bit of "Temporary" is stored in "Carry flag."
3. "Temporary" is shifted right by 1 bit.
4. When "Carry flag" is "ON," the 16th bit of "Temporary" is turned on.
5. When "Carry flag" is "OFF," the 16th bit of "Temporary" is turned off.
6. Processing 2-5 is repeated the number of times of "No. of rotate bits."
7. Data which did the shift processing is stored in "Rotation data" again.

<< FLEX-PC N >>

Conditional contact

|--| [-----] [NRGR D , n]--|


D : Device in which data is to be rotated

n : A number of bits by which data is to be rotated

↓

Appendix 7 Alternative Proposal


<<Call processing when making to FB with SX-Programmer Standard>>



[Variable Explanation]
DF000A: Temporary

Appendix 7 Alternative Proposal

Rotate Right Carry n Program Alternative



Appendix 7 Alternative Proposal

Rotate Left Carry n

"Rotate Left Carry n" instruction is not supported in SX-Programmer Standard. The alternative solution is explained.

1. "Rotation data" is stored in "Temporary."
2. SLC instruction is done to "Temporary."
3. The 16th bit of "Temporary" is stored in "Carry flag."
4. Processing 2-3 is repeated the number of times of "No. of rotate bits."
5. Data which did the shift processing is stored in "Rotation data" again.

<<FLEX-PC N>>

Conditional contact

|---| [-----] [NRCL D , n]-|


D : Device in which data is to be rotated

n : A number of bits by which data is to be rotated



Appendix 7 Alternative Proposal


<<Call processing when making to FB with SX-Programmer Standard>>



[Variable Explanation]
DM000A: Temporary

Appendix 7 Alternative Proposal

Rotate Left Carry n Program Alternative



Appendix 7 Alternative Proposal

Double Rotate Right Carry n

“Double Rotate Right Carry n” instruction is not supported in SX-Programmer Standard.
The alternative solution is explained.

1. “Rotation data” is stored in “Temporary1.”
2. SRC instruction is done to “Temporary1,” and it is output to “Temporary2.”
3. “Carry flag” of “Temporary1” is output.
4. “Temporary2” is stored in “Temporary1.”
5. Processing 2-4 is repeated the number of times of “No. of rotate bits.”
6. Data which did the shift processing is stored in “Rotation data” again.

<<FLEX-PC N>>

Conditional contact

|---| [-----] [DNR CR D n]-|


D : Device in which data is to be rotated

n : A number of bits by which data is to be rotated



Appendix 7 Alternative Proposal

<<Call processing when making to FB with SX-Programmer Standard>>




[Variable Explanation]

DF000A: Temporary

DF000C: Temporary

Appendix 7 Alternative Proposal

Double Rotate Right Carry n Program Alternative



Appendix 7 Alternative Proposal

Double Rotate Left Carry n

"Double Rotate Left Carry n" instruction is not supported in SX-Programmer Standard. The alternative solution is explained.

1. "Rotation data" is stored in "Temporary1."
2. SLC instruction is done to "Temporary1," and it is output to "Temporary2."
3. "Carry flag" of "Temporary1" is output.
4. "Temporary22 is stored in "Temporary1."
5. Processing 2-4 is repeated the number of times of "No. of rotate bits."
6. Data which did the shift processing is stored in "Rotation data" again.

<<FLEX-PC N>>

Conditional contact

|---] [-----] [DNRCL D n]-|


D : Device in which data is to be rotated

n : A number of bits by which data is to be rotated



Appendix 7 Alternative Proposal

<<Call processing when making to FB with SX-Programmer Standard>>



[Variable Explanation]

DF000A: Temporary

DF000C: Temporary

Appendix 7 Alternative Proposal

Double Rotate Left Carry n Program Alternative

1	The data is stored in Temporary.			
	Conditio		Rotation	Temporar
	nal		data	Y
	V		DV	DF
	0001		0002	000A
2] [MOVE	→	
3	repeats for No. of rotate bits.			
	Conditio			No of ro
	nal			tate bit
	V			DV
	0001			0003
4] [LOOP	
5	shifts left.			
	Conditio	Temporar	Carry fl	Temporar
	nal	Y	ag	Y
	V	DF	V	DF
	0001	000A	0004	000C
6] [SLC	→	
7	The carry flag is output.			
	Conditio		Temporar	Carry fl
	nal		Y	ag
	V		DF	V
	0001		000A	0004
8] [SLCO	→
9	Data which did the shift processing is made the latest data.			
	Conditio	Temporar		Temporar
	nal	Y		Y
	V	DF		DF
	0001	000C		000A
10] [MOVE	→	
11				CONT
12	Data which ends the shift processing is stored in the parameter.			
	Conditio	Temporar		Rotation
	nal	Y		data
	V	DF		DV
	0001	000A		0002
13] [MOVE	→	
14		END		

Appendix 7 Alternative Proposal

Step Control


"Step Control" instruction is not supported in SX-Programmer Standard. The alternative solution is explained.

"Step Control" instruction is achieved by "S" device in SX-Programmer Standard.

The group number and the step number which wants to control are set to "S" device of the step control instruction.

Appendix 7 Alternative Proposal

Step Control Program Alternative



Appendix 7 Alternative Proposal

Real Comparison

"Real Comparison" instruction is not supported in SX-Programmer Standard. The alternative solution is explained.

1. New program(FB) is made, and the input parameter(origin of comparison, destination of comparison) I/O parameter (comparison result flag1,2) is set.
2. When it is "origin of comparison > destination of comparison," comparison result flag1 and comparison result flag2 are set in "OFF."
3. When it is "origin of comparison = destination of comparison," comparison result flag1 is set in "ON" and, comparison result flag2 is set in "OFF."
4. When it is "origin of comparison < destination of comparison," comparison result flag1 is set in "OFF" and, comparison result flag2 is set in "ON."

The following figures show the relation between the above-mentioned comparison result flag1, 2.

Big and small relation	Comparison result flag1	Comparison result flag2
Origin of comparison > destination of comparison	OFF	OFF
Origin of comparison = destination of comparison	ON	OFF
Origin of comparison < destination of comparison	OFF	ON

<<FLEX-PC N>>

Seizing signal

|---| [-----] [ECMP S1 S2]-|


S1 : Origin of comparison

S2 : Destination of comparison



Appendix 7 Alternative Proposal

<<Call processing when making to FB with SX-Programmer Standard>>



Appendix 7 Alternative Proposal

Real Comparison Program Alternative

1	When relation condition is "Truth", the output parameter "V0003" and "V0004" are made "OFF".	Comparis on Addre DV 0001	Comparis on Addre DV 0002	Comparis on Flag V 0003
2	R>			(R)
3	When relation condition is "Truth", the output parameter "V0003" is made "ON".	Comparis on Addre DV 0001	Comparis on Addre DV 0002	Comparis on Flag V 0004
4	R=			(R)
5	When relation condition is "Truth", the output parameter "V0004" is made "ON".	Comparis on Addre DV 0001	Comparis on Addre DV 0002	Comparis on Flag V 0003
6	R<			(S)
7				END

Appendix 7 Alternative Proposal

Real Range Comparison

“Real Range Comparison” instruction is not supported in SX-Programmer Standard. The alternative solution is explained.

1. New program(FB) is made, and the input parameter(origin of comparison1, 2, destination of comparison) I/O parameter (comparison result flag1, 2, 3) is set.
2. When it is “origin of comparison1 > destination of comparison,” comparison result flag1 is set in "ON" and, comparison result flag2, 3 is set in “OFF.”
3. When it is “origin of comparison1 <= destination of comparison,” and “destination of comparison <= origin of comparison2,” comparison result flag2 is set in "ON" and, comparison result flag1, 3 is set in “OFF.”
4. When it is “destination of comparison > origin of comparison2,” comparison result flag3 is set in "ON" and, comparison result flag1, 2 is set in OFF.”

The following figures show the relation between the above-mentioned comparison result flag1, 2.

Big and small relation	Comparison result flag 1	Comparison result flag 2	Comparison result flag 3
Origin of comparison1 > destination of comparison	ON	OFF	OFF
Origin of comparison1 <= destination of comparison and destination of comparison <= Origin of comparison2	OFF	ON	OFF
Destination of comparison > Origin of comparison2	OFF	OFF	ON

<<FLEX-PC N>>

Seizing signal

|---] [-----] [EZCP S1 S2 S]-|

S1 : Origin of comparison1


S2 : Origin of comparison2

S : Destination of comparison

↓


Appendix 7 Alternative Proposal

<<Call processing when making to FB with SX-Programmer Standard>>



Appendix 7 Alternative Proposal

Real Range Comparison Program Alternative



Appendix 7 Alternative Proposal

Time Comparison

"Time Comparison" instruction is not supported in SX-Programmer Standard. The alternative solution is explained.

1. New program(FB) is made, and the input parameter(origin of comparison(Hour, Minute, Second), destination of comparison (Hour, Minute, Second)) I/O parameter(comparison result flag1, 2) is set.
2. When it is "origin of comparison(Hour) > destination of comparison(Hour)," comparison result flag1 and comparison result flag2 are set in "OFF."
3. When it is "destination of comparison(Hour) > origin of comparison(Hour)," comparison result flag2 is set in "ON" and, comparison result flag1 is set in "OFF."
4. It is set that result1 of the comparison between "origin of comparison(Minute)" and "destination of comparison(Minute)" at "origin of comparison(Hour) = destination of comparison(Hour)" referring to processing1, 2. And it is set that result1 of the comparison between "origin of comparison(Second)" and "destination of comparison(Second)" at "origin of comparison(Minute) = destination of comparison(Minute)" referring to processing1, 2. As a result, when it is "origin of comparison(Hour, Minute, Second) = destination of comparison(Hour, Minute, Second)", comparison result flag1 is made "ON", and comparison result flag2 is made "OFF."

The following figures show the relation between the above-mentioned comparison result flag1, 2.

Big and small relation	Comparison result flag1	Comparison result flag2
Origin of comparison > destination of comparison	OFF	OFF
Origin of comparison = destination of comparison	ON	OFF
Origin of comparison < destination of comparison	OFF	ON

<<FLEX-PC N>>

Seizing signal

|---| [-----] [TCMP S1 S2 S3 S]-|

S1 : Origin of comparison (Hour)

S2 : Origin of comparison (Minute)


S3 : Origin of comparison (Second)

S : Destination of comparison

↓


Appendix 7 Alternative Proposal

<<Call processing when making to FB with SX-Programmer Standard>>




Appendix 7 Alternative Proposal


Time Comparison Program Alternative



Appendix 7 Alternative Proposal



Appendix 7 Alternative Proposal



Appendix 7 Alternative Proposal

Time Range Comparison

"Time Range Comparison" instruction is not supported in SX-Programmer Standard. The alternative solution is explained.

1. New program(FB) is made, and the input parameter(origin of comparison1- 1, 2, 3(Hour, Minute, Second), origin of comparison2- 1, 2, 3(Hour, Minute, Second), destination of comparison(Hour, Minute, Second)) I/O parameter(comparison result flag1, 2, 3, 4) is set.
2. Comparison result flag1 is set in "OFF."
3. Comparison result flag2 is set in "OFF."
4. Comparison result flag3 is set in "OFF."
5. Comparison result flag4 is set in "OFF."
6. When it is "origin of comparison1- 1(Hour) > destination of comparison2- 1(Hour)," comparison result flag1 is set in "ON."
7. When it is "origin of comparison1- 1(Hour) = origin of comparison2- 1(Hour)" and "origin of comparison1- 2(Minute) > origin of comparison2- 1(Minute)," comparison result flag1 is set in "ON." And when it is "origin of comparison1- 2(Minute) = origin of comparison2- 2(Minute)," "origin of comparison1- 3(Second) > origin of comparison2- 3(Second)" is compared. When the result is "True," comparison result flag1 is made "ON."
8. When comparison result flag1 is "ON," FB is ended.
9. When it is "origin of comparison1- 1(Hour) > destination of comparison(Hour)," comparison result flag2 is set in "ON."
10. When it is "origin of comparison1- 1(Hour) = destination of comparison(Hour)" and "origin of comparison1- 2(Minute) > destination of comparison(Minute)," comparison result flag1 is set in "ON." And when it is "origin of comparison1- 2(Minute) = destination of comparison(Minute)," "origin of comparison1- 3(Second) > destination of comparison(Second)" is compared. When the result is "True," comparison result flag2 is made "ON."
11. When comparison result flag2 is "ON," FB is ended.
12. When it is "destination of comparison(Hour) > origin of comparison2- 1(Hour)," comparison result flag3 is set in "ON."
13. When it is "destination of comparison(Hour) = origin of comparison2- 1(Hour)" and "destination of comparison(Minute) > origin of comparison2- 2(Minute)," comparison result flag3 is set in "ON". And when it is "destination of comparison(Minute) = origin of comparison2- 2(Minute)," "destination of comparison(Second) > origin of comparison2- 3(Second)" is compared. When the result is "True", comparison result flag3 is made "ON."
14. When comparison result flag3 is "ON," FB is ended.
15. Comparison result flag4 is set in "ON" * Comparison result flag1, 2, 3 becomes "OFF" it and " origin of comparison1(Hour, Minute, Second) <= destination of comparison(Hour, Minute, Second) <= origin of comparison2(Hour, Minute, Second)" because of current processing.

Appendix 7 Alternative Proposal

The following figures show the relation between the above-mentioned comparison result flag1, 2, 3, 4.

Big and small relation	Comparison result flag1	Comparison result flag2	Comparison result flag3	Comparison result flag4
Origin of comparison1(Hour, Minute, Second) > origin of comparison2(Hour, Minute, Second)	ON	OFF	OFF	OFF
Origin of comparison1(Hour, Minute, Second) > destination of comparison(Hour, Minute, Second)	OFF	ON	OFF	OFF
Origin of comparison1(Hour, Minute, Second) <=destination of comparison(Hour, Minute, Second) <=origin of comparison2(Hour, Minute, Second)	OFF	OFF	ON	OFF
destination of comparison (Hour, Minute, Second) > origin of comparison2(Hour, Minute, Second)	OFF	OFF	OFF	ON

<<FLEX-PC N>>

Seizing signal

|--] [-----] [TZCP S1 S2 S]-|

S1 : Origin of comparison1 (Hour, Minute, Second)

S2 : Origin of comparison2 (Hour, Minute, Second)

S : Destination of comparison (Hour, Minute, Second)

↓


Appendix 7 Alternative Proposal

<<Call processing when making to FB with SX-Programmer Standard>>


	USERFB	TZCMP	0	
WM0	WV1 IN1			
WM1	WV2 IN2			
WM2	WV3 IN3			
WM3	WV4 IN4			
WM4	WV5 IN5			
WM5	WV6 IN6			
WM6	WV7 IN7			
WM7	WV8 IN8			
WM8	WV9 IN9			
M100	V10 IN10	————	V10 IN10	M100
M200	V11 IN11	————	V11 IN11	M200
M300	V12 IN12	————	V12 IN12	M300

Appendix 7 Alternative Proposal


Time Range Comparison Program Alternative



Appendix 7 Alternative Proposal



Appendix 7 Alternative Proposal



Appendix 7 Alternative Proposal

Some instructions which can not be pasted

When the connection and comparison instructions are included in a ladder line where the following instructions are included and for a parallel output, the instructions are not pasted.

- Increment on Rising Edge (INCP)
- Double Increment on Rising Edge (DINCP)
- Decrement on Rising Edge (DECP)
- Double Decrement on Rising Edge (DDECP)
- Output rising differential (PLS)
- Output falling differential (PLF)
- Transfer Message (MSGT)
- Receive Message (MSGR)
- Stores a file (FFST)
- First-in first-out control (FIFO)
- First-in last-out control (FILO)
- Pulse Train Output 1 (PLS1)
- Double Pulse Train Output 1 (DPLS1)
- Pulse Train Output 2 (PLS2)
- Double Pulse Train Output 2 (DPLS2)
- Pulse Width Modulation 1 (PWM1)
- Pulse Width Modulation 2 (PWM2)

When it is possible to paste it, it replaces with the following instructions. Please edit the program referring to this.

Note: The operation execution result might be different from the original Line's. So modify the pasted line referring to the original line.


FLEX-PC	MICREX-SX
Increment on Rising Edge (INCP)	Addition
Double Increment on Rising Edge (DINCP)	Addition
Decrement on Rising Edge (DECP)	Subtraction
Double Decrement on Rising Edge (DDECP)	Subtraction
Output rising differential (PLS)	Rising edge trigger
Output falling differential (PLF)	Falling edge trigger
Transfer Message (MSGT)	Send message
Receive Message (MSGR)	Receive message
Stores a file (FFST)	Sequential file store
First-in first-out control (FIFO)	Sequential file load first
First-in last-out control (FILO)	Sequential file load last
Pulse Train Output 1 (PLS1)	Pulse output
Double Pulse Train Output 1 (DPLS1)	Pulse output
Pulse Train Output 2 (PLS2)	Pulse output
Double Pulse Train Output 2 (DPLS2)	Pulse output
Pulse Width Modulation 1 (PWM1)	Pulse output
Pulse Width Modulation 2 (PWM2)	Pulse output

Appendix 7 Alternative Proposal


Please refer to the following examples.

[Example of pasting the Increment on Rising Edge]

[FLEX-PC]




[MICREX-SX]




[Example of pasting the Output rising differential]

[FLEX-PC]



[MICREX-SX]

The case of using M000030 as a start signal.



Appendix 7 Alternative Proposal


Instruction without alternative method (FLEX-PC)

There is not an alternative method of the following instructions.

- HEX to ASCII (ASCI)
- ASCII to HEX (HEX)
- Convert to Secs (SEC)
- Convert to HMS (HMS)
- Option Init (OPDF)
- Data instruction (DATAB, DATAM)
- Status set/reset (SLT, SLTR)
- Trace set/reset (STRA, STRAR)
- Real Bin to Decimal (EBCD)
- Real Decimal to Bin (EBIN)
- Read Time/Write Time (TRD, TWR)
- Pulse Train Output I (PLSI, DPLSI)
- Pulse Train Output A (PLSA, DPLSA)
- Zero Return (ORG, DORG)
- Ramp Output (RAMP)
- PID Calculation (PID)
- Manipulates the bit data (ABSD, INCD)
- Matrix Read (MTR)
- Digital Switch (DSW)
- 7 Segment Displays (SEGL)
- SFC instructions

Appendix 8 Project View

In the “Project View” window, the entire SX project is structured and displayed. This section explains each item displayed in the Project View window.



Project:

This is the parent folder of a project. The name of a currently opened project is displayed.

System Definition:

When you click this, the system definition screen opens. For more details, refer to “Section 3 System Definition.”

Resource:

This is the CPU module. When you right-click this, you can make settings about conversion. For more details, refer to “Appendix 8-1 Resource.”

Programs:

This is the parent folder of programs. Register tasks directly under this folder.

Default:

This is the folder for the default task. Programs assigned under this folder (ladder0 in the above figure) are cyclically executed.

Fixed:

This is the folder for the periodic task. Programs assigned under this folder are executed at a specified period. Right-click this and then select “Properties” to set the cycle and priority.

Event:

This is the folder for the event task. Programs assigned under this folder are executed at the rising edge of the specified event address. Right-click this and then select “Properties” to set the event address and priority.

Device:

You can open the list of devices, on which tags, description, initial values can be edited and use status of the devices can be listed. For more details, refer to “Appendix 8-2 Device.”

Unassigned Programs:

Programs assigned here are invalid and not loaded to the PLC.

Function Blocks:

Function blocks (FB) created by a user are registered here. You can also import and register expansion FBs provided by Fuji Electric. When converting a MICREX-F program, the loader system automatically registers FBs for conversion.

Simulation:

This folder is used for the simulation function. For more details, refer to “Appendix 3 Simulator Function.”

Array/Struct:

Arrays and structures are defined. For more details, refer to “Appendix 4 Arrays/Structures.”

File Defines:

Used in pairs with a file instruction (incl. FFST_MF, FIFO_MF, and FILO_MF). If a file instruction is included in a MICREX-F program that is converted, they are automatically defined.


Appendix 8 Project View

Appendix 8-1 Resource

Right-click the Resource icon to open the “Resource Properties” or “Optimization setting” dialog box.

(1) Property

When converting a MICREX-F program, the optimum settings are made automatically on the “Resource Properties” dialog box. The “Resource Properties” dialog box is only supported by SPH2000/SPH3000 series. (Not usable in SPH200/SPH300 series.)



- Permit the use of index register ⇒ Check this option to use index register instructions.
- Bit reverse ⇒ Specify the bit operation when the pointer of an index register is added or subtracted.
When checked: The same bit operation as MICREX-F. In the case of index register addition, the offset address is moved to the right (to the low-order).
When unchecked: The same bit operation as MICREX-SX. In the case of index register subtraction, the offset address is moved to the left (to the high-order).
- Permit the use of Timer/Counter MF ⇒ Check this option to use timer and counter instructions suffixed with “_MF.” The operation of these instructions is same as MICREX-F. 11072 (approx. 11K) words of the user FB memory is used.
- Permit the use of temporary area and save area for task switch ⇒ This option is automatically checked when a MICREX-F program is converted. The temporary area is reserved to make the program operation same as MICREX-F.
- Step control treated as a BCD value ⇒ Check this option to treat data as BCD when the step control memory is used as a word (WS). When unchecked, data is treated as decimal.

Appendix 8 Project View

(2) Optimization setting

The “Optimization setting” dialog box is only supported by SPH3000 series.

SPH3000 is provided with two types of POU execution areas (high-speed/default). You can choose an area to which each POU is assigned. Programs assigned to the high-speed area are executed faster than those assigned to the default area. In addition, if you select “Valid,” the program code is optimized to enable faster program execution.


The default setting is “Invalid.” In this case, program optimization is not performed. Programs are automatically assigned to the high-speed program area in order from the top.

When you change this setting, you need to execute [Conversion] > [Conversion All] to load the program to the PLC. (Stop the PLC and transfer the program.)

It is not possible to optimize programs that have instructions suffixed with “_MF” (incl. TON_MF and MOVE_MF) that are automatically used for conversion of a MICREX-F program. Select “Invalid” for such programs.

How to make optimization settings

- ◆ Right-click the Resource icon, and then select [Optimize]. The following dialog box opens.
Select an “Optimize Option.”



- Valid ⇒ All the programs (including function blocks) are optimized.
- Individual ⇒ You can select which program to optimize.
- Invalid: (default) ⇒ None of the programs (including function blocks) are optimized.

When you select “Valid” or “Individual” for optimize option, the execution time of the “Conversion All” command is three to ten times longer than when “Invalid” is selected. The warning message appears on the loader screen.


Appendix 8 Project View

◆ Click the [Setting] button. The “Option setting” dialog box opens.

Calling structure of programs and FBs is displayed.

Select “Valid” or “Invalid” of optimization.

Select an area to assign the program: “High-speed” or “Default” (See *1 and *2.)



*1 To change these settings, uncheck “The placement of all POU are automatic setting” in the [Setting] menu. It is checked by default.

*2 The program is automatically assigned to the high-speed area within the range of the memory size. If there is not enough memory size, the program is assigned to the default area.

◆ On the dialog box above, you can choose “Valid” or “Invalid” for optimization and “High-speed” or “Default” area for placement for each program.

After setting each item, click [File] menu > [Exit] to return to the “Optimization setting” dialog box. Click the [OK] button there. The following dialog box appears.



Click the [OK] button to complete the setting.


Make sure to execute [Conversion All] in the [Conversion] menu before loading the program to the PLC. Stop the PLC to load the program to it. (A program cannot be changed while the PLC is running.)

Appendix 8 Project View

Appendix 8-2 Device

Double-click the Device icon to open the device window. Tags and descriptions edited on this window are reflected in the ladder circuit. Devices displayed here are common devices of the programs in a project and called "global device." They are used to edit the tags in a batch.

You cannot check the ON/OFF status of the devices on this window. To check it, use the monitoring function; click [Online] menu > [Data Monitor] > [Data Monitor 1].



<Character limit on a tag>

A tag can be up to 32 characters. The following symbols and character strings cannot be used:

Symbols "#," "\" (backslash), ",", and "." (period)

A character string consisting only of numerical values (including a decimal number, a hexadecimal number, and a number starting with a plus (+) or minus (-) sign

The same character string as the device address

The same character string as the array expression (e.g. DATA[1])

<Character limit on description>

A description can be up to 50 characters. A comma (,) cannot be used.

- [Device Type] selection button ⇔ This button is used to switch the displayed devices.

X, WX, DX: Input memory

Y, WY, DY: Output memory

M, WM, DM: Internal memory (non retained)

L, WL, DL: Internal memory (retain)

SM, WSM, DSM: System memory

T: Timer

The target are TON, TOF, TP and MR. The range is T8192 to T16383.

C: Counter

The target are CTU, CTD, and RCT. The range is C8192 to C16383.

TR: Integrating timer

The target is TMR.

N: Section instruction

S, WS: Step control

GM: Global memory

The target are the processor-link memory of P-link, PE-link, or FL-net.

TM: MF timer

The target are the timer instructions with the suffix "_MF."

CT: MF counter

The target are the counter instructions with the suffix "_MF."

RI/RJ/RK, WRI/WRJ/WRK, DRI/DRJ/DRK: Index register (excluding timer and counter)

RL/RM: Index resistor (dedicated to timer and counter)


WFL, DFL: File memory

Appendix 8 Project View

<Selecting device address>

The device screen shows 2038 lines from the top of the selected device by default.


To display the lines after them, click the "Next page" button on the bottom right.



[Previous page] button [Next page] button

The [Search] function is also available.

For example, when you want to display "M3000," place the cursor on the device window and press the <Ctrl> + <F> keys. The "Find Tag" dialog box appears. Enter "M3000," and then click the [Find] button. The device window shows 2048 lines, in the middle of which is "M3000."





Appendix 8 Project View

<Local device of program>

Right-click on a program in the project view and select [Device]. The device screen opens. The devices shown there are valid only in the selected program (Ladder0 in the example below) and called "local device."

The local device includes T (timer), TR (integrating timer) and C (counter) and the target address is as follows.

T0 to T8191, TR0 to TR8191, C0 to C8191




Appendix 8 Project View

<Local device of user FB>

Right-click on an FB in the project view and select [Device]. The device screen opens. The devices shown there are valid only in the selected program (FB0 in the example below) and called "local device."

The local device includes T, TR and C, as in that of a program, and F/WF/DF (user FB memory) and V/WV/DV (I/O parameter). For F/WF/DF and V/WV/DV, only the defined memories are displayed.

WF can be retained during a power failure by checking the box of "Retain."




The screenshot shows a window titled 'Local: FB0'. It contains a table with columns: 'Used', 'Device', 'Tag', 'Description', 'Initial Value', and 'Retain'. The table lists three rows: WF0, WF1, and WF2. Each row has an empty 'Retain' checkbox.

Used	Device	Tag	Description	Initial Value	Retain
	WF0				<input type="checkbox"/>
	WF1				<input type="checkbox"/>
	WF2				<input type="checkbox"/>

Appendix 8 Project View

- [Filter] button ⇨ This button opens the “Filter” dialog box. You can filter the devices displayed on the device window. Multiple filter conditions can be specified.

Perform filter setting for each device type. The following screen shows filter setting of M device.



Use: If “in use” is checked, only the devices used in the program are displayed. If “not in use” is checked, only the unused devices are displayed.

Tag: If “has tag” is checked, only the devices that have tags in the program are displayed. By entering characters in the “Tag” box, only the tags that contain the entered characters can be displayed. By using “*”, the devices that partially match the entered characters can be displayed.

Example) If you enter “Mem*”, the tags starting with “Mem” are displayed.

If “no tag” is checked, only the devices without tags are displayed.

Initial value: If “has an initial value” is checked, only the devices in which an initial value is set in the program are displayed. If “no initial value” is checked, only the devices without initial value setting are displayed.

Address range: You can specify the address range to be displayed.

Ignore IO config: If this option is checked, only the I/O devices that have tags are displayed.

- [Update] button ⇨ This button updates the contents of the device screen.

Appendix 8 Project View

- [Use map] button ⇨ When you select a device on the device screen and click this button, the use status of the selected device is shown in map form. The bit addresses used in the program are colored. “W” in the word column indicates that the device is used as word in the program.

Device	F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0	Use as WORD
WM0	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	
WM1																	
WM2	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	W
WM3																	
WM4																	

- [Use status display] ⇨ When the selected device is used in the program,
 - For bit device: a symbol of a contact or coil is shown.
 - For word/double-word device: “*” is shown.
 If the devices is also used as another bit length, “!” is shown.

Used	Device	Tag	Description	Initial Value
!- }	M20	3V+	3V or more	
!- }	M21	8V-	8V or more	
!- }	M22			
!-()-	M23			
!	M24			
!	M25			


In the screen above, symbols of a contact and a coil are shown for M20, which indicates that M20 is used as a contact and a coil in the program. “!” is also shown, which indicates that M20 is also used as another bit length (WM2 or DM2).

Appendix 8 Project View



Appendix 8-3 Unassigned Programs

When you delete a program folder in the project view, it is moved into the “Unassigned Programs” folder. The programs assigned in the “Unassigned Programs” folder are not loaded to the PLC.

<Example of an unassigned program>



Select “Ladder2” and click the key to delete it.



“Ladder2” has moved into “Unassigned Programs.”

Appendix 8 Project View

Appendix 8-4 Function Blocks

“Function Blocks” is a folder to which user FBs (function blocks) are assigned. When expansion FBs provided by Fuji Electric are imported, they are assigned here.

For more details of how to create a user FB, refer to the user’s manual Introduction (FEH597) “4-2 User FB.”

Appendix 8-5 Simulation

“Simulation” is a folder used to create a simulation panel.

For more details, refer to “Appendix 3 Simulator Function.”

Appendix 8-6 Array/Structure

“Array/Struct” is a folder used for the array/structure function.

For more details, refer to “Appendix 4 Arrays/Structures.”

Appendix 8-7 File Defines

“File Defines” is automatically created when a MICREX-F program that contains a file instruction or a table instruction is converted.



Appendix 9 USB Driver Installation

To connect a CPU module with a built-in USB port and a computer using a USB cable, you need to install the USB driver for MICREX-SX in the computer. You can install the USB driver either offline (without connecting the computer to the PLC) or online (by connecting the computer to the PLC).

Appendix 9-1 Offline Installation



This function is supported by Standard loader V3.0.10.19 or later versions and Windows Vista or later operating systems. For older versions of Standard loader and Windows XP or earlier operating systems, follow the procedure explained in “Appendix 9-2 Online Installations.”

- ◆ Click [Start] of Windows > [All Programs] > [SX-Programmer Standard V3] > [Tools] > [USB Driver For MICREX-SX].
The following dialog box opens. Click the [Next] button.




Appendix 9 USB Driver Installation

- ◆ A message appears saying “The drivers are now installing.” If the screen saying “Windows can’t verify the publisher of this driver software” appears, click “Install this driver software anyway.”




- ◆ The screen appears saying “Would you like to install this driver software?” Check [Always trust software from “Fuji Electric Co., Ltd.”], and then click the [Install] button.





Appendix 9 USB Driver Installation


- ◆ The screen appears saying “Completing the Device Driver Installation Wizard.” Click the [Finish] button. The offline installation is now complete.



The actual setup of the driver in the computer is executed when connecting the PLC to the computer using a USB cable. The progress of the setup is displayed on the bottom right of the computer screen.





In the Device Manager, the installed driver software is shown as “MICREX-SX” under “Loader USB device” as shown below.




Appendix 9 USB Driver Installation

Appendix 9-2 Online Installation

Connect the computer to the PLC using a USB cable. A message saying “Installing device driver software” appears on the bottom right of the computer screen. The Windows standard USB driver is installed in this step, therefore, a message saying “Device driver software was not successfully installed” appears next. Perform overwrite installation of the USB driver following the procedure below.




- ◆ Click [Start] of Windows > [Control Panel]. Select “Large icons” for View by,” and then click “Device Manager” from the list.




Appendix 9 USB Driver Installation

- ◆ On the “Device Manager” screen, right-click “Unknown device,” and then select “Update Driver Software.”



- ◆ On the following screen, click “Browse my computer for driver software.”



Appendix 9 USB Driver Installation

◆ On the following screen, click the [Browse] button to specify the location of the USB driver. The USB driver is located in the folder where Standard loader is installed. The default folder where Standard loader is installed differs depending on the computer.



32-bit computer

C:\Program Files\Fuji Electric\SX-Programmer Standard\Driver\MICREXSX

64-bit computer



C:\Program Files(86)\Fuji Electric\SX-Programmer Standard\Driver\MICREXSX

After specifying the folder, click the [Next] button.




Appendix 9 USB Driver Installation

- ◆ A message appears saying “Installing driver software.” If the screen saying “Windows can’t verify the publisher of this driver software” appears, click “Install this driver software anyway.”




- ◆ The screen appears saying “Would you like to install this driver software?” Check [Always trust software from “Fuji Electric Co., Ltd.”], and then click the [Install] button.




Appendix 9 USB Driver Installation

- ◆ The message appears saying “Windows has successfully updated your driver software.” Click the [Close] button. The online installation is now complete.



In the Device Manager, the installed driver software is shown as “MICREX-SX” under “Loader USB device” as shown below.




Appendix 9 USB Driver Installation

Appendix 9-3 When USB Communication Fails

If USB communication fails although the USB driver has been successfully installed, perform the following steps.

(1) Check the status of the PLC

Connectors (IN and OUT) for SX bus expansion are provided on the left end of a PLC base board. Make sure to connect SX bus terminating plugs there. Without them, the loader communication may not be performed normally. In the case of an SX bus expansion system, connect terminating plugs at both ends of the SX bus after connecting an SX bus expansion cable. In the case of a single CPU system, set the CPU No. selection key switch at "0."



(2) Check the status of the computer

If communication cannot be established even after the step (1) is performed, restart the computer. If still not established, try to use another USB port of the computer.

Fuji Electric Co., Ltd.

Gate City Ohsaki, East Tower,
11-2, Osaki 1-chome, Shinagawa-ku, Tokyo 141-0032, Japan

E-mail: micrex-sx@fujielectric.com
URL: <http://www.fujielectric.com/>

Materials covered in this document are subject to revision due to the modification of the product.